

# M-series MQ Controller



*The DeltaV™ MQ Controller and the DeltaV I/O subsystem make rapid installation easy.*

- Increases productivity
- Easy to use
- Has the flexibility to meet your needs

## Introduction

The MQ Controller provides communication and control between the field devices and the other nodes on the control network. Control strategies and system configurations created on earlier DeltaV™ systems can be used with this powerful controller. The MQ Controller provides all the features and functions of the MD Plus Controller, with the same amount of memory.

The control languages executed in the controllers are described in the Configuration Software Suite product data sheet.



## Benefits

### Increases productivity

The MQ Controller is as quick as the MD Plus Controller and provides the same configurable memory as the MD Plus controller, while Enhanced Memory handling got added. The Ethernet ports are full duplex, 100MB/second maximum throughput. The results are lower CPU utilization and higher capacity for control strategies.

**Self-addressing.** The DeltaV controller is unique in its ability to automatically identify itself to the DeltaV control network. When the controller is powered up, it is automatically assigned a unique address—no dip switches, no configuring—*just plug and play!*

**Self-locating.** A controller's physical location is easy to find. LEDs on the face of the controller can be made to flash, providing a strong visual clue.

**Automatic I/O detection.** The controller can identify all I/O interface channels located on the subsystem. As soon as an I/O interface is plugged in, the controller knows the general characteristics of the field devices managed by that I/O interface. This reduces the no value engineering associated with configuration — *easy!*

### Easy to use

**Total control.** The controller manages all control activities for the I/O interface channels. It also manages all communication functions for the communications network. Time stamping, alarming, and trend objects are also managed within the controller. The controller executes all control strategy with execution speeds up to every 100 ms.

**Data protection.** All online changes made to control parameters are automatically stored for later upload into the engineering database. This way, the system always retains a complete record of all the data that has been changed online..

**Cold restart.** This feature provides automatic restart of the controller in case of a power failure. The restart is completely autonomous because the entire control strategy is stored in NVM RAM of the controller for this purpose. Simply set the restart state of the controller to current conditions.



*The MQ Controller*

**Note:** To prevent process disruption during a short power loss, an uninterruptible power supply (UPS) is available for the controller.

### Has the flexibility to meet your needs

**Advanced operations.** The MQ Controller is equipped to handle the DeltaV Batch option, as well as advanced control functions.

You can also use advanced control function such as Neural and Model Predictive Control on the MQ controller.

**Data pass-through.** The controller is equipped with the ability to pass smart HART<sup>®</sup> information from field devices to any workstation node in the control network. This means you can take advantage of applications, such as Asset Management Solutions, that enable you to remotely manage the HART information contained in your HART or FOUNDATION fieldbus-equipped devices.

**Prepares you for the future.** As your system grows, you can expand your software license to increase the number of device signal tags (DSTs) allocated to the DeltaV controller. Begin with 50 and expand to 750 DSTs. Control strategy complexity and control module scan rates determine overall controller performance and application size. A redundant controller may be added to back up an MQ Controller *online*. The standby controller comes online automatically, with a bumpless transition. For more information, refer to the I/O Redundancy product data sheet.

**Mounting.** This plug-and-play system structure provides modular system growth with a single controller and can be mounted in a Class 1, Div 2 or ATEX Zone II environment.<sup>1</sup> Refer to the System Power Supplies and I/O Subsystem Carriers product data sheets for additional information.

---

<sup>1</sup> Refer to Zone 2 installation instructions (12P2046) and/or Class 1 Division 2 installation instructions (12P1293) for details.

## Specifications

Power, Mounting, and Memory	
Power requirement	Supplied by System Power Supply through 2-wide Power/Controller Carrier
Fuse protection	3.0 A, non-replaceable fuses
Power dissipation	5.0 W typical, 7.0 W maximum
Mounting	On right slot of power/controller carrier.
User Memory	48 MB
Primary Control Network	8-pin RJ-45 connector
Redundant Control Network	8-pin RJ-45 connector
LED Indicators (ON Status)	
Green – Power	Indicates DC power is applied.
Red – Error	Indicates an error condition.
Green – Active	Indicates that the controller is operating as the primary controller.
Green – Standby	Indicates that the controller is operating as a backup controller (reserved for future use).
Yellow flashing – Pri. CN	Indicates valid primary control network communication.
Yellow, flashing – Sec. CN	Indicates valid secondary control network communication.
All except Power flashing	Visual identification of controller initiated from user interface software by <i>ping</i> command.
All except Power flashing, alternating even and odd	Firmware upgrade in progress.
Environmental	
Operating temperature	-40° to 70° C (-40° to 158° F)
Storage temperature	-40° to 85° C (-40° to 185° F)
Relative humidity	5 to 95%, non-condensing
Airborne contaminants	ISA-S71.04-1985 Airborne Contaminants Class G3 Conformal coating
Shock (normal operating conditions)	10 g ½-sine wave for 11 ms
Hazardous area/location Refer to Zone 2 installation instructions (12P2046) and/or Class 1 Division 2 installation instructions (12P1293) for information on installing in hazardous areas.	ATEX EEx nA IIC T4 Class 1, Div 2, Groups A, B, C, D, T4
Vibration (operative limit)	1 mm peak-to-peak from 5 Hz to 16 Hz, 0.5 g from 16 Hz to 150 Hz

Ordering Information

Description	Model Number
MQ Controller	CE3008

Prerequisites

- For each controller you will need to select the mounting carrier. Please refer to the I/O Carrier product data sheet for details.
- Each controller requires a dedicated system power supply. Please refer to the Power Supplies product data sheet for details.
- The MQ controller requires DeltaV R5 English or later DeltaV software.

To locate a sales office near you, visit our website at:  
[www.EmersonProcess.com](http://www.EmersonProcess.com)  
Or call us at:  
India: +91 22 66620566  
Asia Pacific: 65.6777.8211

Office Address:  
Emerson Process Management (India) Pvt. Ltd.  
Delphi B-Wing,  
601-602, 6th Floor, Central Avenue,  
Hiranandani Business Park,  
Mumbai-400076

© Emerson Process Management 2016. All rights reserved. For Emerson Process Management trademarks and service marks, go to:  
<http://www.emersonprocess.com/home/news/resources/marks.pdf>.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the design or specification of such products at any time without notice.