

GH BETTIS

OPERATING & MAINTENANCE INSTRUCTIONS

DISASSEMBLY & ASSEMBLY

NCB315-SRXX, NCB415-SRXX, NCB420-SRXX,

NCB520-SRXX, NCB525-SRXX, AND NCB725-SRXX

SPRING RETURN

NUCLEAR SERIES ACTUATORS

PART NUMBER 65035

REVISION "D"

DATE: AUGUST, 1989

REPLACES NUCLEAR-007 (JAN,1986)

ECN	DATE	REV LTR		By *	Date
8609	10/28/85	A	Compiled	Bill S. Cornelius	08-22-89
8689	01/23/86	B	Checked	Louis Duemer	08-22-89
9042	12/03/86	C	Approved	R. R. Kane	08-22-89
10207	06/20/89	D	Approved		

1.0 **INTRODUCTION**

- 1.1 In order to assure and maintain the present level of qualification and auditability to the Bettis Qualification Report number 37274, the following is required:
 - 1.1.1 All maintenance or service work must be performed by a certified technician.
 - 1.1.2 Maintain a service interval of six hundred twenty-five cycles or five years, which ever occurs first.
- 1.2 This service procedure is offered as a guide to enable general maintenance to be performed on GH Bettis NCB Spring Return Series Nuclear Actuators. When the actuator model number has a "-S" as a suffix then the actuator is special and may have some differences that are not included in this procedure.

COMPLETE ACTUATOR REFURBISHMENT
REQUIRES THAT THE ACTUATOR BE
DISMOUNTED FROM THE VALVE

2.0 **BASIC TOOLS**

All tools are American standard inch. Two adjustable wrenches, allen wrench set, small screwdriver with sharp edges rounded off, medium size screwdriver, diagonal cutting pliers, external snap ring pliers, flat file, 1/2" drive ratchet and deepwell socket set, torque wrench (up to 2,000 in.lbs.), commercial leak testing solution, and non-hardening thread sealant.

3.0 **REFERENCE GH BETTIS MATERIALS**

- 3.1 NCB315-SR, NCB420-SR, & NCB525-SR Assembly Drawing Part No. 39585.
- 3.2 NCB315-SR, NCB420-SR, & NCB525-SR Exploded Detail Part No. 65590.
- 3.3 NCB415-SR, NCB520-SR, & NCB725-SR Assembly Drawing Part No. 39587.
- 3.4 NCB415-SR, NCB520-SR, & NCB725-SR Exploded Detail Part No. 65591.
- 3.5 Base I Standard Dimensional Drawing Part No. 65531.

4.0 **GENERAL**

- 4.1 Numbers in parentheses, () indicate the bubble number (reference number) used on the GH Bettis Assembly Drawings, Exploded Detail, and Actuator Parts List.
- 4.2 When removing or installing seals, use a small screwdriver with sharp edges rounded off or use a commercial seal removing tool.
- 4.3 Use a non-hardening thread sealant on all pipe threads.
- 4.4 Disassembly must be done in a clean area on a work bench.
- 4.5 **LUBRICATION REQUIREMENTS:** Dow Corning Molykote 44 medium grade.

5.0 **GENERAL DISASSEMBLY**

- 5.1 The setting of the stop screws (2-70 & 2-80) should be checked and setting recorded before stop screws are loosened or removed.
- 5.2 Remove all operating pressure from actuator allowing the spring to stroke. The spring will rotate to the fail position.
- 5.3 Remove all piping and any accessories mounted on the actuator.
- 5.4 Remove actuator from valve and valve mounting bracket.

- 5.5 Loosen and removes hex nut (2-90) from housing stop screw (2-80). Remove seal washer (3-80) and screw thread seal (3-70) from housing stop screw.
- 5.6 Remove housing stop screw (2-80).

6.0 SPRING CYLINDER DISASSEMBLY

- 6.1 The spring in NCB Series Spring Return Units is preloaded. Unit must be disassembled in the following manner.
- 6.2 Remove the breather (2-130) from the end cap (2-20).
- 6.3 Remove acorn nut (2-110) from spring cylinder end of center bar assembly (2-50).
- 6.4 Using a (1/2" drive) ratchet and socket on the welded nut, located on the housing end of the center bar assembly (2-50), rotate the center bar assembly counter-clockwise (CCW). This will cause the spring cylinder end cap (2-20) to gradually unscrew from the center bar assembly (2-50).
- 6.5 Continue to rotate the center bar assembly (2-50) counter-clockwise (CCW) until the spring preload is eliminated. As the preload is reduced it may be necessary to prevent the spring cylinder end cap (2-20) from turning by holding the end cap stop screw nut (2-90) with an adjustable wrench.
- 6.6 After the spring preload is eliminated, unscrew and remove the spring cylinder end cap (2-20) from the center bar assembly (2-50). It is not necessary to remove the end cap stop screw (2-70) to service the actuator.
- 6.7 Remove the spring (4) from within spring cylinder (2-10).
- 6.8 Hold housing torque shaft (1-30) and pull cylinder (2-10) away from housing (1-10); slide cylinder over piston (2-30) and remove the cylinder.
- 6.9 Pull piston (2-30) out of housing (1-10) and carefully slide piston off center bar assembly (2-50). Roll pin (1-60) and yoke pin (1-40) are removed as part of the piston (2-30).

7.0 HOUSING DISASSEMBLY

- 7.1 On actuators equipped with a cylinder adapter (2-140) NCB-415-SR, NCB-520-SR and NCB-725-SR, remove cylinder adapter (2-140) from the housing.
- 7.2 Slide center bar assembly (2-50) out of housing (1-10).
- 7.3 Cut and remove gasket seal (3-10) from center bar.
- 7.4 Remove both retaining rings (1-80) from torque shaft (1-30).
- 7.5 The following steps may need to be taken before disassembly can continue.
 - 7.5.1 If the torque shaft has any raised burrs or sharp edges they should be filed off, removing as little metal as possible.
 - 7.5.2 If there is excessive paint build-up on torque shaft it should be removed.
- 7.6 Push the torque shaft (1-30) out one side of housing (1-10) until a torque shaft o-ring seal (3-40) is clear of housing. Remove o-ring seal (3-40) from torque shaft.
- 7.7 Push torque shaft (1-30) back thru housing and pull torque shaft completely out of housing while holding yoke key (1-50) in with your fingers.
- 7.8 Remove yoke key (1-50) and yoke key spring (1-70) from torque shaft (1-30).
- 7.9 Remove yoke (1-20) from housing (1-10).

8.0 PRE-ASSEMBLY NOTES

- 8.1 Remove all old seals and gaskets, taking care not to scratch or damage seal grooves.
- 8.2 All parts should be thoroughly inspected. Particular attention should be directed to threads, sealing surfaces and areas that will be subjected to sliding motion. Sealing surfaces must be free of deep scratches, pitting, corrosion and blistering or flaking coating.
- 8.3 After inspection, the parts should be carefully cleaned to remove all dirt, gaskets and other foreign material.
- 8.4 All seals and the groove they fit in are to be lightly lubricated prior to seal installation.

9.0 GENERAL RE-ASSEMBLY

- 9.1 Apply a light coating of lubricant to the housing (1-10) torque shaft holes.
- 9.2 Coat the yoke (1-20) with lubricant and insert into housing (1-10).
- 9.3 Insert the yoke key spring (1-70), with the ends pointing down, into the slot in the torque shaft (1-30) and place the yoke key (1-50) on top of the spring with the tapered side outward. Refer to assembly drawing for correct key orientation.
- 9.4 Hold the yoke key (1-50) down with your thumb, insert the torque shaft (1-30) into and thru the housing and yoke. Rotate the torque shaft until the yoke key snaps into the keyway in the yoke.
- 9.5 Push the torque shaft out of one side of the housing until the o-ring groove is clear of the housing.
- 9.6 Install one of the torque shaft o-ring seals (3-40) into the o-ring groove of the torque shaft (1-30).
- 9.7 Carefully push the torque shaft back into the housing until the o-ring groove on the opposite end of the torque shaft is just clear of the housing.
- 9.8 Install the remaining torque shaft o-ring seal (3-40) into the other o-ring groove of the torque shaft (1-30).
- 9.9 Install one of the torque shaft retaining rings (1-80) onto the torque shaft, making certain it is properly seated in the shaft groove.
- 9.10 Push the torque shaft back into the housing and install the remaining retaining ring (1-80) on the torque shaft.
- 9.11 Rotate the torque shaft so that the yoke arms point outward.
- 9.12 Apply a generous amount of lubricant to the slots in the yoke arms.
- 9.13 Lightly coat the center bar assembly (2-50) with lubricant, being sure to coat the exposed threads.
- 9.14 Slide the gasket seal (3-10) onto the center bar (2-50) until it rests against the welded nut.
- 9.15 Insert the center bar assembly (2-50) into the center hole of housing (1-10) and slide center bar assembly through housing until seal gasket (3-10) and welded nut are flush against the housing. Care should be taken during installation of the center bar so as to not scratch it.
- 9.16 Install cylinder gasket (3-30) on housing flange. On actuators equipped with a cylinder adapter (2-140), NCB-415-SR, NCB-520-SR and NCB-725-SR, install the cylinder adapter (2-140) onto the housing flange, with the stepped outer diameter facing away from the housing, and place a cylinder gasket (3-20) onto the stepped diameter on the cylinder adapter.

10.0 SPRING CYLINDER RE-ASSEMBLY

- 10.1 Lightly recoat the center bar assembly (2-50) with lubricant.
- 10.2 Lightly coat the piston center bar o-ring seal (3-50) with lubricant and install in the internal groove in the head of piston (2-30).
- 10.3 Lightly coat the piston cylinder T-seal (3-60) with lubricant and install onto the piston. T-Seal is composed of rubber (EP) seal and two back-up rings. The rings serve as anti-extrusion back-ups.
- 10.4 Lightly coat the heal of the piston along with the exposed ends of yoke pin (1-40) with lubricant.
- 10.5 With the piston head facing away from the housing (1-10) and with the yoke pin (1-40) up, carefully slide the piston (2-30) onto the center bar assembly (2-50).
- 10.6 Slide the piston (2-30) along the center bar assembly (2-50) until the yoke pin (1-40) engages the yoke slots. Push the piston into the housing as far as it will go, while holding the center bar assembly flush against the housing.
- 10.7 Apply a very thin coating of lubricant to the cylinder bore of cylinder (2-10).
 - 10.7.1 CAUTION: EXCESS LUBRICANT IN THE CYLINDER BORE MAY CAUSE ERRATIC OR JUMPY/JERKY OPERATION.
- 10.8 Slip the lubricated cylinder (2-10) over the piston and onto the flange of housing (1-10). Cylinder (2-10) will slip onto the flange of cylinder adapter (2-140) on NCB415-SR, NCB520-SR, and NCB725-SR models.
- 10.9 Apply a coat of lubricant on the spring and carefully slide the spring (4) into the open cylinder until it contacts the piston head.
- 10.10 Screw the spring cylinder end cap (2-20) onto the center bar assembly (2-50) until it just touches the spring (4).
- 10.11 Position the spring cylinder end cap (2-20) so that the breather port is at the bottom and the stop screw (2-70) is at the top.
- 10.12 Keep the spring cylinder end cap (2-20) from turning by holding the end cap stop screw (2-90) with a wrench.
- 10.13 Using a (1/2" drive) ratchet and socket on the welded nut, located on the housing end of the center bar assembly (2-50), rotate the center bar assembly clockwise (CW). This will cause the spring cylinder end cap (2-20) to gradually screw further onto the center bar assembly (2-50).
- 10.14 Continue to rotate the center bar assembly (2-50) clockwise until the spring (4) is fully compressed, the cylinder is seated against the housing flange or adapter (2-140) and the spring cylinder end cap (2-20) is properly seated against the cylinder (2-10).
- 10.15 Tighten the center bar assembly to the proper torque as specified in Chart 1.
- 10.16 Place the acorn nut (2-110) on the exposed end of the center bar assembly (2-50) and tighten securely.
- 10.17 Lightly coat stop screw (2-80) with lubricant and insert into the housing (1-10) and screw in until stop screw contacts the piston.
- 10.18 Lightly coat stop screw thread seal (3-70) with lubricant and thread onto the stop screw (2-80) until it is flush with the housing.

- 10.19 Slip the seal washer (3-80) onto the stop screw with the chamfer side facing the thread seal (3-70).
- 10.20 Thread the stop screw nut (2-90) onto the stop screw (2-80) until hand tight.
- 10.21 If removed, insert stop screw (2-70) into end cap (2-20).
- 10.22 If removed, thread the remaining stop screw hex nut (2-90) onto SR stop screw (2-70).
- 10.23 Adjust both stop screws (2-70 & 2-80) back to setting recorded in step 5.1 under General Disassembly. Tighten both stop screw hex nuts (2-90) securely, while holding stop screw (2-70 & 2-80). If the stop screw settings were not recorded and cannot be determined, then refer to "Operating & Maintenance Instructions For Initially Setting Travel Stop Screws On CB & NCB Actuators", part number Service 74943.

11.0 ACTUATOR TESTING

- 11.1 All areas where leakage to atmosphere may occur are to be checked using a commercial leak testing solution.
- 11.2 Cycle the actuator five times at the Nominal Operating Pressure as per Chart 2 (for the model being tested). This will allow the seals to seek their proper working attitude.
- 11.3 Stroke the actuator with the Nominal Operating Pressure and allow the unit to stabilize.
- 11.4 Apply a leak testing solution to the following areas:
 - 11.4.1 Cylinder to housing joint on NCB315-SR, NCB420-SR, and NCB525-SR or cylinder to cylinder adapter to housing joints on NCB415-SR, NCB520-SR, and NCB725-SR actuator.
 - 11.4.2 Center bar seal and nut to housing.
 - 11.4.3 Housing stop screw and stop screw thread seal.
 - 11.4.4 Torque shaft seals.
 - 11.4.5 Cylinder breather.
- 11.5 If excessive leakage across the piston is noted (generally a bubble which breaks three seconds or less after starting to form), the unit must be disassembled and the cause of leakage must be determined and corrected.
- 11.6 If an actuator was disassembled and repaired as a result of this procedure, the above leakage test must be performed again.
- 11.7 Operational test the actuator to verify proper function of the actuator. This test is to be done off of the valve or when valve stem is not coupled to the actuator torque plug.
- 11.8 Adjust the pressure regulator to the pressure rating indicated in column "B" of Chart 2, on the following pages for the model actuator being tested.
- 11.9 Apply the above pressure to the actuator and allow the unit to stabilize. The actuator should stroke a full 90 degrees travel with the stops properly set.

12.0 RETURN TO SERVICE

- 12.1 Re-install breather (2-130) into end cap (2-20). A new breather is provided in the service kit.

- 12.2 Re-install actuator to valve mounting bracket and valve.
- 12.3 Re-install any piping and accessories that were removed.
- 12.4 All accessories, including solenoid valves, positioners, pressure switches, etc., must be hooked up at this point and tested for proper operations and replaced if found defective.

CHART 1

TORQUE REQUIREMENTS

FOR CB SERIES CENTER BARS

ACTUATOR MODEL	MAXIMUM TORQUE IN. LBS.	MAXIMUM TORQUE FT. LBS.
NCB315-SRXX	660	55
NCB415-SRXX	660	55
NCB420-SRXX	1,200	100
NCB520-SRXX	1,200	100
NCB525-SRXX	1,560	130
NCB725-SRXX	1,560	130

CHART 2

PRESSURE REQUIREMENTS & LIMITATIONS

FOR NCB SERIES

SPRING RETURN NUCLEAR ACTUATORS

<u>ACTUATOR MODEL</u>	<u>NOMINAL OPERATING PRESSURE</u>	<u>MAXIMUM OPERATING PRESSURE</u>	<u>MAXIMUM HYDROSTATIC TEST PRESS.</u>	<u>MAXIMUM AIR ASSIST PRESSURE</u>	<u>COLUMN B SPRING SELECTION PRESSURE</u>
NCB315-SR40	40	145	240	98	28
NCB315-SR60	60	160	240	86	42
NCB315-SR80	80	170	240	74	56
NCB415-SR40	40	90	160	56	30
NCB415-SR60	60	100	160	48	44
NCB415-SR80	80	115	160	33	57
NCB420-SR40	40	140	240	96	29
NCB420-SR60	60	155	240	83	45
NCB420-SR80	80	165	240	71	58
NCB520-SR40	40	100	160	55	30
NCB520-SR60	60	110	160	43	44
NCB520-SR80	80	125	160	31	59
NCB525-SR40	40	160	240	97	28
NCB525-SR60	60	175	240	84	42
NCB525-SR80	80	190	240	71	57
NCB725-SR40	40	95	160	56	28
NCB725-SR60	60	105	160	43	44

NCB725-SR80

80

120

160

30

58

World Area Configuration Centers (WACC) offer sales support, service, inventory and commissioning to our global customers. Choose the WACC or sales office nearest you:

NORTH & SOUTH AMERICA

19200 Northwest Freeway
Houston, TX 77065
USA
T +1 281 477 4100
F +1 281 477 2809

Av. Hollingsworth,
325, Iporanga Sorocaba
SP 18087-105
Brazil
T +55 15 3238 3788
F +55 15 3228 3300

ASIA PACIFIC

No. 9 Gul Road
#01-02 Singapore 629361
T +65 6501 4600
F +65 6268 0028

No.1 Lai Yuan Road
Wuqing Development Area
Tianjin 301700
P.R.China
T +86 22 8212 3300
F +86 22 8212 3308

MIDDLE EAST & AFRICA

P. O. Box 17033
Dubai
United Arab Emirates
T +971 4 811 8100
F +971 4 886 5465

P. O. Box 10305
Jubail 31961
Saudi Arabia
T +966 3 340 8650
F +966 3 340 8790

24 Angus Crescent
Longmeadow Business Estate
East P.O. Box 6908; Greenstone
1616 Modderfontein, Extension 5
South Africa
T +27 11 451 3700
F +27 11 451 3800

EUROPE

Berenyi u. 72- 100
Videoton Industry Park,
Building #230
Székesfehérvár 8000
Hungary
T +36 22 530 950
F +36 22 543 700

For complete list of sales and manufacturing sites, please visit
www.emersonprocess.com/valveautomationlocations
Or contact us at info.valveautomation@emerson.com

www.emersonprocess.com/bettis

©2016 Emerson Process Management. All rights reserved.

The Emerson logo is a trademark and service mark of Emerson Electric Co. Bettis is a mark of one of the Emerson Process Management family of companies. All other marks are property of their respective owners.

The contents of this publication are presented for information purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the designs or specifications of our products at any time without notice.

BETTIS™



EMERSON™
Process Management