


FBxStation Control™ Application User Manual



Application & Device Safety Considerations

▪ Reading these Instructions

Before operating a device or application, read these instructions carefully and understand their safety implications. In some situations, improper use may result in damage or injury. Keep this manual in a convenient location for future reference. Note that these instructions may not cover all details or variations in equipment or cover every possible situation regarding installation, operation, or maintenance. Should problems arise that are not covered sufficiently in the text, immediately contact Energy and Transportation Solutions (ETS) Customer Support for further information.

▪ Protecting Operating Processes

The failure of a device or application – for whatever reason – may leave an operating process without appropriate protection and could result in possible damage to property or injury to persons. To protect against this, review the need for additional backup equipment or provide alternate means of protection (such as alarm devices, output limiting, fail-safe valves, relief valves, emergency shutoffs, emergency switches, etc.). Contact ETS for additional information.

▪ Using Qualified Personnel

Installation, configuration, and any subsequent modifications to a device or application should only be performed by qualified, suitably trained personnel information.

▪ System Training

A well-trained workforce is critical to the success of your operation. Knowing how to correctly install, configure, program, calibrate, and troubleshoot your Emerson equipment provides your engineers and technicians with the skills and confidence to optimize your investment. ETS offers a variety of ways for your personnel to acquire essential system expertise. Our full-time professional instructors can conduct classroom training at several of our corporate offices, at your site, or even at your regional Emerson office. You can also receive the same quality training via our live, interactive Emerson Virtual Classroom and save on travel costs. For our complete schedule and further information, contact the ETS Training Department at 800-338-8158 or email us at education@emerson.com.

▪ Grounding Equipment

Ground metal enclosures and exposed metal parts of electrical instruments in accordance with relevant safety standards. For the USA, refer to OSHA rules and regulations as specified in *Design Safety Standards for Electrical Systems*, 29 CFR, Part 1910, Subpart S, dated: May 16, 1981 (OSHA rulings are in agreement with the National Electrical Code). For international locations, refer to IEC 60364-4-41: PROTECTION AGAINST ELECTRIC SHOCK. You must also ground mechanical or pneumatic instruments that include electrically operated devices such as lights, switches, relays, alarms, or chart drives. The chassis (or earth ground) lug provides a safe connection point to a customer-designated ground location for ESD and transient voltage suppression. Do not use the chassis ground lug for signal, common, or return connections. **Do not connect the chassis ground lug directly to a lightning arrester/lightning rod.** Do not run signal wiring in conduit or open trays with power wiring or near heavy electrical equipment. If shielded wiring is used, ground the shield of the signal wiring at any one point of the signal loop.

Important: Complying with the codes and regulations of authorities having jurisdiction is essential to ensuring personnel safety. The guidelines and recommendations in this manual are intended to meet or exceed applicable codes and regulations. If differences occur between this manual and the codes and regulations of authorities having jurisdiction, those codes and regulations must take precedence.

▪ Protecting from Electrostatic Discharge (ESD)

Any device contains sensitive electronic components which can be damaged by exposure to an ESD voltage. Depending on the magnitude and duration of the ESD, it can result in erratic operation or complete failure of the equipment. Ensure that you correctly care for and handle ESD-sensitive components.

▪ Ethernet Connectivity

This automation device is intended to be used in an Ethernet network which **does not** have public access. The inclusion of this device in a publicly accessible Ethernet-based network is **not recommended**.

▪ Returning Equipment

If you need to return any equipment to ETS, it is your responsibility to ensure that the equipment has been cleaned to safe levels, as defined and/or determined by applicable federal, state and/or local law regulations or codes. You also agree to indemnify ETS and hold ETS harmless from any liability or damage which ETS may incur or suffer due to your failure to ensure device cleanliness.

Contents

Chapter 1. Introduction	1
1.1 Meters	1
1.2 Stations	2
1.3 Station Control Functions	2
Chapter 2. Installation	3
2.1 Before You Begin	3
2.1.1 Licensing	4
2.2 Installing the Application	5
2.3 Updating an Existing Application	7
2.4 Configuration Overview	8
Chapter 3. Starting the Application	9
3.1 Menu Navigation	9
3.2 Saving Changes	10
Chapter 4. Run Mapping	11
Chapter 5. Site Settings	17
5.1 Site Settings – Station Switches Tab	18
5.2 Site Settings – RCV Switches Tab	19
Chapter 6. Station Control Config - General Tab	21
6.1 Working with the Point Picker	27
Chapter 7. Station Control Config - PID tabs	29
7.1 Primary PIDs	29
7.2 Protection PIDs	30
7.3 Override PIDs	30
7.4 PID Control Parameters	31
7.5 PID Tuning	33
7.5.1 Loop Tuning Procedure	34
Chapter 8. Station Control Config - Control Valves Tab	37

8.1	Control Valve Mapping	39
-----	-----------------------------	----

Chapter 9.	Station Control Config – Bi-Directional Flow Tab	41
-------------------	---	-----------

9.1	DP (Metrology)	42
9.2	Programmed Control	43
9.3	Single DI	50
9.4	Limit Switches	50
9.5	Dual Limit Switches	52
9.6	Software Switch	53
9.7	Frequency (Metrology)	54
9.8	Bi-Directional Flow Control Examples	55
9.8.1	Example 1: 2 Differential Pressure (DP) Meters With a Separate Transmitter for Forward and Reverse DP	55
9.8.2	Example 2: A Single Linear Turbine Meter with one Frequency Output for Forward/Reverse Flow using a Digital Input to Force a Direction Change	59
9.8.3	Example 3: Two Linear Turbine Meters with One Frequency Output for Forward/Reverse Flow Using a Digital Input to Switch Direction	62

Chapter 10.	Station Control Monitor	67
--------------------	--------------------------------	-----------

Chapter 11.	Remote Control Valve Config	75
--------------------	------------------------------------	-----------

Chapter 12.	Remote Control Valve Monitor	79
--------------------	-------------------------------------	-----------

Chapter 13.	Run Staging Configuration	83
--------------------	----------------------------------	-----------

13.1	Tube Settings tab	87
13.2	Valve Settings Tab	90

Chapter 14.	Run Staging Monitor	93
--------------------	----------------------------	-----------

Chapter 15.	Bi-Directional Flow Control Monitor	99
--------------------	--	-----------


15.1	DP (Metrology)	100
15.2	Programmed Control	101
15.3	Single DI	104
15.4	Limit Switches	105
15.5	Dual Limit Switches	107
15.6	Software Switch	109
15.7	Frequency (Metrology)	109

Chapter 1. Introduction

FBxStation Control™ is an application for the Emerson FB3000 RTU you can configure to control multiple natural gas meter runs associated with multiple stations. It operates in conjunction with the standard measurement application included in the FB3000 firmware.

While the FB3000 measurement application supports both natural gas and liquids metering, the FBxStation Control application was designed primarily for control of natural gas meters and stations.

Figure 1-1. Monitor Screen



1.1 Meters

A meter is a device which measures natural gas flow and pressure through a single pipeline or tube. This is referred to a meter run. In some cases, a physical meter can handle measurements for more than a single pipeline/tube (multiple meter runs) but for purposes of this application, the term meter refers to a single meter run.

1.2 Stations

A station is a grouping of one or more meters. The FBxStation Control application running in the FB3000 RTU supports up to 24 stations.

1.3 Station Control Functions

Station Control supports the following functions:

- **Station Regulation** – Through the Station Control Config tabs, you specify whether the station measures flow or energy, and what circumstances cause station valves to shut and what actions to take should an error condition arise. Screens also let you configure PID loops. You also use the Run Mapping tab to import your station and meter run mapping configuration directly from FBxConnect.
- **Run Staging** – On the Run Staging tabs, you identify the order in which meter runs (tubes) become active to achieve the desired flow and pressure.
- **Remote Control Valves** – These valves open and close in response to commands either from FBxStation Control or from a SCADA system to meet the demand for flow or pressure. You specify for FBxStation Control how the valves operate so it can monitor them and initiate open/close commands as needed.
- **Bi-Directional Flow Control (Optional)** – Most natural gas pipelines deliver gas in a single direction. Optionally, the same pipeline can be used to deliver gas in both directions – bi-directional flow, sometimes abbreviated as “bi-di”. FBxStation Control can manage bi-directional flow through the pipeline.

Chapter 2. Installation

2.1 Before You Begin

- You must install the FB3000 RTU on site and connect the field devices associated with meter runs to the I/O modules in the FB3000 RTU. You must ensure the RTU includes sufficient I/O capacity to support the number of stations and meter runs you want to control through FBxStation Control. For example, if you plan to use valve position feedback, ensure you have enough inputs to support that. See the *Emerson FB3000 RTU Instruction Manual (D301851X012)* for information on mounting, wiring, and I/O configuration.
- You must install Field Tools/FBxConnect version 3.11 or newer on a laptop computer and establish communications with the FB3000 RTU through Field Tools, either by a serial or Ethernet connection. See the *Field Tools Quick Start Guide (D301703X412)* for information
- Your FB3000 RTU must be running firmware version 2.11 or newer. See the *FBxConnect Configuration Software User Manual for the FB3000 (D301882X012)* for information about installing a firmware upgrade.
- You must have configured I/O for your field devices in FBxConnect, and you must define your stations and meters in FBxConnect. See the *FBxConnect Configuration Software User Manual for the FB3000 (D301882X012)* for information on these topics.

Note: The Station Control application is designed to control natural gas meters. If your site(s) include a combination of natural gas and liquids metering, we recommended you configure Stations 1 -24 to handle the natural gas meters, and only configure Stations 25 and higher for liquids meters.

Note: The FBxStation Control application is a licensed program (SC04). You must license it prior to the installation.

Once you complete all of these items, you can install the FBxStation Control application.

2.1.1 Licensing

You license the FBxStation Control application in FBxConnect. To see that screen, click **Services > Device License** and add the license file for Station Control you purchased to the device.



Important

If you add an additional FBxStation Control license, you must **stop** the FBxStation Control application and then **start** it, so it recognizes the newly licensed runs/stations. The FBxStation Control license agreement is available for download from Guardian.

Figure 2-1. Licensing in FBxConnect

Desktop_FB3000 - Device license

License information

Date license was applied: 7/7/2022 12:58:05 PM Device serial number: P21220239

Products Features

Summary of products

Product name	Description	In Use	Remaining	Licensed
Click on a product to view its detail information				
SC04	FBxStation Control	6	0	6
LIQC4	Liquid Calcs - includes 4 Mtr Runs (BQM04)	2	0	2
GASC4	Gas AGA/ISO Fiscal Calcs - includes 4 Meter Runs (BQM04)	1	0	1
BQM32	Thirty two Bulk Meter Runs	0	1	1
GSAL4	Gas Calcs + CrudeOil Allocation - includes 4 Mtr Runs(BQM04)	0	1	1
CTL01	Base Control-PID, Action Blocks, Math Blocks, Effects	1	0	1

Features associated with a product


Feature name	AppCode	In Use	Remaining	Quantity	Publisher	Version	Time created	Expiration

Add license file to device Login to manage license Close

Bi-Directional Control License

If you plan to use bi-directional flow control, you must purchase the Station Control Bi-Directional control license (**SCBD**) in addition to any other licenses you have for the device.

Figure 2-2. SCBD License



2.2 Installing the Application



Important

If your FB3000 already includes an earlier version of FBxStation Control, follow the steps in *Section 2.3* before installing the new version.


1. In FBxConnect, click **Applications > Management**.

Figure 2-3. Applications Management




2. Click to select an empty slot (one that has no application) then click **Import application** and navigate to the FBxStation Control ZAP application file and select it.

Figure 2-4. Application Management dialog box



3. Click **Open**.
4. When FBxConnect reports *Application added successfully* click **Close**.

Figure 2-5. Application added successfully




2.3 Updating an Existing Application

To update your application, it must have the same name as the existing application.

1. In FBxConnect, click **Applications > Management**.

Figure 2-6. Application Management



2. Click **Update application** and navigate to the new FBxStation Control ZAP application file (which includes the Configuration.XML file in it) and select it.
3. Click **Open** and wait until FBxConnect reports the update has completed successfully.

2.4 Configuration Overview


Follow these steps in order:

1. Launch Field Tools and create a connection to the FB3000 RTU to launch FBxConnect for online communication with the RTU.
2. In FBxConnect, configure the I/O necessary for station control. See the FBxConnect online help or the *FBxConnect Configuration Software User Manual (For FB3000) (D301882X012)* for details.
3. In FBxConnect define your stations and meters and assign the meters to particular stations. See the FBxConnect online help or the *FBxConnect Configuration Software User Manual (for FB3000) (D301882X012)* for details.
4. From the Application Management page in FBxConnect, install the FBxStation Control Application in the RTU.
5. Start the FBxStation Control application in FBxConnect.
6. Click **Run Mapping** and import the station/meter mapping from FBxConnect that you did in Step 3.
7. Configure Site Settings.
8. Select the station you want to configure.
9. Depending upon whether or not you plan to use Bi-directional flow, you must choose **one** of the following options:
 - Configure parameters on the Station Control Config General tab, and then Configure PIDs on the appropriate PID tabs (Primary PIDs, Protection PIDs, Override PIDs), then tune the loops from the PID tuning screens.
 - Configure bi-directional control parameters on the Station Control Config bi-directional tab.
10. Configure remote control valves.
11. Repeat steps 8 through 10 for additional stations.
12. Use the overview screens to monitor the operation of the loops.
13. Configure meter run staging (optional).

Chapter 3. Starting the Application

1. Click the **Applications** tab in FBxConnect.
2. Expand the Station Control menu and select **Run Mapping**.


Figure 3-1. Calling up the Config Menu



3.1 Menu Navigation


To reach the various screens in FBxStation Control, click the **Applications** tab in FBxConnect, then click the StationControl application name and select from the menu items shown.

Figure 3-2. Calling up Screens



Many screens have tabs or sub-tabs to organize the information related to a particular feature. Click on the tab name to open the tab.


Figure 3-3. Selecting a Tab



3.2 Saving Changes

Before the edits you make in the FBxStation Control application can take effect, you must save them. When you make an edit, FBxStation Control highlights unsaved edits in a golden-brown color. Click **Save** before you move off that tab to save your edits.

Figure 3-4. Highlighting of unsaved changes



- 1 Tab highlighted to indicate un-saved changes.
- 2 Changes you made but have not saved are highlighted.
- 3 Click **Save** to save changes; then those fields are no longer highlighted.

Chapter 4. Run Mapping

Note

Before you attempt to configure any of the major functions in the FBxStation Control application, you must map meters to stations in FBxConnect software **first** from the Meter Setup and Station items on the Configure tab. This sets up the standard firmware functionality in the FB3000. Then you import that configuration into the FBxStation Control application as described in this section.

The FB3000 supports both natural gas and liquid meter types, while FBxStation Control was developed to control natural gas meters and stations only. You should determine the proper meter setup and station assignment in advance, particularly for installations where the FB3000 will be performing both natural gas and liquid metering. Although it is certainly possible to stagger natural gas and liquid metering stations, in order to simplify the configuration process and track station data and functions, we recommend you reserve a contiguous block of stations, starting with 1 and sized based on licensing and future requirements, for natural gas metering.

For example, if you have an installation that will initially incorporate a single SC04 license to control up to 4 meters and stations, but you plan future expansion to control 8 meters and stations, you can use the setup shown below:

- Station 1-4 (current)→ Natural Gas Metering (DP and Linear meter types)
- Station 5-8 (future)→ Natural Gas Metering (DP and Linear meter types)
- Station 9 & up→ Liquids Metering (Liquid Allocation meter types)


Once you complete your mapping in FBxConnect, you can import the mapping into FBxStation Control using the Station Control Run Mapping screen.

On any screen, you can update the data on the screen by clicking **Refresh** and save your edits by clicking **Save**.

You can reach the Station Control Run Mapping screen by either of two ways:

- Select **Run Mapping** from the Station Control application menu in FBxConnect.


Figure 4-1. Calling up the Run Mapping Screen



- Click the **Run Mapping** button on the Station Control Config General tab.

Run Mapping

Figure 4-2. No Meter Runs Mapped Yet




When you open the Run Mapping display it shows the meter setup configured for Station No. 1 measurement. If other stations have been configured, the screen shows additional tabs below the Station_1 tab. If no meters are shown for the selected station, it means the configuration was not completed in FBxConnect.

The Station Control Run Mapping screen shows your existing stations for the current **Site** and their meter runs. You need to bring each station's meter runs into FBxStation Control, and then (if using meter run staging) set a tube rank for each meter run.


1. In the **Site Name** column on the left of the screen, click on a station name and FBxStation Control shows the current meter setup for that **Station** at right in the **Current Meter Setup in Metrology** column including the **Meter ID**, as well as an optional **Description**. The meters are listed in the order they were configured in measurement, with DP Meter types listed first. Descriptions (if shown) come directly from the device configuration.

Figure 4-3. Selecting the Station



2. Click **Save Meters To Station Control** to bring that station and its meters into the application. FBxStation Control copies the details to the **Saved To Station Control** column. This overwrites any previously saved details for this station.

Figure 4-4. Saving Meters into Station Control



Note: If you realize you made a mistake and want to remove **all** the saved information, you can click **Clear All Saved Meters**.

3. If you plan to use meter run staging (tube staging) use the up and down arrow controls to assign a **Tube Rank**. Rank refers to order in which a run is opened or

closed, as flow varies through the station. The run ranked 1 will open first, to meet any demand for flow. The runs ranked 2 and higher will open as the flow through the station increases and more runs are required. In a given station, no meter run (tube) should have the same rank as another meter run (tube). If you do **not** plan to use meter run staging, you should leave the **Tube Rank** at the default value.

Figure 4-5. Setting the Tube Rank

Meters Saved To Station Control				
Stn	Run	Meter ID	Meter Description	Tube Rank
1	1	DP Mtr_1	Meter 1ab	2
1	2	DP Mtr_2	Meter 2ab	4
1	3	DP Mtr_3	Meter 3	1
1	4	DP Mtr_4	Meter 4	3

4. If you have made changes to the **Description** in FBxConnect metrology and want them reflected in Station Control, click **Update Description in S.C.**
5. The **SC BiDi License Status** shows **Enabled** if bi-directional control is licensed for these stations; or **Disabled** if bi-directional control is not licensed.
6. Repeat steps 1, 2, and 3 for each additional station. When you finish, click **Save** to save all your changes.

The center of the Station Control Run Mapping screen includes a Licensing box. As you copy station and meter run configurations into FBxStation Control, it maintains a count of the available licenses and monitors to see that your configuration does not exceed any licensing limits.

Figure 4-6. Licensing

Licensing

Number SC Licenses

Number Saved Stations

Number Saved Meters

Remaining SC Licenses

Number Meters This Station

Status

OK

Number SC Licenses

The number of FBxStation Control licenses currently installed in this device.

Number Saved Stations	The number of different stations you have brought into FBxStation Control.	
Number Saved Meters	The total number of meters across all stations under FBxStation Control.	
Remaining SC Licenses	The number of unused FBxStation Control licenses remaining. A negative number means you have used up all your purchased licenses and are trying to use more than you have purchased.	
Number Meters This Station	The number of meters for the currently selected station.	
Status	Status messages include:	
	No Status	The status check operation has not executed or is pending.
	No Meters Setup For This Station	Nothing has been configured in FBxConnect for the selected station.
	No Meters Saved For This Station	The meter setup for the selected station has not been saved to Station Control.
	Saved Meter Mismatch	The meter setup saved to Station Control for the selected station does not match the current meter setup in FBxConnect.
	OK	The saved meter setup for the selected station matches the current meter setup in FBxConnect.

If Status indicates you have exceeded a limit, and you want to start over, click **Clear All Saved Meters**, and make different choices that do not exceed the licensing limits. You would also clear the meters if you modify the meter-station mapping in FBxConnect



Important


If you add an additional FBxStation Control license, you must **stop** the FBxStation Control application and then **start** it, so it recognizes the newly licensed runs/stations.

Chapter 5. Site Settings

FBxStation Control includes 24 switches you can associate with individual valves. These switches support a lockout of either local control (FBxConnect user) or remote (SCADA system) control of the valves.

To reach the Site Settings – General tab, select **Site Settings** from the Station Control application menu in FBxConnect.

Figure 5-1. Site Settings – General tab



Under **Control Mode** if you choose **Site Wide**, all stations, valves, and switches support whatever access you choose under **Site Switch** - either **Remote** (SCADA system access) or **Local** (FBxConnect/FBxStation Control access). Click **Save** to save that choice.

You can use **Site Switch Point** to specify a database tag, the value of which will determine whether **Local** or **Remote** is active. If you configure the tag, the **Site Switch** box disappears. The database tag must be type BOOL; a state of FALSE chooses **Remote**; a state of TRUE chooses **Local**.

If you choose **Configurable**, the Site Switch field disappears, and a table of switches shows on the **General** tab, and FBxStation Control shows two new tabs (**Station Switches** and **RCV Switches**).

Figure 5-2. Configurable Mode – Choosing Local or Local/Remote

The screenshot shows the 'Site Settings' window with the 'Station Switches' tab selected. Under 'Control Mode', the 'Configurable' radio button is chosen. Below, there are two columns of switches, each with 12 entries. Each entry has three radio buttons: 'Local / Remote' (which is selected for all), 'Local Only', and 'Local Only'. At the bottom of each column, there are two 'Select All' buttons.

Choose **Local/Remote** if you want both local control (FBxConnect user) and remote control (SCADA system). This allows both someone making local changes in a Station Control screen, as well as a remote SCADA system to issue commands to an associated station or valve. If you want to set that for every switch in a column, choose **Select All**.

Choose **Local only** to allow someone making local changes in a Station Control screen to issue commands to an associated station or valve, but to lockout commands issued from a remote SCADA system. If you want to set that for every switch in a column, choose **Select All**.

On any screen, you can update the data on the tab by clicking **Refresh** and save your edits by clicking **Save**.

5.1 Site Settings – Station Switches Tab

By default, Station 1 is associated with Switch 1, Station 2 is associated with Switch 2, and so on. On the Station Switches tab, you can associate a station with any of the 24 switches. You can also associate the same switch with more than one station. You cannot, however, associate a station with more than one switch.

Figure 5-3. Station Switches Tab

Site Settings

General **Station Switches** RCV Switches

	Station Tag	Switch		Station Tag	Switch
1	Station_1	1	1	Station_13	13
2	Station_2	3	2	Station_14	14
3	Station_3	3	3	Station_15	15
4	Station_4	4	4	Station_16	16
5	Station_5	5	5	Station_17	17
6	Station_6	6	6	Station_18	18
7	Station_7	7	7	Station_19	19
8	Station_8	8	8	Station_20	20
9	Station_9	9	9	Station_21	21
10	Station_10	10	10	Station_22	22
11	Station_11	11	11	Station_23	23
12	Station_12	12	12	Station_24	24

5.2 Site Settings – RCV Switches Tab

By default, Station 1 is associated with Remote Control Valve (RCV) 1, Station 2 is associated with RCV 2, and so on. On the RCV Switches tab, you can associate a remote control valve with any of the 24 switches. You can also associate the same switch with more than one RCV. You cannot, however, associate an RCV with more than one switch.

Figure 5-4. RCV Switches Tab

Site Settings

General Station Switches **RCV Switches**

	RCV Tag	Switch
1	SC RCV_1	1
2	SC RCV_2	2
3	SC RCV_3	3
4	SC RCV_4	4
5	SC RCV_5	5
6	SC RCV_6	6
7	SC RCV_7	7
8	SC RCV_8	8
9	SC RCV_9	9
10	SC RCV_10	10
11	SC RCV_11	11
12	SC RCV_12	12

FBxStation Control™ Application User Manual

D301919X012

March 2024

Chapter 6. Station Control Config - General Tab

Go to Station Control Config and select the Station you want to configure from the listed instances:

Figure 6-1. Navigating to Station Control Config






Figure 6-2. Selecting the Station



The General tab defines certain parameters that apply to the entire station.

Figure 6-3. Station Control Config tab



You can update the data on the tab by clicking **Refresh** and save your edits by clicking **Save**.

Station Control

Enable Click to activate the station control functions for this station.

Disable Click **Disable** to turn off the station control functions for this station. You should leave station control disabled until you have fully configured the Station Control application.

Flow/Energy Select

A station can control either flow or energy; they are mutually exclusive.

Flow Choose if this station runs a **Flow** control loop.

Energy Choose if this station runs an **Energy** control loop.

Action on Zero Setpoint

Note: Fast Close and Close at Low PV are mutually exclusive choices; you can only enable one of these at any given time.

Fast Close

Click **Enable** to allow this station to shut valves quickly (Fast Close) when the setpoint is 0%.

Click **Disable** to prevent Fast Close.

Close at Low PV

If you choose **Enable**, when the process variable for this station falls below a certain user-defined value or percentage, close valves. Valves close more gradually than with the Fast Close option.

Choose **Disable** to turn off the close at low PV option.

Low PV Limit

If **Close at Low PV** is enabled, select “%” to set a percentage, or “UNITS” to enter a value. Enter the percentage or value in the **Low PV Limit** field.

One Step Remote Control

- | | |
|----------------|--|
| Enable | Valves operate by a single Execute signal. |
| Disable | Valves operate in ARM and Execute mode. This means an ARM signal comes on for 5 seconds, and an Execute signal must turn on within that same 5 second period to actuate the valve; otherwise, both ARM and execute signals turn off. |

Meter Protection

- | | |
|----------------|---|
| Enable | Activate meter protection PIDs for out-of-range process values. |
| Disable | De-activates meter protection PIDs. |

Action on Bad Data

- | | |
|-----------------|---|
| Continue | When questionable data is detected on a PID control, FBxStation Control continues using the questionable data for that PID control. |
|-----------------|---|

Track When questionable data is detected, FBxStation Control disables the relevant loop.

Action on Disable

Specifies action to take when Station Control is disabled.

Shutin If Station Control is disabled, the station is shut in; all valves are closed.

Hold If Station Control is disabled, all valves are left in their current position.


Action on No Control

When all primary loops are disabled, or tracking is active because the Qbit is TRUE (questionable data), this specifies the action to take.

Shutin If all primary loops are disabled or tracking active, the station is shut in; all valves are closed.

Hold If all primary loops are disabled or tracking active, all valves are left in their current position.

Alt Outlet Pressure Source

Enable If you want to specify an alternate outlet pressure source to use if there is a problem with the standard outlet pressure source, select this and then click the point picker  to specify the parameter which represents the alternate outlet pressure source value.


Disable There is no alternate outlet pressure source.

Run Mapping Click this button to map meter runs.

BiDi Mode This option is only shown for even-numbered stations.

Forward This is the default – no bi-directional flow.

Reverse This allows for bi-directional control for this pair of stations. Once you select this, FBxStation Control makes the Bi-Directional Flow tab visible.



Bi-Directional Settings

Process Variables

When in bi-directional control mode, the point picker buttons on the PID loop pages are disabled. Click the Process Variables button to select the process variables used in bi-directional control.




Figure 6-4. BiDi PVs

BiDi PV									
SC SInChl_2 (Station Control_2)									
PID	Description	Current PV	Forward PV	Reverse PV	MP Run	Description	Current PV	Forward PV	Reverse PV
Flow	Flow	Station_1.SVOL_RATE	Station_1.SVOL	Station_2.SVOL	Meter Protect 1	Meter Protect 1	Undefined	Undefined	---
Energy	Energy	Station_1.ENERGY_RATE	Station_1.ENERG	Station_2.ENERG	Meter Protect 2	Meter Protect 2	Undefined	Undefined	---
Outlet Press	Outlet Press	SC SInChl_1.OUTLET_P	SC SInChl_1.OIL	SC SInChl_2.OIL	Meter Protect 3	Meter Protect 3	Undefined	Undefined	---
Primary 4	Primary 4	Undefined	Undefined	Undefined	Meter Protect 4	Meter Protect 4	Undefined	Undefined	---
MAOP	MAOP	SC SInChl_1.OUTLET_P	SC SInChl_1.OIL	SC SInChl_2.OIL					
Max Outlet Press	Max Outlet Press	SC SInChl_1.OUTLET_P	SC SInChl_1.OIL	SC SInChl_2.OIL					
Min Inlet Press	Min Inlet Press	SC SInChl_1.INLET_P	SC SInChl_1.IN	SC SInChl_2.IN					
Min Outlet Press	Min Outlet Press	SC SInChl_1.OUTLET_P	SC SInChl_1.OIL	SC SInChl_2.OIL					


Config Error Number of Fwd/Rev Runs Mismatch

Apply Default PV's

Refresh Save Cancel

- PID** Shows the name of the loop.
- Description** Shows a short description for the loop.
- Current PV** Shows the current process variable monitored by this loop.
- Forward PV** Click the point picker  to specify the process variable that applies for this loop when bi-directional control operates in the forward flow direction.
- Reverse PV** Click the point picker  to specify the process variable that applies for this loop when bi-directional control operates in the reverse flow direction.
- MP Run** Shows the name of the Meter Protection run.
- Description** Shows a short description of the meter protection run.
- Current PV** Shows the current process variable monitored by this meter protection run.
- Forward PV** Click the point picker  to specify the process variable that applies for this meter protection

run when bi-directional control operates in the forward flow direction.


Reverse PV Click the point picker  to specify the process variable that applies for this meter protection run when bi-directional control operates in the reverse flow direction.

Apply Default PVs If you decide you want to restore the default process variables for the loops, instead of any pVs you picked with the point picker, click **Apply Default PVs**.

ESD


Enable Emergency Shut Down (ESD) closes all valves for a station (called a “shut-in”) when FBxStation Control receives notification of an emergency condition.


Disable Emergency Shut Down (ESD) function is disabled.

ESD Point When enabled, Emergency Shut Down (ESD) closes all valves for a station when FBxStation Control receives notification of an emergency condition. Use the point picker  to specify the parameter which reports the emergency condition.

Latch Station ESD When set to Yes – The station remains shut even when the ESD condition clears. You must manually reset the ESD condition using the Reset ESD button on the monitor screen to allow operation of the station to resume.

When set to No – The station operation resumes when the ESD condition clears.


Inlet Pressure Source Click the point picker  to specify the parameter which represents the inlet pressure source value.

Outlet Pressure Source Click the point picker  to specify the parameter which represents the outlet pressure source value.

Note


When using bi-directional flow control, you must specify an inlet pressure source and outlet pressure source for both the forward and reverse stations.

6.1 Working with the Point Picker

FBxStation Control has the same point picker button available in FBxConnect. Many fields are already populated with default parameters. Unless you have a specific reason to use something other than default, you should accept the default. If there is no default specified, or you want to replace the default specified with something else, click the point picker .

In the Point Picker, use the filter menu to select the object or instance, for example, **Meter Objects**.

Figure 6-5. Selecting the Type of Objects in the Point Picker




Now click the **Collect Tag Names** button.

The Point Picker searches for all the object's tag names and displays them in the Objects and Instances pane.

Select the name of the parameter you want for this field and click **OK**.

Figure 6-6. Selecting the Object



Chapter 7. Station Control Config - PID tabs

Proportional, Integral, and Derivative (PID) control loops compare the value of a process variable (PV) to a pre-defined setpoint (SP) which is the desired new value for that process variable. To reach that desired value, the control output of the PID, manipulates another variable called the variable (MV) to minimize the error – the difference between the PV value and SP value. For example, to increase a flow rate to its desired setpoint, a valve is opened a certain percentage thereby increasing the flow, until the desired setpoint is reached; in that example, the valve position is the MV and the flow rate is the PV.

FBxStation Control supports primary PIDs, Protection PIDs, and Override PIDs.

On any screen, you can update the data on the tab by clicking **Refresh** and save your edits by clicking **Save**.

7.1 Primary PIDs

There are four primary PIDs per station – three for specific process variables (station flow rate, station energy rate, and station outlet pressure) and the fourth you can configure for the process variable of your choice, it has no default PV. Click the **Primary PIDs** tab in Station Config to configure these.

Note: Flow rate and energy rate are mutually exclusive; you can only choose one or the other for a particular station at a given time.

Figure 7-1. Primary PIDs tab

The screenshot displays the 'Station Control Config' interface with the 'Primary PIDs' tab selected. The interface is organized into four columns, each representing a primary PID configuration:

- Primary 1 - Station Flow Rate:**
 - Enable Status:** ☒ Enable, ☐ Disable
 - General:** Tag: Flow, Desc: Flow
 - Process Variable:** Point: Station_1.SVOL_RATE, PV Max: 1000.0
 - Settings:** Setpoint Ramp R...: 10.0 Units/Sec, Deadband: 0.0 %
 - Tuning:** Gain: 1.0, Integral: 1.0 rpm, Derivative: 0 min
- Primary 2 - Station Energy Rate:**
 - Enable Status:** ☐ Enable, ☒ Disable
 - General:** Tag: Energy, Desc: Energy
 - Process Variable:** Point: Station_1.ENERGY_RATE, PV Max: 1000.0
 - Settings:** Setpoint Ramp R...: 0.0 Units/Sec, Deadband: 0.0 %
 - Tuning:** Gain: 1.0, Integral: 0.0 rpm, Derivative: 0 min
- Primary 3 - Station Outlet Press:**
 - Enable Switch:** ☐ Enable, ☒ Disable
 - General:** Tag: Outlet Press, Desc: Outlet Press
 - Process Variable:** Point: SC StnCtrl_1.OUTLET_PRES, PV Max: 1000.0
 - Settings:** Setpoint Ramp R...: 0.0 Units/Sec, Deadband: 0.0 %
 - Tuning:** Gain: 1.0, Integral: 0.0 rpm, Derivative: 0 min
- Primary 4 - Configurable:**
 - Enable Switch:** ☐ Enable, ☒ Disable
 - General:** Tag: Primary 4, Desc: Primary 4
 - Process Variable:** Point: Undefined, PV Max: 1000.0
 - Settings:** Setpoint Ramp R...: 0.0 Units/Sec, Deadband: 0.0 %
 - Tuning:** Gain: 1.0, Integral: 0.0 rpm, Derivative: 0 min

A 'PID Tuning' button is located at the bottom left of the Primary 1 configuration panel.

7.2 Protection PIDs

Protection PIDs only activate when the setpoint of the PV is exceeded. The Station MAOP PID has highest priority, then the protection PIDs. The primary PID resumes control when the process variable returns to the acceptable range (at or below the setpoint). Click the **Protection PIDs** tab in Station Control Config to configure these.

Figure 7-2. Protection PIDs tab

The screenshot displays the 'Station Control Config' window with the 'Protection PIDs' tab selected. The interface is organized into several sections:

- Station MAOP:** Includes an 'Enable Switch' (set to 'Enable'), 'General' fields (Tag: MAOP, Desc: MAOP), 'Process Variable' (Point: SC StnCtrl_1/OUTLET_PRES, PV Max: 1000.0), 'Settings' (Control Action: Forward, Setpoint Ramp Rate: 0.0 Units/Sec, Deadband: 0.0 %), and 'Tuning' (Gain: 1.0, Integral: 0.0 rpm, Derivative: 0 min). A 'PID Tuning' button is at the bottom.
- Meter Protection PIDs:** A sub-tab for 'Meters 1-3' and 'Meters 4-6'. It contains three identical configuration blocks for 'Meter #1 Protection', 'Meter #2 Protection', and 'Meter #3 Protection'. Each block includes:
 - Enable Switch:** 'Meter #1' is 'Enable', 'Meter #2' and 'Meter #3' are 'Disable'.
 - General:** Tag and Desc fields (e.g., Meter Protect 1).
 - Process Variable:** Point (e.g., DP Mtr_1/DP_INUSE), PV Max (1000.0).
 - Settings:** Setpoint Ramp Rate (0.0 Units/Sec), Deadband (0.0 %).
 - Tuning:** Gain (1.0), Integral (0.0 rpm), Derivative (0.0 rpm).

Buttons for 'Use Default PVs' and 'MPPID Tuning' are located between the MAOP and Meter sections. At the bottom right are 'Refresh' and 'Save' buttons. The status bar at the very bottom shows 'admin', 'Online', 'FB3000', 'IP: 192.168.2.10.20000', and '100 %'.

7.3 Override PIDs

Like meter protection PIDs, if the PV in a primary PID exceeds the setpoint, an override PID takes control until the PV comes back into normal operating range. Once back in normal operating range, the primary PID resumes control. Click the **Override PIDs** tab in Station Control Config to configure these.

Override 1 and 2 default to inlet and outlet pressure, respectively, but you can change them.

Figure 7-3. Override PIDs

7.4 PID Control Parameters

Unless otherwise noted, all these parameters apply to Primary PIDs, Protection PIDs, and Override PIDs.

Enable Status / Enable Switch

Enable Click to activate this PID loop.


Disable Click to de-activate this PID loop.

General

Tag A name used on the monitor screen to identify the control box for the loop, such as “Flow” shown, below.

Desc A description for the loop also shown on the overview screen.

Process Variable

Point	The AI point used as the process value for the PID. Click the point picker button  to select the AI point.
PV Max	The maximum value for the process value.

Settings

Control Action (MAOP PID on Protection PIDs tab only)	<p>Note: This setting is only available on specific PIDs such as MAOP and the Override PIDs 1, 2, and 3.</p> <p>Important: Exercise care when selecting the proper control action. The choice of setting depends on the relationship of the selected process variable to the control action of the output device, typically a station valve. For example, if Override 1's default PV is Station Outlet Pressure and the loop will be limiting the outlet pressure to some maximum value, reverse control action is required to reduce the control output and close the station valve when PV exceeds setpoint (SP). If the control action is erroneously set to Forward, the control action causes the station valve to open further, resulting in increased outlet pressure.</p> <p>Forward When the control action is set to Forward, the PID output increases when the assigned PV value exceeds setpoint (SP).</p> <p>Reverse When set to Reverse, the output decreases when the PV value exceeds setpoint (SP).</p>
Setpoint Ramp Rate	The rate at which a change in setpoint should be applied to the loop.
Deadband	A calculated loop output which does not vary by more than the percent specified here will not change the output.

Tuning

Gain	The proportional gain which determines the amount of output change produced by a change of error.
Integral	Integral establishes the reset rate in "repeats per minute" for the loop.

Derivative Derivative establishes a scale factor to determine how much the rate-of-change of the manipulated variable (MV, not error) affects the function block output. The numerical entry for this parameter represents the amount of rate correction in minutes.

Use Default PVs Click this button on the Protection PIDs tab if you want to use the default process variables FBxStation Control uses for protection PIDs. For orifice meters, the default is DP; for linear meters, the default is uncorrected flow rate. If you do **not** want to use the defaults, select the variables yourself using the point picker.

7.5 PID Tuning

Click **PID Tuning** or **MPPID Tuning** to bring up the tuning screen.

Figure 7-4. PID Tuning Screen



Enable Switch

Enable Click to activate this PID loop.


Disable Click to de-activate this PID loop.

General

Tag A name used on the overview screen to identify the control box for the loop.

Desc	A description shown on the control box for the loop.
-------------	--

Process Variable

Point	The AI point used as the process value for the PID. Click the point picker button  to select the AI point.
--------------	---

Max Value	The maximum value for the process value.
------------------	--

Settings

Direction	Set to either Low or High.
------------------	----------------------------

Setpoint Ramp Rate	The rate at which a change in setpoint should be applied to the loop.
-------------------------------	---

Output Deadband	A calculated loop output which does not vary by more than the percent specified here will not change the output.
----------------------------	--

Tuning

Gain	The proportional gain which determines the amount of output change produced by a change of error.
-------------	---


Integral	Integral establishes the reset rate in “repeats per minute” for the loop.
-----------------	---

Derivative	Derivative establishes a scale factor to determine how much the rate-of-change of the process variable (not error) affects the function block output. The numerical entry for this parameter represents the amount of rate correction in minutes.
-------------------	---

7.5.1 Loop Tuning Procedure

This PID tuning procedure presents one possible approach. Consult books or online resources on PID tuning if necessary.

1.To begin, select the desired PID loop from the drop-down menu.



2. In the **Max Value** field, specify the maximum possible value that could ever be measured for the process variable in this loop. For example, this might be the span of the transmitter, or the maximum possible flow through this station.
3. Specify a **Setpoint Ramp Rate** in units/second to indicate how quickly a change in setpoint should be applied. If you leave at zero, changes are applied immediately – without any ramping.
4. Set initial values for **Gain**, **Integral**, and **Derivative**. One way to determine these is to use the Ziegler/Nichols method. Consult resources as needed.
5. Set **Output Deadband** to define a range above and below the output within which a fluctuation in the calculated output will not result in a change in the actual output.
6. Enable the loop.
7. While monitoring the trend window, make small incremental changes to the setpoint, and observe how it affects the PV. Adjust **Gain**, **Integral**, and **Derivative** as needed to achieve smooth, stable control.

Chapter 8. Station Control Config - Control Valves Tab

Click the **Control Valves** tab in Station Control Config to configure these, then select the valves you want to configure.

You can update the data on the tab by clicking **Refresh** and save your edits by clicking **Save**.

Figure 8-1. Station Config – Control Valves tab

The screenshot displays the 'Station Control Config' window with the 'Control Valves' tab selected. The window is divided into several sections. On the left, there is a sidebar with 'Valves 1-3' and a 'CV Mapping' button. The main area is divided into two columns for 'Control Valve #1' and 'Control Valve #2'. Each column contains the following sections:

- General:** Tag and Desc fields.
- Permissive:** Permissive Point dropdown menu.
- Operate Range:** Input Low Range and Input High Range fields.
- Settings:** Valve Action dropdown menu and Output Ramp Rate field.
- Valve Type:** Valve Type dropdown menu, Open Cmd Obj, Close Cmd Obj, PDO Mode dropdown menu, Travel Time field, Min Pulse, and Max Pulse fields.
- Position Feedback:** Analog Feedback Pnt, Open Limit Point, and Close Limit Point fields.

At the bottom right of the window, there are 'Refresh' and 'Save' buttons. The bottom status bar shows 'admin', 'Online', 'FB3000', 'IP: 192.168.2.10.20000', and a '100 %' scale indicator.

General

Tag

A tag name used as a label for the box on the overview screen associated with the valve.

Desc

A description for the valve also appearing in the box on the overview screen.

Permissive

Permissive Point

Associate the control valve with a particular tube staging meter run. The valve only operates when that meter run is open.

Operate Range

Defines the normal operating range for the valve. If there are multiple valves associated with the station, you might choose to split the ranges so certain valves cover a certain range.

Input Low range

Defines the lowest percent open the valve should be to remain in the normal operating range. You can set the **Input Low Range** to a negative value so the valve operates over a shorter range.

Input High range

Defines the highest percent open the valve should be to remain in the normal operating range.

Settings

Valve Action

Set to either Direct for direct action or Indirect for indirect action. Direct action increases the valve output as the input increases. Indirect action decreases the valve output as the input increases.

Output Ramp Rate

The rate at which a change in setpoint should be applied to the valve as a percentage of valve travel per second.

Valve Type

Valve Type

Choose Analog if the valve has analog position feedback or Raise Lower if the valve is pulsed and receives feedback from opened and closed limit switches.

Analog Out Obj


Click the point picker button  to select the analog output point which controls the valve.

Position Feedback


Analog Feedback Point

Click the point picker button  to specify the analog input which reports the current position of the valve.

Open Limit Point

Click the point picker button  to specify the bool which reports the current position of the valve is totally open.

Close Limit Point

Click the point picker button  to specify the bool input which reports the current position of the valve is totally closed.

CV Mapping

Click here to call up the Control Valve (CV) Mapping screen.


8.1 Control Valve Mapping

You can map a valve to any station, but the valve can only be mapped to one station at a time. You can also map multiple valves to one station which allows you to split the ranges at which valves operate.

To assign a valve to a station:

1. Choose the valve (based on its number in the CV column).
2. Type in the number of the station (or use the arrows to adjust the number).
3. If you want to assign additional valves to particular stations, repeat steps 1 and 2 for each valve.
4. Click **Save** to store the valve/station assignments.

Figure 8-2. Control Valve (CV) Mapping



CV	Station Assignment
1	StnCtrl Output : 1
2	StnCtrl Output : 2
3	StnCtrl Output : 3
4	StnCtrl Output : 1
5	StnCtrl Output : 5
6	StnCtrl Output : 6
7	StnCtrl Output : 7
8	StnCtrl Output : 8
9	StnCtrl Output : 9
10	StnCtrl Output : 10
11	StnCtrl Output : 11
12	StnCtrl Output : 12

CV	Station Assignment
13	StnCtrl Output : 13
14	StnCtrl Output : 14
15	StnCtrl Output : 15
16	StnCtrl Output : 16
17	StnCtrl Output : 17
18	StnCtrl Output : 18
19	StnCtrl Output : 19
20	StnCtrl Output : 20
21	StnCtrl Output : 21
22	StnCtrl Output : 22
23	StnCtrl Output : 23
24	StnCtrl Output : 24


Refresh Save Cancel

Chapter 9. Station Control Config – Bi-Directional Flow Tab

By default, flow through the pipeline travels in a single direction. Bi-directional flow allows the flow of gas through a single pipeline to change its direction from forward-to-reverse or reverse-to-forward. To use bi-directional flow, you must configure a pair of consecutively numbered stations for the same pipeline – the first (odd-numbered) station handles forward flow, the second (even-numbered) station handles reverse flow.


Station Control only displays the **Bi-directional Flow** tab if you select **Reverse** as the **BiDi Mode** on the **Station Control Config – General tab** for the second station (even-numbered station) in a pair of consecutively numbered stations.

Figure 9-1. Selecting the BiDi Mode on the General Tab



When configuring the even-numbered station, you must select the indication method for bi-directional control. **This choice determines what variable causes a direction change.**

Figure 9-2. Choosing the Direction Indication Method



The Programmed Control, Single DI, Software Switch, Limit Switches, and Dual Limit Switches direction indication methods include a **Flow Cut-off Config** button which opens a pop-up screen in which you can specify a no flow cutoff

value for a meter. This overrides any cutoff specified in the DP/Linear meter setup in FBxConnect. Simply enter the value below which flow should be stopped in the **No Flow Cut-off** field and click **Save**.

Figure 9-3. No Flow Cut-off

Meter	Description	Station	No Flow Cut-off
Linear Mtr_1	Meter 1	3	0.1
Linear Mtr_2	Meter 2	3	0.1
Linear Mtr_3	Meter 3	4	0.1
Linear Mtr_4	Meter 4	4	0.1

Note

The no flow cut-off does not apply to the DP and frequency indication methods which use the cutoff specified in the DP/Linear meter setup in FBxConnect.

On any screen, you can update the data on the tab by clicking **Refresh** and save your edits by clicking **Save**.

The sections that follow cover the various indication methods.

9.1 DP (Metrology)

When you choose DP (differential pressure), the value of differential pressure, as determined by the standard firmware functionality in the RTU (standard metrology), determines whether flow direction for this station should be forward or reverse.

Figure 9-4. Bi-Directional Control - DP

Station Control Config

SC StrCtrl_1 (Station Control_1)

General Primary PIDs Protection PIDs Override PIDs Control Valves **Bi-Directional Flow**

Method **DP** Programmed Control Single DI Limit Switch Dual LS Software Switch Frequency

Direction Indication Source

Direction Indication Method: DP (Metrology)

Label Configuration


Transfer Point A: Undefined Transfer Point B: Undefined

Direction Label: Inject/Withdrawl

Label

Configuration

Figure 9-5. Transfer Point Labels



Transfer Point A

Specify the text that appears in the Bi-Directional Monitor display on the **left** of the direction graphic in the Current Rate & Totals.


Transfer Point B

Specify the text that appears in the Bi-Directional Monitor display on the **right** of the direction graphic in the Current Rate & Totals.

Direction Label

Normally, the terms "Forward" and "Reverse" show the direction in various places on FBxStation Control displays. Optionally, you can use this drop-down to select alternate pairs to use instead of Forward/Reverse. Among the choices are "Inject/Withdrawl" and "Delivery/Receipt."


Figure 9-6. Direction Label



9.2 Programmed Control

When you choose **Programmed Control**, FBxStation Control manipulates up to 8 block valves in a predefined sequence to change the direction of flow for the station.

Figure 9-7. Bi-Directional Control – Programmed Control



Permissive

Either the **Fast Close** or **Close at Low PV** option has to be **Enabled** to use a permissive.

Dir Change Permissive

Choose either:

Enabled

FBxStation Control checks that conditions are valid for the chosen permissive before changing flow direction. Valid conditions are:

Permissive:	Valid Condition:
Fast Close	Zero setpoint entered for primary loop.
Close at Low PV	Zero setpoint entered for primary loop and the PV for the primary loop must be below the value configured for the Close at Low PV option.

Disabled

FBxStation Control can change direction without checking for valid conditions.

No Flow Shutin

Choose either:

- Enabled** When enabled, if there is no flow for this station, FBxStation Control closes the bi-direction block valves for this station. Enabling **No Flow Shutin** also enables the **Close at Low PV** option if it or the **Fast Close** option are not enabled. **Close at Low PV** and **Fast Close** are configured on the Station Control Config – General tab.
- Disabled** A no flow indication does not trigger FBxControl to close bi-direction block valves for this station.

Label Configuration See *Section 9.1*.

Settings

Forward label Direction

Open Sequence BV# Choose the order in which specific block valves should be opened in sequence to establish forward flow for this station. Selecting **1** means block valve 1 (BV#1) opens at this step in the sequence; selecting **2** means block valve 2 (BV#2) opens at this step in the sequence, and so on.

Close Sequence BV# Choose the order in which specific block valves should be closed in sequence to establish forward flow for this station. Selecting **1** means block valve 1 (BV#1) closes at this step in the sequence; selecting **2** means block valve 2 (BV#2) closes at this step in the sequence, and so on.

Operation

Failure Mode Choose one of the following actions to occur during a failure of a valve to reach the demanded state within the specified travel time for the valve.

Revert FBxStation Control attempts to return to the previous state in the event of a failure.

When commanding the station from the forward-to-reverse direction, if a failure occurs, FBxStation Control commands the valves go back to the **Forward** positions.

When commanding the station from the reverse-to-forward direction, if a failure occurs, FBxStation Control commands the valves go back to the **Reverse** positions.

ESD All ESD (Emergency Shut Down) forces the station to shut-in (close all valves) in the event of a failure. When this happens, all valves close simultaneously.

ESD Step ESD Step forces the station to shut-in based on the **Step Mode**. If **Step Mode** is **Time Delay**, valves close one at a time in sequence based on the **Time Delay for Steps** value. If **Step Mode** is **Limit Switches**, valves close one at a time in sequence when the limit switch for the current valve reports closed, or the valve fails.

Pause FBxStation control halts the valve sequence to allow the failed valve indication to be rectified, and then resumes the sequence.

Auto Reset

Only available if the **Failure Mode** is **Pause**. When enabled, attempts to automatically reset an error, as if the reset button was clicked. Specify the maximum number of reset attempts FBxStation Control should make in the box next to the Enabled/Disable selection. If the maximum number of attempts is set to 0, there

is no limit on the number of reset attempts, and reset attempts continue indefinitely.

Step Mode

There are two possible step modes:

Time Delay In this mode, FBxConnect commands the next valve in sequence based on the **Time Delay for Steps** setting.

Limit Switches In this mode, when the Opened or Closed limit switch for the active valve triggers, or if there is a valve failure, the application moves to operate the next valve in sequence.

Time Delay for Steps

Note: This field is not visible if Step Mode is set to Limit Switches.

Specify the amount of time, in seconds, between valve actions. If you set this to 0, FBxConnect commands the next valve in the sequence to operate immediately after the current valve command is done being issued. If it is necessary to wait until one valve is done operating before operating the next valve in the sequence, set **Time Delay for Steps** to a value that is greater than the travel time of the valve.

Auto-Zero Setpoint

When enabled, automatically sets the Station Control setpoint to zero to shut the station in to allow for a direction change. Enabling this also enables the **Dir Change Permissive** and **Close at Low PV** options. **Close at Low PV** is configured on the Station Control Config – General tab.

Reverse label Direction

Open Sequence BV# Choose the order in which specific block valves should be opened in sequence to establish reverse flow for this station. Selecting **1** means block valve 1 (BV#1) opens at this step in the sequence; selecting **2** means block valve 2 (BV#2) opens at this step in the sequence, and so on.

Close Sequence BV# Choose the order in which specific block valves should be closed in sequence to establish reverse flow for this station. Selecting **1** means block valve 1 (BV#1) closes at this step in the sequence; selecting **2** means block valve 2 (BV#2) closes at this step in the sequence, and so on.

BV# Click the tab for the group of four block valves you want to view.

Block Valve *n* Up to 8 block valves (BV) can be configured for each station.

General

Tag Optionally specify a name for the block valve here.

Description Optionally enter a description for the block valve here.

Settings





Valve Control Type Each block valve may be configured for one of three control types. The settings for each block valve may be made independently of the other block valves. The **Valve Control Type** selection may be one of the following:

No Control FBxStation Control has no control of the valve.

Single Maintained Output Choose this option when a single output energizes to change the position of the valve. When this is selected, only configure the Open

	Cmd Object 1, and optionally, the Open Cmd Object 2 items.
Dual Maintained Outputs	Choose this option when there are two outputs, one to open the valve, and the other to close the valve, and these outputs should be maintained, even after the appropriate limit switch indicates that the valve is in the demanded position.
Dual Pulsed Outputs	Choose this option when there are two outputs, one to open the valve, and the other to close the valve, and these outputs should pulse until the appropriate limit switch indicates that the valve is in the demanded position. Use Limit Delay to maintain a pulse for some time after the limit switch triggers.
Valve Travel Time	Specify the amount of time, in seconds, it takes the valve to fully travel from the open-to-close or close-to-open position.
Pulse Duration	Specify the amount of time to pulse the output. This setting only applies when Control Type is Dual Pulsed Outputs .
Limit Delay	Specify the amount of time, in seconds, to maintain the output pulse after an opened or closed limit is indicated. This setting only applies when Control Type is Dual Pulsed Outputs .
Invert	If you check this box, it changes the output to its opposite state when it is transmitted to the valve. An output in the state OFF becomes ON ; an output in the state ON becomes OFF .
Blind Mode	Check this box if there is no limit switch feedback provided by the valve.


I/O

- Open Output Obj** Click the point picker  to choose the open output variable used to command the valve to open.
- Close Output Obj** Click the point picker  to choose the close output variable used to command the valve to close.
- Open Limit SW Pnt** Click the point picker  to choose the input which provides feedback that the valve is open.
- Close Limit SW Pnt** Click the point picker  to choose the input which provides feedback that the valve is closed.


9.3 Single DI

When you choose **Single DI**, FBxStation Control chooses flow direction for this station based on the state of a single digital input.

Figure 9-8. Bi-Directional Flow – Single DI



Settings

- Selected DI** Either use the default, or click the point picker  to choose the single digital input which determines the direction of flow for this station.

- Label Configuration** See *Section 9.1*.

9.4 Limit Switches


When you choose **Limit Switches**, you can configure up to six limit switches to specify the direction of flow for this station. This operates using a voting scheme. A direction change only occurs when a **majority** of the switches call for a change of direction.

Figure 9-9. Bi-Directional Control – Limit Switch

The screenshot shows the 'Station Control Config' window with the 'Bi-Directional Flow' tab selected. Within this tab, the 'Limit Switch' sub-tab is active. The 'Direction Indication Source' is set to 'Limit Switches'. The 'Label Configuration' section has 'Transfer Point A' and 'Transfer Point B' set to 'Undefined' and 'Direction Label' set to 'Forward/Reverse'. The 'Settings' section contains a table with two columns: 'Tag' and 'Forward Direction'. There are six rows for 'Open LS/DI 1' through 'Open LS/DI 6', all currently set to 'Undefined'. To the right of this table are six 'OLS Set State' dropdowns, all currently set to 'Off'. Below the table, 'Force Direction' is set to 'Disable' and 'Set Direction To' is set to 'Forward'. An 'Alarm Delay' is set to '0 s'. A 'Flow Cut-off Config' button is located in the top right corner of the settings area.

Settings

Open LS/DI *n*

Either use the default, or click the point picker  to choose a variable for this limit switch *n*.

OLS State Forward *n*

Select the state which indicates flow should be in the **forward** direction:

- On** If you choose this, it means that this limit switch should be in the **On** state when flow is in the forward direction.
- Off** If you choose this, it means that this limit switch should be in the **Off** state when flow is in the forward direction.

Force Direction

If enabled, no flow direction changes until the states of all limit switches agree. This is unlike a voting system. Until all limit switches agree, the direction remains at that chosen by **Set Direction To**.

Set Direction To

Determines the flow direction when the states of limit switches are not in agreement. Only operates when **Force Direction** is enabled.

Alarm Delay

If **Force Direction** is enabled and the states of all limits switches do not agree, this specifies a time (in seconds) after which an alarm is generated to indicate a discrepancy in the states of limit switches. Set to 0 to disable the alarm.

Label Configuration

See *Section 9.1*.

9.5 Dual Limit Switches


When you choose **Dual Limit Switches**, you can configure up to twelve limit switches to specify the direction of flow for this station; 6 open limit switches and 6 closed limit switches. This operates using a voting scheme. A direction change only occurs when a **majority** of the switches call for a change of direction.

Figure 9-10. Dual Limit Switches

The screenshot shows the 'Station Control Config' window with the 'Bi-Directional Flow' tab selected. The 'Dual LS' sub-tab is active. The 'Direction Indication Source' is set to 'Dual Limit SWs'. The 'Label Configuration' section shows 'Transfer Point A' as 'Undefined', 'Transfer Point B' as 'Undefined', and 'Direction Label' as 'Forward/Reverse'. The 'Settings' section contains three main areas: 'Open LS/DI' (6 switches, all 'Undefined'), 'Forward Direction' (6 states, all 'Off'), and 'Close LS/DI' (6 switches, all 'Undefined'). Each switch/state has a point picker icon (three dots). At the bottom, 'Force Direction' is set to 'Disable' and 'Set Direction To' is set to 'Forward'. An 'Alarm Delay' of 0 seconds is shown.

Settings

Open LS/DI *n*

Either use the default, or click the point picker  to choose a variable for this limit switch *n*.


OLS State Forward *n*

Select the state which indicates flow should be in the **forward** direction:

On If you choose this, it means that this limit switch should be in the **On** state when flow is in the forward direction.

Off If you choose this, it means that this limit switch should be in the **Off** state when flow is in the forward direction.

Close LS/DI *n*

Either use the default, or click the point picker  to choose a variable for this limit switch *n*.

Force Direction

If enabled, no flow direction changes until the states of all limit switches agree. This is unlike a voting system. Until all limit switches agree, the direction remains at that chosen by **Set Direction To**.

Set Direction To	Determines the flow direction when the states of limit switches are not in agreement. Only operates when Force Direction is enabled.
Alarm Delay	If Force Direction is enabled and the states of all limits switches do not agree, this specifies a time (in seconds) after which an alarm is generated to indicate a discrepancy in the states of limit switches. Set to 0 to disable the alarm.
<u>Label Configuration</u>	See <i>Section 9.1</i> .

9.6 Software Switch

When you choose **Software Switch** the flow direction is determined by the state of a software switch. This is a variable either set locally, or by the SCADA system.

Figure 9-11. Bi-Directional Control – Software Switch

The screenshot shows the 'Station Control Config' window with the 'Bi-Directional Flow' tab selected. The 'Method' dropdown is set to 'Software Switch'. The 'Direction Indication Source' section shows 'Direction Indication Method' set to 'Software Switch'. The 'Settings' section shows 'Software Switch' set to 'Forward'. The 'Label Configuration' section shows 'Transfer Point A' and 'Transfer Point B' both set to 'Undefined', and 'Direction Label' set to 'Forward/Reverse'. A 'Flow Cut-off Config' button is visible in the bottom right corner.

Settings

Software Switch

If the state of the software switch is **Forward** (OFF) then flow through the station is in the forward direction.

If the state of the software switch is **Reverse** (ON), then flow through the station is in the reverse direction.

Label Configuration

See *Section 9.1*.

9.7 Frequency (Metrology)

When you choose **Frequency Input**, the flow direction is determined by the value of the frequency provided by the standard firmware functionality in the FB3000 (standard metrology).

If the frequency on a forward run is above the cutoff, the direction is **Forward**.

If the frequency on a reverse run is above the cutoff, the direction is **Reverse**.

If there are multiple runs configured, and there is flow through more than one run, direction is determined by a voting scheme. Whatever the majority of the runs indicates determines the station direction. A tie results in unchanged results from the previous state.

Figure 9-12. Bi-Directional Control - Frequency

The screenshot shows the 'Station Control Config' window with the 'Bi-Directional Flow' tab selected. Within this tab, the 'Frequency' sub-tab is active. The 'Direction Indication Source' section shows 'Direction Indication Method' set to 'Frequency(Metrology)'. The 'Label Configuration' section shows 'Transfer Point A' and 'Transfer Point B' both set to 'Undefined', and 'Direction Label' set to 'Inject/Withdrawal'.

Label Configuration

See *Section 9.1*.

9.8 Bi-Directional Flow Control Examples

The following examples show various scenarios for using bi-directional flow control:

9.8.1 Example 1: 2 Differential Pressure (DP) Meters With a Separate Transmitter for Forward and Reverse DP

Reminder

In FBxStation Control, forward flow stations are always odd-numbered and reverse flow stations are always even-numbered.

In this case, in FBxConnect, you would assign 2 DP meters to the forward station, and 2 DP meters to the reverse station. Each DP meter has its own I/O for DP. All DP meters share the same I/O for static pressure (SP) and flowing temperature (FT).

Figure 9-13. Assigning DP Meter 1 to Station 1 (Forward)

DP Meter

Tag: DP Mtr_1
 Description:
 Serial Number:
 Status: Override

Station Assignment: Station_1
 Fluid Properties Reference: Fluid Prop_1
 Flow Alarm Object: Alarm_1

Meter Type
 Meter Type: AGA3 Orifice (Flange Taps)
 AGA 3 Calculation Selection: AGA 3 2013 Volume

Meter Sizing
 Orifice Diameter: 4.0 in
 Pipe Diameter: 8.0 in

No Flow Cut-off Limit
 0.5 inH2O
 No Flow Status: Not Flowing

Meter Inputs

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Differential Pressure	AI_2-1	Override ▼ -21.0	-21.0	inH2O	Alarms
Flowing Pressure	AI_2-5	Override ▼ 511.0	511.0	psi(g)	Alarms
Flowing Temperature	AI_2-6	Override ▼ 51.0	51.0	°F	Alarms

Corrected Volume Rate Alarm

Limit	Status
High High Alarm Limit 10000.0 MCF/d	Disabled
High Alarm Limit 10000.0 MCF/d	Disabled
Low Alarm Limit 0.0 MCF/d	Disabled
Low Low Alarm Limit 0.0 MCF/d	Disabled
Rate of Change Limit 100.0 MCF/d	Disabled

Last Meter Inspection Time
 1/1/2000 12:00:00 AM

Copy Paste Pause Refresh Save

admin Online FB3000 IP: 10.216.247.5.20000 100% 8:46 AM

Figure 9-14. Assigning DP Meter 2 to Station 1 (Forward)

The screenshot shows the 'DP Meter' configuration window for 'DP Mtr_2'. The 'General' tab is active, displaying the following information:

- Tag:** DP Mtr_2
- Description:**
- Serial Number:**
- Status:** Override
- Station Assignment:** Station_1
- Fluid Properties Reference:** Fluid Prop_2
- Flow Alarm Object:** Alarm_2
- Meter Type:** AGA3 Office (Flange Taps)
- AGA 3 Calculation Selection:** AGA 2013 Volume
- Meter Sizing:** Orifice Diameter: 4.0 in, Pipe Diameter: 8.0 in
- No Flow Cut-off Limit:** 0.5 inH2O, No Flow Status: Not Flowing
- Meter Inputs:**

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Differential Pressure	Override	-22.0	-22.0	inH2O	Alarms
Flowing Pressure	Override	511.0	511.0	psi(g)	Alarms
Flowing Temperature	Override	51.0	51.0	°F	Alarms
- Corrected Volume Rate Alarm:**

Limit	Status
High High Alarm Limit	10000.0 MCF/d Disabled
High Alarm Limit	10000.0 MCF/d Disabled
Low Alarm Limit	0.0 MCF/d Disabled
Low Low Alarm Limit	0.0 MCF/d Disabled
Rate of Change Limit	100.0 MCF/d Disabled
- Last Meter Inspection Time:** 1/1/2000 12:00:00 AM

Buttons at the bottom include 'Copy', 'Paste', 'Pause', 'Refresh', and 'Save'. The status bar at the bottom shows 'admin', 'Online', 'FB3000', 'IP: 10.216.247.5:20000', '100 %', and '8:47 AM'.

Figure 9-15. Assigning DP Meter 3 to Station 2 (Reverse)

The screenshot shows the 'DP Meter' configuration window for 'DP Mtr_3'. The 'General' tab is active, displaying the following information:

- Tag:** DP Mtr_3
- Description:**
- Serial Number:**
- Status:** Override
- Station Assignment:** Station_2
- Fluid Properties Reference:** Fluid Prop_3
- Flow Alarm Object:** Alarm_3
- Meter Type:** AGA3 Office (Flange Taps)
- AGA 3 Calculation Selection:** AGA 2013 Volume
- Meter Sizing:** Orifice Diameter: 4.0 in, Pipe Diameter: 8.0 in
- No Flow Cut-off Limit:** 0.5 inH2O, No Flow Status: Flowing
- Meter Inputs:**

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Differential Pressure	Override	21.0	21.0	inH2O	Alarms
Flowing Pressure	Override	511.0	511.0	psi(g)	Alarms
Flowing Temperature	Override	51.0	51.0	°F	Alarms
- Corrected Volume Rate Alarm:**

Limit	Status
High High Alarm Limit	10000.0 MCF/d Disabled
High Alarm Limit	10000.0 MCF/d Disabled
Low Alarm Limit	0.0 MCF/d Disabled
Low Low Alarm Limit	0.0 MCF/d Disabled
Rate of Change Limit	100.0 MCF/d Disabled
- Last Meter Inspection Time:** 1/1/2000 12:00:00 AM

Buttons at the bottom include 'Copy', 'Paste', 'Pause', 'Refresh', and 'Save'. The status bar at the bottom shows 'admin', 'Online', 'FB3000', 'IP: 10.216.247.5:20000', '100 %', and '8:47 AM'.

Figure 9-16. Assigning DP Meter 4 to Station 2 (Reverse)

DP Meter

General | **Advanced**

Tag: DP Mtr_4
 Description:
 Serial Number:
 Status: Override

Station Assignment: Station_2
 Fluid Properties Reference: Fluid Prop_4
 Flow Alarm Object: Alarm_4

Meter Type
 Meter Type: AGA3 Orifice (Flange Taps)
 AGA 3 Calculation Selection: AGA3 2013 Volume

Meter Sizing
 Orifice Diameter: 4.0 in
 Pipe Diameter: 8.0 in

No Flow Cut-off Limit
 0.5 inH2O
 No Flow Status: Flowing

Meter Inputs

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Differential Pressure	Override	22.0	22.0	inH2O	Alarms
Flowing Pressure	Override	511.0	511.0	psi(g)	Alarms
Flowing Temperature	Override	51.0	51.0	°F	Alarms

Corrected Volume Rate Alarm

Limit	Status
High High Alarm Limit	Disabled
High Alarm Limit	Disabled
Low Alarm Limit	Disabled
Low Low Alarm Limit	Disabled
Rate of Change Limit	Disabled

Last Meter Inspection Time
 1/1/2000 12:00:00 AM

Buttons: Copy, Paste, Pause, Refresh, Save

Status Bar: admin Online FB3000 IP: 10.216.247.5:20000 100% 8:48 AM

The switch from forward flow to reverse flow occurs when the positive DP on DP Meters 1 and 2 switches to negative and the negative DP on DP meters 3 and 4 switches to positive.

On the monitor screen we see which DP meters are in use; if flow is below cut-off, it shows as 0.0 flow.

Figure 9-17. Station 1 Active (Forward Flow)





Figure 9-18. Station 2 Active (Reverse Flow)



9.8.2 Example 2: A Single Linear Turbine Meter with one Frequency Output for Forward/Reverse Flow using a Digital Input to Force a Direction Change

In FBxConnect, we assign Linear Meter 2 to Station 5.

Figure 9-19. Assigning Linear Meter 2 to Station 5

FBxConnect - Murakib FB3000

File Monitor Configure Services Reports Applications FBxVue Help

Home I/O Engr Units I/O Setup Meter Setup Summary Station Station Averages Totals Alarms History Logs PID Loops Action Blocks Math Blocks Effects

Main I/O Measurement Logs Control

Linear Mtr_2 **Linear Meter**

General Advanced

Tag : Linear Mtr_2 Station Assignment : Station_5

Description : Fluid Properties Reference : Fluid Prop_102

Serial Number : Flow Alarm Object : Alarm_102

Status : Override

Meter Type

☒ Turbine

☐ Coriolis

☐ Auto-Adjust

No Flow Option

☐ Time Between Pulses

☒ Flow Cut-off

No Flow Status : Flowing

0.0 Hz

Pipe Diameter

Pipe Diameter : 8.0 in

Meter Inputs

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Indicated Flow	PL2-7	Override	51.0	51.0	Hz
Static Pressure	AI_2-5	Override	511.0	511.0	psi(g)
Flowing Temperature	AI_2-6	Override	51.0	51.0	°F

Corrected Volume Rate Alarm

Limit	Status
High High Alarm Limit	10000.0 MCF/d
High Alarm Limit	10000.0 MCF/d
Low Alarm Limit	0.0 MCF/d
Low Alarm Limit	0.0 MCF/d

Copy Paste Pause Refresh Save

admin Online FB3000 IP: 10.216.247.5.20000 100% 1:22 PM

When measuring reverse flow, the physical meter we called Linear Meter 2 is called Linear Meter 3 and we assign it to Station 6 in FBxConnect. In either direction, it uses the same I/O points.

Figure 9-20. Assigning Linear Meter 3 to Station 6

Linear Meter

General | **Advanced**

Tag : Linear Mtr_3
 Description :
 Serial Number :
 Status : Override

Station Assignment : Station_6
 Fluid Properties Reference : Fluid Prop_103
 Flow Alarm Object : Alarm_103

Meter Type
☒ Turbine
☐ Coriolis
☐ Auto-Adjust

No Flow Option
☐ Time Between Pulses
☒ Flow Cut-off
 999999999.0 Hz

No Flow Status : Not Flowing

Pipe Diameter
 Pipe Diameter : 8.0 in

Meter Inputs

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Indicated Flow	PI_2-7	Override	51.0	51.0	Hz
Static Pressure	AI_2-5	Override	511.0	511.0	psi(g)
Flowing Temperature	AI_2-6	Override	51.0	51.0	°F

Corrected Volume Rate Alarm


Limit	Status
High High Alarm Limit	10000.0 MCF/d Disabled
High Alarm Limit	10000.0 MCF/d Disabled
Low Alarm Limit	0.0 MCF/d Disabled
Low Low Alarm Limit	0.0 MCF/d Disabled

Copy Paste Pause Refresh Save

admin Online FB3000 IP: 10.216.247.5.20000 100 % 1:22 PM


In the FBxStation Control Bidirectional Flow Control Monitor you can see meters shown while in forward flow. FBxStation Control writes to the cutoff parameter. The **DI Status** value (associated with the pulse output) is Off.

Figure 9-21. Station 5 Active (Forward)



When the **DI Status** value changes state to On, the cutoff parameters update and flow switches from forward to reverse.

Figure 9-22. Station 6 Active (Reverse)



9.8.3 Example 3: Two Linear Turbine Meters with One Frequency Output for Forward/Reverse Flow Using a Digital Input to Switch Direction

In FBxConnect, we assign Linear Meters 4 and 5 to Station 7.

Figure 9-23. Assigning Linear Meter 4 to Station 7 (Forward)

Linear Meter

General | **Advanced**

Tag : Linear Mtr_4
 Description :
 Serial Number :
 Status : **Override**

Station Assignment : Station_7
 Fluid Properties Reference : Fluid Prop_104
 Flow Alarm Object : Alarm_104

Meter Type
☒ Turbine
☐ Coriolis
☐ Auto-Adjust

No Flow Option
☐ Time Between Pulses
☒ Flow Cut-off
 No Flow Status : Flowing
 0.0 Hz

Pipe Diameter
 Pipe Diameter : 8.0 in

Meter Inputs

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Indicated Flow	Override	21.0	21.0	Hz	Alarms
Static Pressure	Override	511.0	511.0	psi(g)	Alarms
Flowing Temperature	Override	51.0	51.0	°F	Alarms

Corrected Volume Rate Alarm

Limit	Status
High High Alarm Limit	10000.0 MCF/d Disabled
High Alarm Limit	10000.0 MCF/d Disabled
Low Alarm Limit	0.0 MCF/d Disabled
Low Low Alarm Limit	0.0 MCF/d Disabled

Copy Paste Pause Refresh Save

admin Online FB3000 IP: 10.216.247.5.20000 100 % 2:43 PM

Figure 9-24. Assigning Linear Meter 5 to Station 7 (Forward)

Linear Meter

General **Advanced**

Tag : Linear Mtr_5
 Description :
 Serial Number :
 Status : **Override**

Station Assignment : Station_7
 Fluid Properties Reference : Fluid Prop_105
 Flow Alarm Object : Alarm_105

Meter Type
☒ Turbine
☐ Coriolis
☐ Auto-Adjust

No Flow Option
☐ Time Between Pulses
☒ Flow Cut-off
 No Flow Status : Flowing
 0.0 Hz

Pipe Diameter
 Pipe Diameter : 8.0 in

Meter Inputs

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Indicated Flow	PI_3-2	Override ▼	22.0	Hz	Alarms
Static Pressure	AI_2-5	Override ▼	511.0	psi(g)	Alarms
Flowing Temperature	AI_2-6	Override ▼	51.0	°F	Alarms

Corrected Volume Rate Alarm

Limit	Status
High High Alarm Limit	10000.0 MCF/d Disabled
High Alarm Limit	10000.0 MCF/d Disabled
Low Alarm Limit	0.0 MCF/d Disabled
Low Low Alarm Limit	0.0 MCF/d Disabled

Copy Paste Pause Refresh Save

admin Online FB3000 IP: 10.216.247.5.20000 100% 2:43 PM

When measuring reverse flow, Linear Meter 4 is called Linear Meter 6, and Linear Meter 5 is called Linear Meter 7. Both meters are assigned to Station 8 for reverse flow.

Figure 9-25. Assigning Linear Meter 6 to Station 8 (Reverse)

FBxConnect - Murakib FB3000

File Monitor Configure Services Reports Applications FBxVue Help

Home FIC Eng Units I/O Setup Summary Gas Station Totals Alarms Logs PID Loops Math Blocks
Guided Setup Point Picker Pass Thru Meter Setup Liquid Averages GC History Action Blocks Effects

Main I/O Measurement Logs Control

Linear Mtr_6

Linear Meter

General Advanced

Tag : Linear Mtr_6
Description :
Serial Number :
Status : **Override**

Station Assignment : Station_8
Fluid Properties Reference : Fluid Prop_106
Flow Alarm Object : Alarm_106

Meter Type
☒ Turbine
☐ Coriolis
☐ Auto-Adjust

No Flow Option
☐ Time Between Pulses
☒ Flow Cut-off
 999999999.0 Hz

Pipe Diameter
 Pipe Diameter : 8.0 in

Meter Inputs

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Indicated Flow	PL_3-1	Override	21.0	Hz	Alarms
Static Pressure	AI_2-5	Override	511.0	psi(g)	Alarms
Flowing Temperature	AI_2-6	Override	51.0	°F	Alarms

Corrected Volume Rate Alarm

Limit	Status
High High Alarm Limit	10000.0 MCF/d Disabled
High Alarm Limit	10000.0 MCF/d Disabled
Low Alarm Limit	0.0 MCF/d Disabled
Low Low Alarm Limit	0.0 MCF/d Disabled

Copy Paste Pause Refresh Save

admin Online FB3000 IP: 10.216.247.5.20000 100 % 2:44 PM

Figure 9-26. Assigning Linear Meter 7 to Station 8 (Reverse)

FBxConnect - Murakib FB3000

File Monitor Configure Services Reports Applications FBxVue Help

Home FIC Eng Units I/O Setup Summary Gas Station Totals Alarms Logs PID Loops Math Blocks
Guided Setup Point Picker Pass Thru Meter Setup Liquid Averages GC History Action Blocks Effects

Main I/O Measurement Logs Control

Linear Mtr_7

Linear Meter

General Advanced

Tag : Linear Mtr_7
Description :
Serial Number :
Status : **Override**

Station Assignment : Station_8
Fluid Properties Reference : Fluid Prop_107
Flow Alarm Object : Alarm_107

Meter Type
☒ Turbine
☐ Coriolis
☐ Auto-Adjust

No Flow Option
☐ Time Between Pulses
☒ Flow Cut-off
 999999999.0 Hz

Pipe Diameter
 Pipe Diameter : 8.0 in

Meter Inputs

I/O Definition	Mode	Override Value	Selected Value	Units	Alarms
Indicated Flow	PL_3-2	Override	22.0	Hz	Alarms
Static Pressure	AI_2-5	Override	511.0	psi(g)	Alarms
Flowing Temperature	AI_2-6	Override	51.0	°F	Alarms

Corrected Volume Rate Alarm


Limit	Status
High High Alarm Limit	10000.0 MCF/d Disabled
High Alarm Limit	10000.0 MCF/d Disabled
Low Alarm Limit	0.0 MCF/d Disabled
Low Low Alarm Limit	0.0 MCF/d Disabled

Copy Paste Pause Refresh Save

admin Online FB3000 IP: 10.216.247.5.20000 100 % 2:44 PM


The limit switches used to select the direction are configured on the Limit Switch tab:

Figure 9-27. Configuring Limit Switches to Choose Direction




Meters shown while forward. Station Control is writing to the cutoff parameter.

Figure 9-28. Station 7 Active (Forward)



When the DI changes state the cutoff parameters are updated and flow switches to reverse.

Figure 9-29. Station 8 Active (Reverse)




Chapter 10. Station Control Monitor

To reach Station Control Monitor, select **Station Control Monitor** from the Station Control application menu in FBxConnect.

Tabs on the Station Control Overview screen provide data on the current status of each enabled loop and control valve.


Figure 10-1. Station Control Overview




- 1 Loop in active control for this station. Highlighted in green.
- 2 Loops enabled, but not in active control.
- 3 Loops reporting errors. Highlighted in red.
- 4 Current status of the station.
- 5 Loop quality shows loop(s) reporting errors.
- 6 Shows the name of the loop in active control.
- 7 Click to update the data on the screen.
- 8 Click to save your entries.
- 9 Click the numerical range buttons to choose the meters you want to view onscreen.

The Station Controls and Meter Protection tabs display a control box for only those loops which you have enabled.

You can update the data on the screen by clicking **Refresh**.




A control box outlined in **green** indicates the currently active PID loop. This is the loop that currently provides the lowest control output value to the valve(s).



A control box outlined in **red** indicates that either the data is out-of-range or one or more errors exist.



A control box outlined in gray is enabled but not controlling anything; it tracks the output.



The bar graph in a given control box shows the current value of the process variable in blue. The white triangular pointer shows the local setpoint; the black triangular pointer shows the remote setpoint. When you change either setpoint, the other setpoint tracks it.

PID Status

Shows the status of the loop.

PV

Shows the live value of the process variable controlled by this loop.


Remote SP

Shows the value of the remote entry for the setpoint. A remote entry would be from a SCADA system.

Local SP

Shows the value of the local entry for the setpoint. Local entry would be from an FBxConnect user, such as someone entering a setpoint in the FBxStation Control application.

You can enter the setpoint. Alternatively, you can click on Local SP to bring up controls to set a desired increment by which to increase/decrease the local setpoint, and then use the blue up and down arrows to adjust the setpoint.



Where:

- 1 Increment by which to change the setpoint.
- 2 Click up-arrow to increase the size of the increment.
- 3 Click down arrow to decrease the size of the increment.
- 4 Click to lower setpoint by given increment.
- 5 Click to raise setpoint by given increment.
- 6 Setpoint value.

Control

Access

Access Shows whether the station is under local control (FBxConnect user) or remote control (SCADA system).

Station

Status

Station Status Shows the current status of the station.

Loop Quality Shows any loop currently having errors.

Active Control Shows which loop is currently in control.

Reset ESD If shown as a button, indicates an emergency shut down for the station occurred and a latch is in effect. You must click this button to reset the latch and allow the station control to resume.

Maintenance Bypass

- Enable**
- Only the primary outlet pressure loop operates; all others enter track mode (disabled), and cannot control the pressure loop.
- Disable**
- Any control loop can operate.

Manual Control

- Manual**
- When selected; you have manual control, and can enter a setpoint and ramp rate on this display to control the loop.
- Auto**
- When selected; FBxStation Control automatically chooses which loop(s) control the station.
- Setpoint**
- Enter the manual setpoint for the loop.
- Manual Ramp Rate**
- The rate at which a change in setpoint should be applied to the valve as a percentage of valve travel per second.


Station Demand

- Demand Output**
- Shows the demanded percentage change required for the loop.
- CV Demand Output%**
- Shows the demanded percentage change for each valve.

- CV IO**
- This button opens a read-only screen that shows the variables associated with this control valve.

CV IO						
SC StrCtrl_1 (Station Control_1)						
Name	Open DI	Close DI	Feedback AI	Open DO	Close DO	Output AO
Control Valve_1	DI_2-6.SELECTED	DI_2-7.SELECTED	AI_2-1.SELECTED	Undefined	Undefined	AO_2-1

Figure 10-2. Station Control Overview – Meter Protection tab




These fields, on the Meter Protection overview tab apply specifically to meter protection loops:

Description	A description of the loop.
Status	Reports the status of the loop, and whether it has errors.
PV	The process variable for the loop.
SP	The desired setpoint for the loop.

The Control Valves tab shows currently enabled control valves.

Figure 10-3. Station Control Overview – Control Valves Tab



Station Control Valves

Control Valve

Description

Enter descriptive text for the control valve.

Permissive Point

When enabled, you can assign this valve to a particular tube staged meter run. If the tube staged valve for that meter run is disabled; the control valve will not operate.

Manual Mode

Manual

When selected; you have manual control, and can enter a manual setpoint to control the valve in the FBxStation Control application.

Auto

When selected; FBxStation Control automatically changes the setpoint.

Manual Setpoint

Enter the manual setpoint for the loop.

Source Demand	Shows the desired demand output from the station control logic. Also shown as a horizontal bar graph.
Valve Demand Output	Shows the current % open position of the valve. Also shown as a horizontal bar graph.
Output Ramp Rate	The rate at which a change in setpoint should be applied to the valve as a percentage of valve travel per second.
Raise Command	Used for valves in raise/lower mode. When ON, pulses to open the valve are active.
Lower Command	When ON, pulses to close the valve are active.
<u>Valve Position</u>	
Valve Position	Show the current %open position of the valve.
OLS	Opened limit switch; green indicates the valve is fully opened.
CLS	Closed limit switch; green indicates fully closed.

Chapter 11. Remote Control Valve Config

Valves 1-4
Valves 5-8
Valves 9-12

The Remote Control Valve Config page lets you configure the remote control valves.

To reach the Remote Control Valve Config screen, select **Remote Control Valve Config** from the Station Control application menu in FBxConnect.

The screen displays four valves at one time; select a group of four valves to configure from the column at left.

On any screen, you can update the data on the screen by clicking **Refresh** and save your edits by clicking **Save**.

Figure 11-1. Remote Control Valve Config Screen

The screenshot displays the 'Remote Control Valve Config' window within the FBxConnect application. The interface is organized into four main panels, one for each valve (RCV_1 through RCV_4). Each panel contains the following configuration options:

- Valve Settings:** Includes a 'Valve Type' dropdown set to 'No Control', and input fields for 'Pulse Duration' (0 s), 'Travel Time' (0 s), and 'LS Travel Time' (0 s).
- Control Mode:** Features 'Local' and 'Remote' dropdown menus, both currently set to 'Arm and Execute'.
- I/O:** A section for configuring digital inputs and outputs, including 'Close Cmd Obj 1', 'Close Cmd Obj 2', 'Open Cmd Obj 1', 'Open Cmd Obj 2', 'Close LS DI Input', and 'Open LS DI Input'. Each item has a dropdown menu and a three-dot menu icon.
- Isolation Input Point:** Includes an 'Isolation Input Point' dropdown menu set to 'Disabled'.
- Line Break Point:** Includes a 'LineBreak Point' dropdown menu set to 'Disabled'.

At the bottom of the window, there are 'Refresh' and 'Save' buttons. The status bar at the very bottom shows the user 'admin', the system status 'Online', the station name 'FB3000', the IP address 'IP: 10.216.247.5.20000', a zoom level of '100 %', and the time '8:58 AM'.

RCVn

The remote control valve number.

Tag

A name used to identify the valve.

Valve Settings

Valve Type

There are four types of valves:

No Control Automatic control of the valve is disabled.

Single Maintained Choose this option when a single output energizes to change the position of the valve. When this is selected, only configure the Open Cmd Object 1, and optionally, the Open Cmd Object 2 items.

Dual Maintained Choose this option when there are two analog outputs, one to open the valve, and the other to close the valve. These outputs should be maintained, even after the appropriate limit switch indicates that the valve is in the demanded position.

Dual Pulsed Choose this option when there are two digital outputs, one to open the valve, and the other to close the valve. These outputs should be pulsed until the appropriate limit switch indicates that the valve is in the demanded position. You can use the **Limit Delay** setting to maintain a pulse for some time after the valve position triggers the limit switch.

Pulse Duration

The amount of time (in seconds) to pulse the output. This setting only applies when Valve Type is **Dual Pulsed**.

Travel Time

Specifies the amount of time, in seconds, the valve should take to fully travel from the open-to-close or close-to open position. This entry may be changed from this screen.







LS Travel Time

Specifies a delay to wait for the valve limit switch to change after a pulse to control the valve occurs.

Control Mode

Valve control operates either in **Execute Only** mode or **Arm and Execute**.

In **Arm and Execute** when **Arm** is turned ON, Station Control starts a 10-second timer during which time the **Execute** must turn ON or it will not move the valve. If **Execute** is turned on after the 10-second timer expires, Station Control ignores it and no valve movement occurs.

	Use this mode for extra safety to force you to confirm you really want to move the valve.
	In Execute Only mode, Station Control starts to move the valve as soon as Execute is turned ON. There is no confirmation required.
Local	Select the control mode to use when the station is under local control (FBxConnect user such as Station Control).
Remote	Select the control mode to use when the station is under remote control (SCADA system).
Close Cmd Obj 1	Click the point picker button  to specify the digital output used to command the valve to close.
Close Cmd Obj 2	If the valve close command requires a second digital output in order to confirm that the valve should close, operate, click the point picker button  to specify the second digital output. Typically, this is a safety measure used with large valves.
Open Cmd Obj 1	Click the point picker button  to specify the digital output used to command the valve to open.
Open Cmd Obj 2	If the valve close command requires a second digital output in order to confirm that the valve should open, operate, click the point picker button  to specify the second digital output. Typically, this is a safety measure used for large valves.
Close LS DI Input	Click the point picker button  to specify the digital input that serves a closed limit switch to report the valve fully closed.
Open LS DI Input	Click the point picker button  to specify the digital input that serves an open limit switch to report the valve fully open.
Blind Mode	Select this to ignore limit switch status from the valve.
Position Feedback	Select this to use position feedback from the valve – such as limit switch status.
Invert	Select this to invert outputs. When selected, a valve open command is OFF and a valve close command is ON.

Isolation

Used if you want to isolate the valves.

Input Point

Isolation Point

If the point specified becomes TRUE, the valve closes. If the point becomes FALSE, the valve opens.

When the point says **Disabled**, this does nothing.

When the point specifies a **Station**, Station Control checks if the station is in an emergency shut down (ESD) state. If it is, **Isolation Point** becomes TRUE and the valve shuts. This can also occur if bi-directional control for the station changes direction.

When the point specifies an external input **Ext Input**, and the external input becomes TRUE the valve shuts.

Line Break Point

A line break refers to the pipeline breaking open.

Linebreak Point If the point specified becomes TRUE, the valve closes. If the point becomes FALSE, the valve remains closed, and you must open it manually.

When the point says **Disabled**, this does nothing.

When the point specifies a **Station**, Station Control checks if the station is in an emergency shut down (ESD) state. If it is, **Linebreak Point** becomes TRUE and the valve shuts. This can also occur if bi-directional control for the station changes direction.

When the point specifies an external input **Ext Input**, and the external input becomes TRUE the valve shuts.

Chapter 12. Remote Control Valve Monitor

- Valves 1-4
- Valves 5-8
- Valves 9-12


The Remote Control Valve Monitor page lets you see the current state of the remote control valve, and lets you issue commands to open or close the valves.

To reach the Remote Control Valve Monitor, select **Remote Control Valve Monitor** from the Station Control application menu in FBxConnect.

The screen displays four valves at one time; select a group of four valves to configure from the column at left.

You can update the data on the screen by clicking **Refresh**.

Figure 12-1. Remote Control Valve Monitor



RCVn	The remote control valve number
Tag	Shows a description of the valve.
L/R Access	Shows whether the valve is configured for both local and remote control, or if it is configured for local control only.

Status

Valve Status

The overall status of the valve.

Valve Demand

The requested position for the valve. Shows **Idle** if there is no pending open/close command.

Valve Position

The current position of the valve. Shows **Travel** if the valve is somewhere in-between opened and closed.

Open Status

The status of the open limit switch. Shows **Fail** if the valve limit switch is not open by the end of the valve travel time. Shows **Normal** if the limit switch indicates the valve is in the demanded position.

Close Status

The status of the closed limit switch. Shows **Fail** if the valve limit switch is not closed by the end of the valve travel time. Shows **Normal** if the limit switch indicates the valve is in the demanded position.

Reset

Clear all errors shown for the valve.

Deenergize

Turns off all outputs.

Local Control

Open Valve

Shows buttons for local control of opening the valve.

Arm

Click to start a 10-second timer within which you must click **Execute** to open the valve. If you do not click **Execute** before expiration of the timer, the valve does not open. If shown grayed out, the valve is configured for Execute Only; no timer applies.

Execute

Click to open the valve.

Close Valve

Shows buttons for local control of closing the valve.

Arm

Click to start a 10-second timer within which you must click Execute to close the valve. If you do not click Execute before expiration of the timer, the valve does not close. If shown grayed out, the valve is configured for Execute Only; no timer applies.

Execute

Click to close the valve.

Remote Control


This section is only available if you set the Site Settings page to make this configurable, and if remote control is allowed.

<u>Open State</u>	Shows status of remote control actions for opening the valve.
Arm	Shows if Arm timer has started.
Execute	Shows if Execute in progress.
<u>Close State</u>	Shows status of remote control actions for closing the valve.
Arm	Shows if Arm Timer has started.
Execute	Shows if Execute in progress.
<u>Alternate Source Control</u>	
Isolation Input Trip Status	Shows On if the isolation input is TRUE.
Line Break Trip Status	Shows On if the line break status is TRUE.
IO	This button brings up a read-only pop-up screen which shows the variable associated with the valve (Tag,) and the current status Value of the valve.

Figure 12-2. RCV IO Pop-up

RCV IO ✕						
SC RCV_1 (RCV_1) ▼						
	Open DI	Close DI	Open DO1	Open DO2	Close DO1	Close DO2
TAG:	DI_2-8.SELECTED	DI_2-7.SELECTED	DO_2-2	DO_3-2	DO_2-1	DO_3-1
VALUE:	OFF	OFF	OFF	OFF	OFF	OFF

Chapter 13. Run Staging Configuration



After you finish your selections on the Station Control Config and Run Mapping screens, and assign your switches to particular stations and valves, you can configure meter run staging. Meter run staging is sometimes referred to as run switching or tube switching.

To reach the Run Staging Configuration screen, select **Run Staging** from the FBxStation Control application menu in FBxConnect.

Run staging requires at least two meter runs for a station, and each run on a given station must have a different assigned rank.

On any screen, you can update the data on the screen by clicking **Refresh** and save your edits by clicking **Save**.

Figure 13-1. Run Staging Configuration

The screenshot displays the 'Run Staging Configuration' window. At the top, there's a menu bar with options like File, Monitor, Configure, Services, Reports, Applications, FBxVue, and Help. Below the menu, there's a toolbar with icons for Management, Information, Main, and Applications. The main content area is titled 'Run Staging Configuration' and includes several sections:

- Enable Staging:** Radio buttons for 'Enable' and 'Disable' (selected).
- Initialization:** 'Staging Status' is 'Disabled'. 'Initial Rank' is set to 1. An 'Initialize' button is present.
- Station Settings:** A checkbox for 'Check flow to switch tubes' is unchecked. 'Settle Time' is 5 s. 'Tube Fail Mode' is 'Fail Close'. 'PV Selection' is 'User PV'. A 'User PV' button is available.
- Rank Values:** 'Maximum Rank' is 4, 'Current Rank' is 4, and 'Requested Rank' is 4.
- No Flow Shutin:** 'Station Flow Rate' is 41388.78 MCF/d. A checkbox for 'Enable No Flow Shutin' is unchecked.

Below these settings are four columns, each representing a tube (Tube 1 to Tube 4). Each column contains:

- Tube Settings:** 'Tube ID', 'Meter Tab', 'Tube Status' (Disabled), 'PV Value', 'Valid Flow Limit', and 'Target Rank'.
- Switch Settings:** 'Call Next SetPoint', 'Next Deadband', 'Call Prev. SetPoint', 'Prev. Deadband', a checkbox for 'Shutin Tube When Rank Exceeded', and a checkbox for 'Disable Next / Prev Config Check'.
- Auto / Manual Mode:** Radio buttons for 'Auto' and 'Manual'.
- Command / Status:** 'Called To' (CLOSE or OPEN) and 'Status' (OK).
- Buttons:** 'Close Valve', 'Open Valve', and 'Reset / Clear'.

At the bottom right, there are 'Refresh' and 'Save' buttons. The bottom status bar shows 'admin', 'Online', 'FB3000', 'IP: 10.216.247.49.20000', '100 %', and '8:00 AM'.

Enable Staging

Enable Enables run staging for this station. **Note:** You must initialize run staging before you enable it.

Disable Disables run staging for this station.

Initialization

Staging Status Shows the status of the meter run staging process.

Initial Rank This is the rank the station will demand when you click the **Initialize** button.

Initialize Click this button to initialize run staging based on the initial rank setting.

Station Settings

Check flow to switch tubes When selected, as each meter run is commanded to open, FBxStation Control compares the current flow rate for the meter run to the **Valid Flow Limit** set for that tube in the Tube Settings tab. If the flow rate does not exceed the Valid Flow Limit value, the meter run/tube is considered to have failed, and FBxStation Control (if in automatic mode) opens the next highest ranked tube.

Settle Time When opening or closing a run, the flow rate through the runs may momentarily increase or decrease above or below the setpoints for opening or closing additional runs. **Settle Time** is a period of seconds during which no control actions will occur.

Tube Fail Mode Select either **Fail Open** or **Fail Close**. It is important to understand the advantages and disadvantages of each mode. Tube Fail Mode only applies when FBxStation Control detects a Q-bit or measurement error, and only on the highest-ranking tube. FBxStation Control shuts any lower ranked tube which fails. Depending on the purpose of the station, a different fail mode may be appropriate. In cases where keeping gas flowing outweighs other concerns, you may want to choose **Fail Open**. A possible example of this is when the station feeds a power station or compressor station. In other cases, in which the delivery is not as critical, you may choose for safety concerns to let the tube shut. Ultimately, you must carefully consider the decision of whether to fail open or fail closed on a site-by-site basis.

PV Selection

Choose one of the following:

- DP/Flowrate** Uses differential pressure (DP) for an orifice meter and flow rate for a linear meter.
- FR/Velocity** Uses flow rate for an orifice meter and velocity for linear meters. When you choose this, a **Pipe Diameter** button becomes visible, and you can enter the pipe diameter.
- DP/Velocity** Uses differential pressure (DP) for orifice meters and velocity for a linear meter. When you choose this, a **Pipe Diameter** button becomes visible, and you can enter the pipe diameter.
- Flowrate** Uses flow rate for both differential pressure (DP) meters and linear meters.
- User PV** When selected, a **User PV** button becomes visible which you can click to launch a pop-up display to specify the process variable (PV) to use for run staging/tube staging.

Pipe Diameter

Pipe Diameter

This button is only visible when **PV Selection** is **FR/Velocity** or **DP/Velocity**. When you click **Pipe Diameter**, it opens the Pipe Diameter pop-up screen where you can specify the pipe diameter for the meters.

Pipe Diameter for Velocity

SC TubeStg_6 (RunStaging_6)

Meter	Description	Pipe Diameter
Linear Mtr_5	lin5	8.0
Linear Mtr_6	lin6	8.0
Linear Mtr_7	lin7	8.0
Linear Mtr_8	lin8	8.0

Refresh

Save

Cancel


Enter the **Pipe Diameter** for your meter. You can click **Refresh** to update the screen. Click **Save** when you finish to save your entries and close the pop-up.

Note

The engineering units (EU) used for the pipe diameter are set at the station level in the standard measurement firmware.





User PV



This button is only visible when **PV Selection** is **User PV**. When you click **User PV**, it opens the User PV pop-up screen from which you can select the process variable to use for your tube staging. For each **Meter** shown, you can click the point-picker button  in the **User PV** field to select the process variable to use for tube staging for this meter. Click **Save** when you finish to save your selections and close the pop-up.

User PV Selection

SC TubeStg_1 (RunStaging_1)

Meter	Description	User PV
DP Mtr_1		User Data_1.FLOAT_1 
DP Mtr_2		User Data_1.FLOAT_1 
Linear Mtr_1		User Data_1.FLOAT_1 
Linear Mtr_2		User Data_1.FLOAT_1 

Refresh

Save

Cancel

Rank Values

Rank refers to the order in which a run is opened or closed, as flow varies through the station. The run ranked 1 will open first, to meet any demand for flow. The runs ranked 2 and higher will open as the flow through the station increases and more runs are required.

You assign ranks on the Run Mapping screen.

Maximum Rank

The highest possible ranked meter run (tube) that can be opened for this station. This is equivalent to the number of runs assigned to the station, so if a station has 4 meter runs assigned to it, the maximum rank is 4.

Current Rank

The highest ranked tube (meter run) currently open.

Requested Rank This is the highest ranked tube (meter run) which should be opened to meet the current requested demand. Because the valves for a tube open sequentially by rank, the requested rank might not be the same as the current rank.

No Flow Shutin

Station Flow Rate The current flow rate for the selected station.

Enable No Flow Shutin If enabled, and the station flow rate is 0, all meter runs/tubes for this station are commanded to close.

13.1 Tube Settings tab

Tube *n*

Tube ID A name assigned to the tube.

Tube Status Reports the current status of the tube:

Config Fail Invalid configuration for tube switching. This occurs when the run's low switch point is higher than the previous run's high switch point.

Disabled Tube switching configuration and data are valid, but meter run staging is disabled.

Maint Mode The corresponding meter run is in maintenance mode and meter run staging is disabled.

Normal Tube switching configuration and data are valid, but meter run staging is disabled.

PV Fail The process variable's questionable data bit (Q-Bit) is TRUE.

Q-Bit Fail The flow rate calculated for the station is questionable.

Shutdown The run is closed due to a shutdown command.

PV Value The current value for the process variable associated with the tube. Depending on the configuration, this could be DP, flow rate, or velocity.

Valid Flow Limit If the **Check Flow to Switch Tubes** feature is selected in the Station Settings section of the Run Staging Configuration

screen, the process variable must exceed this limit for flow to be validated. In practical terms, when a run is requested to open, the actual rank will not be updated until the flow validation number is exceeded. If it fails to be exceeded prior to the end of the travel time, the run is marked as failed and the next higher-ranked run is requested.

Target Rank

The rank configured for this run. When the requested rank matches the target rank, the run of that target rank opens. When the run opens, the current rank should match the target rank.

Switch Settings

Call Next Setpoint

The next setpoint is in the same units as the process variable and used to determine whether or not to increment the **Requested Rank** to thereby open an additional tube/meter run.

Next Deadband

The process variable must exceed the value of **Call Next Setpoint** for the number of seconds in **Next Deadband** before FBxStation Control changes the **Requested Rank**.

Call Prev. Setpoint

Call Prev Setpoint is in the same units as the process variable and used to determine whether or not to decrement the **Requested Rank**.

Prev. Deadband

The process variable must be less than the value of **Call Prev Setpoint** for the number of seconds in the **Prev DeadBand** field before FBxStation Control changes the **Requested Rank**.

Shutin Tube When Rank Exceeded

In automatic mode, if **Shutin Tube When Rank Exceeded** is selected, when the **Requested Rank** exceeds the rank for this tube, FBxStation Control shuts the tube.

Disable Next / Prev Config Check

Checks next and previous configuration settings. You disable this if you have a mixture of different types of tubes with different configurations.

Auto / Manual Mode

Auto

When in auto mode, the **Called To** setting is determined by the tube switching logic.

Manual

When in manual mode, you can change the **Called To** setting yourself from this page.

Command/Status

Called To

This is the command to the tube. When the tube is in Auto mode, tube switching logic determines how to set this command.

When the tube is in Manual mode, you can set this command yourself on the Valve tab.

Status

Shows the status summary of the tube. Will show **Fail** for a Config Fail, PV Fail, or Q-Bit Fail.

Open Valve, Close Valve

When the tube is in Manual mode, you can click either of these buttons to send a command to the valve.


Reset / Clear

If an error occurs in the meter run staging sequence that causes a meter run (or runs) to improperly open or shut, you must reset the staging sequence as follows:

1. Determine the root cause of the error then correct the condition. Typical causes might include invalid DP or counts measurements, or incorrect settings for “next” or “previous.”
2. Disable meter run staging.
3. Click **Reset/Clear**.
4. Re-initialize meter run staging.
5. Re-enable meter run staging.

13.2 Valve Settings Tab

Figure 13-2. Valve Settings Tab



Block Valve *n*

Tube ID A name assigned to the tube associated with this block valve.

Valve Control Type

Valve Control Type	No Control	Automatic control of the valve is disabled.
	Single Maintained	Choose this option when a single output energizes to change the position of the valve. When this is selected, only configure the Open Cmd Object 1, and optionally, the Open Cmd Object 2 items.
	Dual Maintained	Choose this option when there are two analog outputs, one to open the valve, and the other to close the valve. These outputs should be maintained, even after the appropriate limit switch indicates that the valve is in the demanded position.
	Dual Pulsed	Choose this option when there are two digital outputs, one to

open the valve, and the other to close the valve. These outputs should be pulsed until the appropriate limit switch indicates that the valve is in the demanded position. You can use the **Limit Delay** setting to maintain a pulse for some time after the valve position triggers the limit switch.

Valve Settings

Valve Travel Time

Specifies the amount of time, in seconds, the valve should take to fully travel from the open-to-close or close-to-open position. This entry may be changed from this screen. We recommend you add a few seconds to the manufacturer's specified valve travel time to account for feedback from limit switches to confirm the valve's position.

Pulse Duration

The amount of time (in seconds) to pulse the output. This setting only applies when Valve Control Type is **Dual Pulsed**.

Limit Delay

The **Limit Delay** is the amount of time, in seconds, that the output pulse will be maintained after an opened or closed limit is indicated. This only applies for the **Valve Control Type** of **Dual Pulsed**.

Blind Mode

When selected, FBxStation Control does not use limit switch feedback to determine whether to pulse the valve.

Invert


This setting changes the operation of the digital output. When this box is checked:

An **OPEN** command sets the digital output assigned to the open command to OFF (or FALSE). If dual outputs are used, FBxStation Control sets the digital output assigned to the Close command to ON (or TRUE).


A **CLOSE** command sets the digital output assigned to the open command to ON (or TRUE). If dual outputs are used, FBxStation Control sets the digital output command" to OFF (or FALSE).











I/O

Close Output Obj

Click the point picker button  to specify the digital output used to command the valve to close.

Open Output Obj

Click the point picker button  to specify the digital output used to command the valve to open.

Close Limit SW Pnt	Click the point picker button  to specify the digital input that serves a closed limit switch to report the valve fully closed.
Open Limit SW Pnt	Click the point picker button  to specify the digital input that serves an open limit switch to report the valve fully opened.
<u>Position</u>	
Valve Called To	This is the command to the valve. When the tube is in Auto mode, tube switching logic determines how to set this command.
Open Valve, Close Valve	When the tube is in Manual mode, you can click either of these buttons to send a command to the valve.
Close LS	Close limit switch status indicated by color: <div><div></div> Gray - Close limit switch OFF</div> <div><div></div> Yellow - Valve traveling</div> <div><div></div> Red - Close limit switch ON – Valve is closed</div> <div><div></div> Error - Unknown state</div>
Open LS	Open limit switch status indicated by color: <div><div></div> Gray - Open limit switch OFF</div> <div><div></div> Yellow - Valve traveling</div> <div><div></div> Red - Open limit switch ON – Valve is opened</div> <div><div></div> Error - Unknown state</div>

Chapter 14. Run Staging Monitor

To reach the Run Staging Monitor screen, select **Run Staging Monitor** from the Station Control application menu in FBxConnect.

Figure 14-1. Run Staging Monitor

Graphic Symbol



Explanation

Meter run and valve shut.

Meter run and valve open.

The PV value has not exceeded the Valid Flow Limit for the configured duration when the meter is called to Open, or the PV value has not dropped below the Valid Flow Limit when the meter is called to Close.

Enable Staging

Enable

Enables run staging for this station. **Note:** You must initialize run staging before you enable it.

Disable

Disables run staging for this station.

Initialization

Staging Status

Shows the status of the meter run staging process. Possible values are:

	Normal	The run staging feature is operating normally.
	Disabled	The run staging feature is not active.
	Initializing	The software is setting up the tubes for run staging.
	Ready to Enable	Click Enable to enable run staging.
	Shutdown ESD	The station is in an emergency shut down (all valves closed).
	Shutdown DirChg	The station is shut down while a flow direction change is about to start.
Initial Rank	This is the rank the station will demand when you click the Initialize button.	
Initialize	Click this button to initialize run staging based on your entries in the Run Staging Configuration screen.	
<u>Rank Values</u>	Rank refers to the order in which a run is opened or closed, as flow varies through the station. The run ranked 1 will open first, to meet any demand for flow. The runs ranked 2 and higher will open as the flow through the station increases and more runs are required. You assign ranks on the Run Mapping screen.	
Maximum Rank	The highest possible ranked meter run (tube) that can be opened for this station. This is equivalent to the number of runs assigned to the station, so if a station has 4 meter runs assigned to it, the maximum rank is 4.	
Current Rank	The highest ranked tube (meter run) currently open.	
Requested Rank	This is the highest ranked tube (meter run) which should be opened to meet the current requested demand. Because the valves for a tube open sequentially by rank, the requested rank might not be the same as the current rank.	


Station Info

Station Flow Rate

The current flow rate for the selected station.

Tube Control

Tube Select



The Tube select buttons are only visible if there are more than 4 tubes in the application. You can use them to move through the tubes in the application. If a particular option is not possible, that button disappears.

Tubes 1-4

Jump to show the first four tubes.

Prev Tube

Scroll to show the previous tube.

Next Tube

Scroll to show the next tube.

Last 4 Tubes

Jump to show the last four tubes.

Tube *n*

Tube ID

A name assigned to the tube.

Tube Status

Reports the current status of the tube:

Config Fail

Invalid configuration for tube switching. This occurs when the run's low switch point is higher than the previous run's high switch point.

Disabled

Tube switching configuration and data are valid, but meter run staging is disabled.

Maint Mode

The corresponding meter run is in maintenance mode and meter run staging is disabled.

Normal

Tube switching configuration and data are valid, but meter run staging is disabled.




PV Fail

The process variable's questionable data bit (Q-Bit) is TRUE.

Q-Bit Fail

The flow rate calculated for the station is questionable.

	Shutdown	The run is closed due to a shutdown command.
Target Rank		The rank configured for this run. When the requested rank matches the target rank, the run of that target rank opens. When the run opens, the current rank should match the target rank.
PV Value		The current value for the process variable associated with the tube. Depending on the configuration, this could be DP, flow rate, or velocity.
Valid Flow Limit		If the Check Flow to Switch Tubes feature is selected in the Station Settings section of the Run Staging Configuration screen, the process variable must exceed this limit for flow to be validated. In practical terms, when a run is requested to open, the actual rank will not be updated until the flow validation number is exceeded. If it fails to be exceeded prior to the end of the travel time, the run is marked as failed and the next higher-ranked run is requested.
Call Next Setpoint		The next setpoint is in the same units as the process variable and used to determine whether or not to increment the Requested Rank to thereby open an additional tube/meter run.
Next Deadband		The process variable must exceed the value of Call Next Setpoint for the number of seconds in Next Deadband before FBxStation Control changes the Requested Rank .
Call Prev. Setpoint		Call Prev Setpoint is in the same units as the process variable and used to determine whether or not to decrement the Requested Rank .
Prev. Deadband		The process variable must be less than the value of Call Prev Setpoint for the number of seconds in the Prev DeadBand field before FBxStation Control changes the Requested Rank .
A/M		Click this button to move the tube into the opposite state; auto to manual or manual to auto. The current state of the tube is shown to the right of the button: Auto When in auto mode, the Called To setting is determined by the tube switching logic.

	Manual	When in manual mode, you can change the Called To setting yourself from this page
Called To		This is the command to the tube. When the tube is in Auto mode, tube switching logic determines how to set this command.
		When the tube is in Manual mode, you can set this command yourself on the Valve tab.
Tube Fail		Shows whether the tube has failed. If there is no failure, shows "OK."
Block Valve n OLS CLS		Shows the state of the open limit switch (OLS) and close limit switch (CLS). Possible states are:
		Red with white "X" – This limit switch is energized.
		Gray – This limit switch is not energized.
		Yellow – The valve is traveling.
Reset		<p>If an error occurs in the meter run staging sequence that causes a meter run (or runs) to improperly open or shut, you must reset the staging sequence as follows:</p> <ol style="list-style-type: none"> 1. Determine the root cause of the error then correct the condition. Typical causes might include invalid DP or counts measurements, or incorrect settings for "next" or "previous." 1. Disable meter run staging. 2. Click Reset. 3. Re-initialize meter run staging. 4. Re-enable meter run staging.

Chapter 15. Bi-Directional Flow Control Monitor


Tabs on the Bi-Directional Flow Control Monitor provide data on the current status of each station configured for bi-directional flow control.

To reach the Bi-Directional Flow Control Monitor screen, select **Bi-Directional Control Monitor** from the Station Control application menu in FBxConnect.

Once you select a station, the tab appropriate for the direction indication method for that station opens and populates with the most recent data from the station. You can update the data on the tab by clicking **Refresh**.

On each tab, the **Current Rates & Totals** section shows the direction of flow.

Figure 15-1. Flow Direction depicted in Current Rates & Totals




- 1 The **Transfer Point A** field on the corresponding configuration display determines the text shown in the left of the graphic.
- 2 The **Transfer Point B** field on the corresponding configuration display determines the text shown in the right of the graphic.
- 3 Arrow and text show direction of flow.
- 4 The station currently in control of flow is highlighted in **green**.

The sections that follow cover each tab in the Bi-Directional Flow Control Monitor.

15.1 DP (Metrology)

If you chose **DP (Metrology)** to determine flow direction, you can view the following:

Figure 15-2. Bi-Directional Control - DP



Current Direction Indication

Shows **Forward** for forward flow or **Reverse** for reverse flow.

DP Meter Status

The status can be one of the following:

- OK** Forward/Reverse meters configured correctly.
- Number DP Meters Unequal** The number of meters for forward and reverse stations do not match.

Forward Meters/Reverse Meters

Shows the name of the meter.

Low Cutoff

Shows the low flow cutoff limit for this meter.

DP in Use

Shows the current differential pressure value for this meter.

Current Rates & Totals

Stn No.	Shows the station number.
Stn Tagname	Shows the name for the station.
Flow Rate	Shows the current flow rate for the station.
Volume Today	Shows the calculated flow volume for the day for this station.

15.2 Programmed Control

If you chose **Programmed Control** to determine flow direction, you can view the following:

Figure 15-3. Bi-Directional Control – Programmed Control

The screenshot displays the 'Bidirectional Flow Control Monitor' interface. At the top, it shows 'SC StrCtrl_1 (Station Control_1)' and 'Program Control' as the selected method. Below this, there are tabs for 'Method', 'DP', 'Program Control', 'Single_DI', 'Limit Switch / DI', 'BV / Dual LS', 'Software Switch', and 'Frequency'. The 'Program Control' tab is active, showing 'Enable / Disable Program Control' with 'Direction Control' selected. To the right, 'Local Control' and 'Remote Control' are both set to 'Disable'. Further right, 'Direction Control Status' shows 'Program Status' as 'Idle' with 'Reset' and 'Auto Reset' buttons. Below this, 'Failure Status' is 'Clear' and 'Direction Indication' is 'Inject'. On the left, 'Block Valve Status' shows a table with 4 valves, all with 'Demand' set to 'CLOSE' or 'OPEN'. On the right, 'Current Rates & Totals' shows a diagram of two stations (Station 1 and Station 2) with flow direction 'Inject' and a table of current rates and totals.

Stn No.	Station Tag	Flow Rate	Volume Today
1	Station_1	506.69 MCF/h	791.836 MCF
2	Station_2	0.0 MCF/d	499.207 MCF

Enable / Disable Program Control

Direction Control When Program Control is disabled, the Block Valve Demand indicators change to buttons, allowing manual control of each valve. Choose either:

- Enabled** Click **Enabled** to enable program control to choose flow direction.
- Disabled** Click **Disabled** to disable program control over flow direction.

Local Control

Local Control

Shows either:

- Enable** You can change the flow direction from this screen.
- Disable** You cannot change the flow direction from this screen.

Local Request

Click **Forward** (or **Delivery** or **Inject**) to request forward flow or **Reverse** (or **Receipt** or **Withdrawal**) to request reverse flow.

Remote Control

Remote Control

Shows either:

- Enable** Indicates that a remote SCADA system can change the flow direction.
- Disable** Indicates that a remote SCADA system **cannot** change the flow direction.

Remote Request

Shows the most recent direction request from the SCADA system:

- Forward** Indicates that the SCADA system's last request was for forward flow.
- Reverse** Indicates that the SCADA system's last request was for reverse flow.

Direction Control Status

Program Status

Possible status values are:

- Active** Currently switching direction.
- Disabled** Programmed control not enabled.
- External ESD** External ESD (emergency shut down) from Station Control input.
- Fail ESD All** ESD (emergency shut down) fail mode. All valves shut.
- Fail ESD Step** ESD (emergency shut down) fail mode. Proceeding in step mode.


Failing	One or more valves not in correct position.
Fail-Paused	Pause fail mode complete.
FailReset-Paused	Maximum number of reset attempts reached. Auto-Reset is paused.
Fail-Resetting	Auto-Reset currently in progress.
Fail-Rvrted	Revert fail mode complete.
Idle	Waiting for direction change.
Reverting	Revert fail mode active.
Startup	Programmed control initially enabled.

Auto Reset

Note: Auto-Reset is only visible if it has been enabled on the Station Control Config Programmed Control tab.



Auto Reset shows green if an auto reset is in progress.



Auto Reset shows red if the maximum number of reset attempts has been reached.

Failure Status

Shows the Valve number and Step number which caused the failure, for example: **Valve1, Step1**

Reset

If a failure occurs, no further action occurs until you click the **Reset** button.

Direction Indication

Shows the current flow direction.

Direction Request

Shows the current demanded direction.

Block Valve Status

BV#

Shows the block valve number.

Tagname

Shows the block valve name.

Demand	Shows the currently demanded position for the block valve. When Program Control is enabled, the demand indicators display the currently demanded position of each valve. When control is disabled, the indicators change to buttons to allow manual control of each valve, and the button text indicates the valve command when activated.
---------------	--

CLS / OLS	Shows the current state of the OLS (open limit switch) and CLS (closed limit switch). Possible states are:
------------------	--



Red with white "X" – This limit switch is energized (ON).



Gray – This limit switch is not energized (OFF).



Yellow – Valve is traveling.


Current Rates & Totals

Stn No.	Shows the station number.
Stn Tagname	Shows the name for the station.
Flow Rate	Shows the current flow rate for the station.
Volume Today	Shows the calculated flow volume for the day for this station.

15.3 Single DI

If you chose **Single DI** to determine flow direction, you can view the following:

Figure 15-4. Bi-Directional Flow – Single DI



DI Status

DI Value Shows the current state of the digital input that chooses the flow direction.

Current Rates & Totals

Stn No. Shows the station number.

Stn Tagname Shows the name for the station.


Flow Rate Shows the current flow rate for the station.

Volume Today Shows the calculated flow volume for the day for this station.

15.4 **Limit Switches**

If you chose **Limit Switches** to determine flow direction, you can view the following:

Figure 15-5. Bi-Directional Control – Limit Switch



Limit Switch / DI Status

LS/DI No.

Shows the number of the open limit switch / digital input. **Note:** If a particular limit switch has no digital input assigned to it, it is not examined when determining the flow direction.

Tagname

Shows the tag in the FB3000 that provides the status of the limit switch or digital input.

Forward State

Forward State:

Off Indicates that this LS/DI is Off when flow is in the forward state.

On Indicates that this LS/DI is On when flow is in the forward state.

Current State

Shows the current state of the limit switch/DI. **Off** is shown highlighted in red, **On** is shown highlighted in green.

Failure Status

In a failure, shows the valve number which caused the failure; otherwise shows **Clear**.

Direction Alarm

Each defined limit switch is evaluated to see if its **Current State** differs from the specified **Forward State**. If any such limit switch differs from the **Forward**

State, it triggers a direction alarm. If the status of the alarm is Off, there is no discrepancy between **Current State** and **Forward State**.


Current Rates & Total

Stn No.	Shows the station number.
Stn Tagname	Shows the name for the station.
Flow Rate	Shows the current flow rate for the station.
Volume Today	Shows the calculated flow volume for the day for this station.

15.5 Dual Limit Switches




If you chose **Dual Limit Switches** to determine flow direction, you can view the following:

Figure 15-6. Dual Limit Switches



Block Valve / Dual LS Status


LS Pair	Identifies the number of the pair of limit switches for a valve, one which turns on when the valve is fully open, the other which turns on when the valve is fully closed.
----------------	--

Open/Close Tagname	<p>The upper box shows the tag in the FB3000 for the open limit switch for this valve.</p> <p>The lower box shows the tag in the FB3000 for the closed limit switch for this valve.</p>
Fwd State	<p>Forward state</p> <p>On Indicates that when flow for this pair of limit switches is in the forward direction, the open limit switch should be on.</p> <p>Off Indicates that when flow for this pair of limit switches is in the forward direction, the open limit switch should be off.</p>
OLS/CLS	<p>Shows the current state of the OLS (open limit switch) and CLS (closed limit switch). Possible states are:</p> <p> Red with white "X" – This limit switch is energized.</p> <p> Gray – This limit switch is not energized.</p> <p> Yellow – The valve is traveling.</p>
Failure Status	<p>In a failure, shows the valve number which caused the failure; otherwise shows Clear.</p>
Direction Alarm	<p>Each defined limit switch is evaluated to see if its Current State differs from the specified Forward State. If any such limit switch differs from the Forward State, it triggers a direction alarm. If the status of the alarm is Off, there is no discrepancy between Current State and Forward State.</p>
<u>Current Rates & Totals</u>	
Stn No.	Shows the station number.
Stn Tagname	Shows the name for the station.
Flow Rate	Shows the current flow rate for the station.
Volume Today	Shows the calculated flow volume for the day for this station.

15.6 Software Switch

If you chose **Software Switch** to determine flow direction, you can view the following:

Figure 15-7. Bi-Directional Control – Software Switch



Software Switch

Click **Forward** to toggle flow to the forward direction.
Click **Reverse** to toggle flow to the reverse direction.


Current Rates & Totals

- Stn No.** Shows the station number.
- Stn Tagname** Shows the name for the station.
- Flow Rate** Shows the current flow rate for the station.
- Volume Today** Shows the calculated flow volume for the day for this station.

15.7 Frequency (Metrology)

If you chose **Frequency (Metrology)** to determine flow direction, you can view the following:

Figure 15-8. Bi-Directional Control - Frequency



Linear Meter Status Shows the status of the linear meter currently in use. The status can be one of the following:

OK Forward/Reverse meters configured correctly.

Number Linear Meters Unequal The number of meters for forward and reverse stations do not match.

Forward Meters / Reverse Meters Identifies the name of the linear meters used in the specified direction.

Low Cutoff When flow drops below this value, valves for the station close.

Freq in Use Shows the frequency used for this meter.

Current Rates & Totals

Stn No. Shows the station number.

Stn Tagname Shows the name for the station.

Flow Rate Shows the current flow rate for the station.

Volume Today Shows the calculated flow volume for the day for this station.

Index

A

Access	
on Station Control Overview screen Station Controls sub tab	69
Action on Bad Data	
on Station Control Config General tab	23
Action on Disable	
on Station Control Config General tab	24
Action on No Control	
on Station Control Config General tab	24
Active Control	
on Station Control Overview screen Station Controls sub tab	69
Alarm Delay	
on Station Control Config Control Bi-Directional Flow tab Limit Switch sub-tab	51, 53
Alt Outlet Pressure Source	
on Station Control Config General tab	24
Alternate Source Control	
on Remote Control Valve Monitor screen ...	81
Analog Feedback Point	
on Station Control Config Control Valves tab	38
Analog Out Obj	
on Station Control Config Control Valves tab	38
Application	
updating	7
Apply Default PVs	
button on on BiDi PV pop-up screen	26
Arm	
on Remote Control Valve Monitor screen ..	80, 81
Auto / Manual Mode	
on Run Staging Configuration screen Tube settings tab	88
Auto Reset	
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	46
Auto-Zero Setpoint	

on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	47
--	----

B

BiDi Mode	
on Station Control Config General tab ...	24, 41
Bi-directional Control	
license	4
Bi-directional flow control	2
Bi-Directional Flow Control Monitor screen	99
Bi-Directional Flow tab	
on Station Control Config screen	41
Blind Mode	
on Remote Control Valve Config screen	77
on Run Staging Configuration screen Valve settings tab	91
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	49
Block Valve	
on Run Staging Configuration screen Valve settings tab	90
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	48
Block Valve / Dual LS Status	
on Single Switch / BV / Dual LS sub-tab on Bi-Directional Flow Control Monitor screen .	107
Block Valve Status	
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen	103
BV#	
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen	103
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	48
BV/Dual LS tab	
on Bi-Directional Flow Control Monitor screen	107

C

Call Next Setpoint	
on Run Staging Configuration screen Tube settings tab	88
Call Prev Setpoint	
on Run Staging Configuration screen Tube settings tab	88
on Run Staging Monitor screen	96
Called To	
on Run Staging Configuration screen Tube settings tab	89
on Run Staging Monitor screen	97
Check flow to switch tubes	
on Run Staging Configuration screen	84
Clear All Saved Meters button	
on Station Control Run Mapping screen	13, 15
Close at Low PV	
on Station Control Config General tab	23
Close Cmd Obj 1	
on Remote Control Valve Config screen	77
Close Cmd Obj 2	
on Remote Control Valve Config screen	77
Close Limit Point	
on Station Control Config Control Valves tab	39
Close Limit SW Pnt	
on Run Staging Configuration screen Valve settings tab	92
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	50
Close LS	
on Run Staging Configuration screen Valve settings tab	92
on Run Staging Monitor screen	97
Close LS DI Input	
on Remote Control Valve Config screen	77
Close Output Obj	
on Run Staging Configuration screen Valve settings tab	91
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	50
Close State	
on Remote Control Valve Monitor screen ...	81
Close Status	
on Remote Control Valve Monitor screen ...	80
Close Valve	
on Remote Control Valve Monitor screen ...	80
on Run Staging Configuration screen Tube settings tab	89
on Run Staging Configuration screen Valve settings tab	92
CLS	
on Block Valve/ Dual LS sub-tab on Bi-Directional Flow Control Monitor screen	108
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen	104
on Station Control Overview screen Control Valves sub tab	73
Command/Status	
on Run Staging Configuration screen Tube settings tab	89
Configuration	
overview of steps	8
Control Access	
on Station Control Overview screen Station Controls sub tab	69
Control Action for MAOP PID	
on Protection PIDs tab on Station Control Config screen	32
Control Mode	
on Remote Control Valve Config screen	76
on Site Settings General tab	17
Control Valve	
on Station Control Overview screen Control Valves sub tab	72
Control Valve (CV) Mapping pop-up	39
Control Valve Mapping	
pop-up from Station Control Config Control Valves tab	39
Cur State	
on Single Switch / DI sub-tab on Bi-Directional Flow Control Monitor screen	106
Current Direction Indication	
on Bi-Directional Flow Control Monitor screen	100
Current PV	
field on on BiDi PV pop-up screen	25
Current Rank	
on Run Staging Monitor screen	94
Current Rates & Total	
on Single Switch / DI sub-tab on Bi-Directional Flow Control Monitor screen	107
Current Rates & Totals	

on Block Valve/ Dual LS sub-tab on Bi-Directional Flow Control Monitor screen	108	on Station Control Run Mapping screen.....	13
on DP sub-tab on Bi-Directional Flow Control Monitor screen	101	DI Status	
on Frequency sub-tab on Bi-Directional Flow Control Monitor screen	110	on Single DI sub-tab on Bi-Directional Flow Control Monitor screen.....	105
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen	104	DI Value	
on Single DI sub-tab on Bi-Directional Flow Control Monitor screen	105	on Single DI sub-tab on Bi-Directional Flow Control Monitor screen.....	105
on Software Switch sub-tab on Bi-Directional Flow Control Monitor screen	109	Dir Change Permissive	
CV Demand Output		on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	44
on Station Control Overview screen Station Controls sub tab.....	70	Direction	
CV IO button		on PIDs tabs on Station Control Config screen	34
on Station Control Overview screen Station Controls sub tab.....	70	Direction Alarm	
CV Mapping button		on Dual LS sub-tab on Bi-Directional Flow Control Monitor screen.....	108
on Station Control Config Control Valves tab	39	on Single Switch / DI sub-tab on Bi-Directional Flow Control Monitor screen .	107
D		Direction Control	
Deadband		on Program Control sub-tab on Bi-Directional Flow Control Monitor screen.....	101
on PIDs tabs on Station Control Config screen	32	Direction Control Status	
Deenergize		on Program Control sub-tab on Bi-Directional Flow Control Monitor screen.....	102
on Remote Control Valve Monitor screen ...	80	Direction Indication	
Demand		on Program Control sub-tab on Bi-Directional Flow Control Monitor screen.....	103
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen	104	Direction Indication Source	
Demand Output		on Station Control Config Control Bi-Directional Flow tab.....	41
on Station Control Overview screen Station Controls sub tab.....	70	Direction Label	
Derivative		on Station Control Config Control Bi-Directional Flow tab DP sub-tab.....	43
on PIDs tabs on Station Control Config screen	33, 34	Direction Request	
Desc		on Program Control sub-tab on Bi-Directional Flow Control Monitor screen.....	103
on PIDs tabs on Station Control Config screen	31, 34	Disable Next / Prev Config Check	
on Station Control Config Control Valves tab	37	on Run Staging Configuration screen Tube settings tab.....	88
Description		DP in Use	
field on on BiDi PV pop-up screen.....	25	on DP sub-tab on Bi-Directional Flow Control Monitor screen.....	100
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	48	DP Meter Status	
on Station Control Overview screen Control Valves sub tab.....	72	on DP sub-tab on Bi-Directional Flow Control Monitor screen.....	100
on Station Control Overview screen Meter Protection sub tab.....	71	DP tab	
		on Bi-Directional Flow Control Monitor screen	

..... 100	on Station Control Config General tab 22
Dual LS sub-tab	FBxStation Control
on Station Control Config Control Bi-Directional Flow tab 52	starting9
Dual Maintained	Figures
on Remote Control Valve Config screen 76	1-1. Monitor Screen.....1
on Run Staging Configuration screen Valve settings tab 90	2-1. Licensing in FBxConnect4
Dual Maintained Outputs	2-2. SCBD License5
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab..... 49	2-3. Applications Management.....5
Dual Pulsed	2-4. Application Management dialog box6
on Remote Control Valve Config screen 76	2-5. Application added successfully6
on Run Staging Configuration screen Valve settings tab 91	2-6. Application Management7
Dual Pulsed Outputs	3-1. Calling up the Config Menu.....9
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab..... 49	3-2. Highlighting of unsaved changes 10
E	3-3. Calling up Screens9
Enable No Flow Shutin	3-4. Selecting a Tab 10
on Run Staging Configuration screen..... 87	4-1. Calling up the Run Mapping Screen 12
Enable Staging	4-2. No Meter Runs Mapped Yet 12
on Run Staging Configuration screen..... 84	4-3. Selecting the Station..... 13
on Run Staging Monitor screen 93, 94	4-4. Saving Meters into Station Control..... 13
Enable Status	4-5. Setting the Tube Rank 14
on PIDs tabs on Station Control Config screen31	4-6. Licensing..... 14
Enable Switch	5-1. Site Settings – General tab..... 17
on PIDs tabs on Station Control Config screen31, 33	5-2. Configurable Mode – Choosing Local or Local/Remote..... 18
Enable/Disable Program Control	5-3. Station Switches Tab 19
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen 101	5-4. RCV Switches Tab 19
ESD	6-1. Navigating to Station Control Config ... 21
on Station Control Config General tab..... 26	6-2. Selecting the STation..... 21
ESD Point	6-3. Station Control Config tab 22
on Station Control Config General tab..... 26	6-4. BiDi PVs 25
Execute	6-5. Selecting the Type of Objects in the Point Picker 27
on Remote Control Valve Monitor screen .. 80, 81	6-6. Selecting the Object 28
F	7-1. Primary PIDs tab 29
Failure Mode	7-2. Protection PIDs tab..... 30
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab..... 45	7-3. Override PIDs 31
Fast Close	7-4. PID Tuning Screen 33
	8-1. Station Config – Control Valves tab 37
	8-2. Control Valve (CV) Mapping..... 39
	9-1. Selecting the BiDi Mode on the General Tab 41
	9-2. Choosing the Direction Indication Method 41
	9-3. No Flow Cut-off 42
	9-4. Bi-Directional Control – DP 42
	9-5. Transfer Point Labels..... 43
	9-6. Direction Label 43

9-7. Bi-Directional Control – Programmed Control.....	44	Rates & Totals.....	99
9-8. Bi-Directional Flow – Single DI.....	50	15-2. Bi-Directional Control - DP	100
9-9. Bi-Directional Control – Limit Switch	51	15-3. Bi-Directional Control – Programmed Control	101
9-10. Bi-Directional Control – Dual Limit Switches	52	15-4. Bi-Directional Flow- Single DI.....	105
9-11. Bi-Directional Control – Software Switch	53	15-5. Bi-Directional Control - Limit Switch .	106
9-12. Bi-Directional Control Frequency.....	54	15-6. Dual Limit Switches	107
9-13. DP Meter 1 assigned to Station 1 (Forward).....	55	15-7. Bi-Directional Control – Software Switch	109
9-14. Assigning DP Meter 2 to Station 1 (Forward).....	56	15-8. Bi-Directional Control-Frequency	110
9-15. Assigning DP Meter 3 to Station 2 (Reverse).....	56	Flow Rate	
9-16. Assigning DP Meter 4 to Station 2 (Reverse).....	57	on Block Valve/ Dual LS sub-tab on Bi-Directional Flow Control Monitor screen .	108
9-17. Station 1 Active – Forward Flow	58	on DP sub-tab on Bi-Directional Flow Control Monitor screen.....	101
9-18. Station 2 Active (Reverse Flow)	58	on Frequency sub-tab on Bi-Directional Flow Control Monitor screen.....	110
9-19. Assigning Linear Meter 2 to Station 5	59	on Program Control sub-tab on Bi-Directional Flow Control Monitor screen.....	104
9-20. Figure Name.....	60	on Single DI sub-tab on Bi-Directional Flow Control Monitor screen.....	105
9-21. Station 5 Active (Forward).....	61	on Single Switch / DI sub-tab on Bi-Directional Flow Control Monitor screen .	107
9-22. Station 6 Active (Reverse)	61	on Software Switch sub-tab on Bi-Directional Flow Control Monitor screen.....	109
9-23. Assigning Linear Meter 4 to Station 7 (Forward).....	62	Flow/Energy Select	
9-24. Assigning Linear Meter 5 to Station 7 (Forward).....	63	on Station Control Config General tab	22
9-25. Assigning Linear Meter 6 to Station 8 (Reverse).....	64	Force Direction	
9-26. Assigning Linear Meter 7 to Station 8 (Reverse).....	64	on Station Control Config Control Bi-Directional Flow tab Limit Switch sub-tab.	51, 52
9-27. Configuring Limit Switches to Choose Direction.....	65	Forward	
9-28. Station 7 Active (Forward).....	65	on Software Switch sub-tab on Bi-Directional Flow Control Monitor screen.....	109
9-29. Station 8 Active (Reverse)	66	Forward Direction	
10-1. Station Control Overview.....	67	on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	45
10-2. Station Control Overview – Meter Protection tab.....	71	Forward Meters	
10-3. Station Control Overview – Control Valves Tab	72	on DP sub-tab on Bi-Directional Flow Control Monitor screen.....	100
11-1. Remote Control Valve Config Screen .	75	on Frequency sub-tab on Bi-Directional Flow Control Monitor screen.....	110
12-1. Remote Control Valve Monitor.....	79	Forward PV	
12-2. RCV IO Pop-up.....	81	field on on BiDi PV pop-up screen	25, 26
13-1. Run Staging Configuration.....	83	Freq in Use	
13-2. Valve Settings Tab	90	on Frequency sub-tab on Bi-Directional Flow	
14-1. Run Staging Monitor	93		
15-1. Flow Direction depicted in Current			

Control Monitor screen	110	on Station Control Config Control Bi- Directional Flow tab Programmed Control sub-tab	49
Frequency sub-tab		IO	
on Station Control Config Control Bi- Directional Flow tab	54	on Remote Control Valve Monitor screen ...	81
Frequency tab		Isolation Input Point	
on Bi-Directional Flow Control Monitor screen	109	on Remote Control Valve Config screen.....	78
Fwd State		Isolation Input Trip Status	
on Block Valve/ Dual LS sub-tab on Bi- Directional Flow Control Monitor screen.	108	on Remote Control Valve Monitor screen ...	81
on Single Switch / DI sub-tab on Bi- Directional Flow Control Monitor screen.	106	Isolation Point	
		on Remote Control Valve Config screen.....	78
G		L	
Gain		L/R Access	
on PIDs tabs on Station Control Config screen	32, 34	on Remote Control Valve Monitor screen ...	79
I		Label Configuration	
I/O		on Station Control Config Control Bi- Directional Flow tab DP sub-tab.....	43
on Run Staging Configuration screen Valve settings tab	91	Latch Station ESD	
on Station Control Config Control Bi- Directional Flow tab Programmed Control sub-tab.....	50	on Station Control Config General tab	26
Initial Rank		Licensing	3, 4, 14
on Run Staging Configuration screen.....	84	for bi-directional control	4
on Run Staging Monitor screen.....	94	restarting FBxStation Control for new license to be recognized	15
Initialization		SC BiDi License Status.....	14
on Run Staging Configuration screen....	84, 86	Limit Delay	
on Run Staging Monitor screen.....	93	on Run Staging Configuration screen Valve settings tab	91
Initialize		on Station Control Config Control Bi- Directional Flow tab Programmed Control sub-tab	49
on Run Staging Configuration screen.....	84	Limit Switch / DI Status	
on Run Staging Monitor screen.....	94	on Single Switch / DI sub-tab on Bi- Directional Flow Control Monitor screen	106
Inlet pressure Source		Limit Switch/DI tab	
on Station Control Config General tab.....	26	on Bi-Directional Flow Control Monitor screen	105
Input High range		Limit Switches sub-tab	
on Station Control Config Control Valves tab	38	on Station Control Config Control Bi- Directional Flow tab	50
Input Low range		Line Break Point	
on Station Control Config Control Valves tab	38	on Remote Control Valve Config screen.....	78
Installation	3, 5	Line Break Trip Status	
Integral		on Remote Control Valve Monitor screen ...	81
on PIDs tabs on Station Control Config screen	32, 34	Linear Meter Status	
Invert		on Frequency sub-tab on Bi-Directional Flow Control Monitor screen	110
on Remote Control Valve Config screen	77	Local	
on Run Staging Configuration screen Valve settings tab	91		

on Remote Control Valve Config screen.....	77	on Station Control Overview screen Control	
Local Control		Valves sub tab	72
on Remote Control Valve Monitor screen ...	80	Max Value	
Local Control Control		on PIDs tabs on Station Control Config screen	34
on Program Control sub-tab on Bi-Directional		Maximum Rank	
Flow Control Monitor screen	101	on Run Staging Configuration screen	86
Local only		on Run Staging Monitor screen	94
on Site Settings General tab	18	Menu navigation	9
Local Request		Meter	
on Program Control sub-tab on Bi-Directional		mapping a meter run	11
Flow Control Monitor screen	102	no meter runs mapped	12
Local SP		Meter Protection	
on Station Control Overview screen Station		on Station Control Config General tab	23
Controls sub tab	68	Meter Type	
Local/Remote		on Station Control Run Mapping screen	13
on Site Settings General tab	18	Meters	
Loop Quality		defined	1
on Station Control Overview screen Station		MP Run	
Controls sub tab	69	field on on BiDi PV pop-up screen	25
Low Cutoff		N	
on Frequency sub-tab on Bi-Directional Flow		Next Deadband	
Control Monitor screen	110	on Run Staging Configuration screen Tube	
Low flow cut-off	42	settings tab	88
Low PV Limit		on Run Staging Monitor screen	96
on Station Control Config General tab	23	No flow cut-off	42
Lower Command		No Flow Shutin	
on Station Control Overview screen Control		on Run Staging Configuration screen	87
Valves sub tab	73	on Station Control Config Control Bi-	
LS Pair		Directional Flow tab Programmed Control	
on Block Valve/ Dual LS sub-tab on Bi-		sub-tab	45
Directional Flow Control Monitor screen	107	No Meters Saved For This Stationon Station	
LS Travel Time		Control Run Mapping screen	15
on Remote Control Valve Config screen.....	76	No Meters Setup For This Station	
M		on Station Control Run Mapping screen	15
Maintenance Bypass		No Status message	
on Station Control Overview screen Station		on Station Control Run Mapping screen	15
Controls sub tab	70	Number Meters This Station	
Manual Control		on Station Control Run Mapping screen	15
on Station Control Overview screen Station		Number Saved Meters	
Controls sub tab	70	on Station Control Run Mapping screen	15
Manual Mode		Number Saved Stations	
on Station Control Overview screen Control		on Station Control Run Mapping screen	15
Valves sub tab	72	Number SC Licenses	
Manual Ramp Rate		on Station Control Run Mapping screen	14
on Station Control Overview screen Station		O	
Controls sub tab	70	OK	
Manual Setpoint			

on Station Control Run Mapping screen	15	Directional Flow tab Programmed Control	
OLS		sub-tab	50
on Block Valve/ Dual LS sub-tab on Bi-		Open State	
Directional Flow Control Monitor screen.	108	on Remote Control Valve Monitor screen ...	81
on Program Control sub-tab on Bi-Directional		Open Status	
Flow Control Monitor screen	104	on Remote Control Valve Monitor screen ...	80
on Station Control Overview screen Control		Open Valve	
Valves sub tab	73	on Remote Control Valve Monitor screen ...	80
OLS State Forward		on Run Staging Configuration screen Tube	
on Station Control Config Control Bi-		settings tab	89
Directional Flow tab Dual LS sub-tab	52	on Run Staging Configuration screen Valve	
on Station Control Config Control Bi-		settings tab	92
Directional Flow tab Limit Switch sub-tab	51,	Open/Close Tagname	
52		on Block Valve/ Dual LS sub-tab on Bi-	
One Step Remote Control		Directional Flow Control Monitor screen	108
on Station Control Config General tab.....	23	Operating Range	
Open Cmd Obj 1		on Station Control Config Control Valves tab	
on Remote Control Valve Config screen	77	38
Open Cmd Obj 2		Outlet Pressure Source	
on Remote Control Valve Config screen	77	on Station Control Config General tab	26
Open Limit Point		Output Deadband	
on Station Control Config Control Valves tab		on PIDs tabs on Station Control Config screen	34
.....	38	Output Ramp Rate	
Open Limit SW Pnt		on Station Control Config Control Valves tab	
on Run Staging Configuration screen Valve		38
settings tab	92	on Station Control Overview screen Control	
on Station Control Config Control Bi-		Valves sub tab.....	73
Directional Flow tab Programmed Control			
sub-tab.....	50	P	
Open LS		Permissive	
on Run Staging Configuration screen Valve		on Station Control Config Control Bi-	
settings tab	92	Directional Flow tab Programmed Control	
on Run Staging Monitor screen	97	sub-tab	44
Open LS DI Input		Permissive Point	
on Remote Control Valve Config screen	77	on Station Control Config Control Valves tab	
Open LS/DI		37
on Station Control Config Control Bi-		on Station Control Overview screen Control	
Directional Flow tab Dual LS sub-tab	52	Valves sub tab.....	72
on Station Control Config Control Bi-		PID	
Directional Flow tab Limit Switch sub-tab .	51	Control Parameters on PIDs tabs on Station	
Open LS/DI No		Control Config screen.....	31
on Single Switch / DI sub-tab on Bi-		field on on BiDi PV pop-up screen.....	25
Directional Flow Control Monitor screen.	106	Loop tuning procedure	34
Open Output Obj		Override PIDs tab on Station Control Config	
on Run Staging Configuration screen Valve		screen	30
settings tab	91	Primary PIDs tab on Station Control Config	
on Station Control Config Control Bi-		screen	29, 31
		Protection PIDs tab on Station Control Config	

screen	30	on PIDs tabs on Station Control Config screen	32
PID Setpoint		PV Selection	
on Station Control Overview screen Station		on Run Staging Configuration screen	85
Controls sub tab	70	PV Value	
PID Status		on Run Staging Configuration screen Tube	
on Station Control Overview screen Station		settings tab	87
Controls sub tab	68	on Run Staging Monitor screen	96
PID Tuning screen	33	R	
Pipe Diameter		Raise Command	
on Run Staging Configuration screen	85	on Station Control Overview screen Control	
Pipe Diameter for Velocity		Valves sub tab	73
on Run Staging Configuration screen	85	Rank	
Point		setting for a tube	14
on PIDs tabs on Station Control Config screen	32, 34	Rank Values	
Point Picker		on Run Staging Configuration screen	86
working with the	27	on Run Staging Monitor screen	94
Position		RCV	
on Run Staging Configuration screen Valve		on Remote Control Valve Config screen	75
settings tab	92	on Remote Control Valve Monitor screen	79
Position Feedback		Remaining SC Licenses	
on Remote Control Valve Config screen	77	on Station Control Run Mapping screen	15
on Station Control Config Control Valves tab		Remote	
.....	38	on Remote Control Valve Config screen	77
Prev Deadband		Remote Control	
on Run Staging Configuration screen Tube		on Program Control sub-tab on Bi-Directional	
settings tab	88	Flow Control Monitor screen	102
on Run Staging Monitor screen	96	on Remote Control Valve Monitor screen	80
Process Variable		Remote Control Valve Config screen	75
on PIDs tabs on Station Control Config screen	32, 34	Remote Control Valve Monitor screen	79
Process Variables button		Remote control valves	2
on Station Control Config General tab	25	Remote Request	
Program Control tab		on Program Control sub-tab on Bi-Directional	
on Bi-Directional Flow Control Monitor screen		Flow Control Monitor screen	102
.....	101	Remote SP	
Pulse Duration		on Station Control Overview screen Station	
on Remote Control Valve Config screen	76	Controls sub tab	68
on Run Staging Configuration screen Valve		Requested Rank	
settings tab	91	on Run Staging Configuration screen	87
on Station Control Config Control Bi-		on Run Staging Monitor screen	94
Directional Flow tab Programmed Control		Reset	
sub-tab	49	on Program Control sub-tab on Bi-Directional	
PV		Flow Control Monitor screen	103
on Station Control Overview screen Meter		on Remote Control Valve Monitor screen	80
Protection sub tab	71	on Run Staging Monitor screen	97
on Station Control Overview screen Station		Reset ESD	
Controls sub tab	68	on Station Control Overview screen Station	
PV Max		Controls sub tab	69

Reset/Clear	on PIDs tabs on Station Control Config screen32, 34
on Run Staging Configuration screen Tube settings tab 89	Setting
Reverse	on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab 45
on Software Switch sub-tab on Bi-Directional Flow Control Monitor screen 109	Settings
Reverse Direction	on PIDs tabs on Station Control Config screen32, 34
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab..... 48	on Station Control Config Control Bi-Directional Flow tab Dual LS sub-tab..... 52
Reverse Meters	on Station Control Config Control Bi-Directional Flow tab Limit Switch sub-tab. 51
on DP sub-tab on Bi-Directional Flow Control Monitor screen 100	on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab 48
on Frequency sub-tab on Bi-Directional Flow Control Monitor screen 110	on Station Control Config Control Bi-Directional Flow tab Single DI sub-tab 50
Reverse PV	on Station Control Config Control Bi-Directional Flow tab Software Switch sub-tab..... 54
field on on BiDi PV pop-up screen 25, 26	on Station Control Config Control Valves tab 38
Run mapping 11	Settle Time
button on Station Control Config General tab 12	on Run Staging Configuration screen 84
Run Mapping button	Shutin Tube When Rank Exceeded
on Station Control Config General tab..... 24	on Run Staging Configuration screen Tube settings tab 88
Run staging..... 2	Single DI
Run Staging Configuration screen..... 83	on Station Control Config Control Bi-Directional Flow tab 50
Run Staging Monitor screen 93	Single DI tab
S	on Bi-Directional Flow Control Monitor screen 104
Save Meters to Station Control button	Single Maintained
on Station Control Run Mapping screen 13	on Remote Control Valve Config screen..... 76
Saved Meter Mismatch	on Run Staging Configuration screen Valve settings tab 90
on Station Control Run Mapping screen 15	Single Maintained Output
Saving your changes..... 10	on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab 49
SC BiDi License Status	Site name
on Station Control Run Mapping screen 14	on Station Control Run Mapping screen 13
Screens	Site Settings
calling up 9	General tab 17
Select All button	RCV switches tab 19
on Site Settings General tab..... 18	Site Settings..... 17
Selected DI	Site Settings Station Switches tab..... 18
on Station Control Config Control Bi-Directional Flow tab Single DI sub-tab..... 50	
Set Direction To	
on Station Control Config Control Bi-Directional Flow tab Limit Switch sub-tab 51, 53	
Setpoint	
on Run Staging Monitor screen 96	
Setpoint Ramp Rate	

Site Switch	
on Site Settings General tab	17
Site Switch Point	
on Site Settings General tab	17
Software Switch	
on Software Switch sub-tab on Bi-Directional Flow Control Monitor screen	109
on Station Control Config Control Bi-Directional Flow tab Software Switch sub-tab	54
Software Switch sub-tab	
on Station Control Config Control Bi-Directional Flow tab	53
Software Switch tab	
on Bi-Directional Flow Control Monitor screen	109
Source Demand	
on Station Control Overview screen Control Valves sub tab.....	73
SP	
on Station Control Overview screen Meter Protection sub tab.....	71
Staging Status	
on Run Staging Configuration screen	84
on Run Staging Monitor screen.....	93
Starting FBxStation Control	9
Station	
selecting	13
selecting the	21
Station Control	
on Station Control Config General tab	22
Station Control Config	
Control Valves tab	37
PID tabs	29
Station Control Config tab	22
Station Control Monitor screen.....	67
Station Control Overview screen	67
Station Control Valves	
on Station Control Overview screen Control Valves sub tab.....	72
Station Demand	
on Station Control Overview screen Station Controls sub tab	70
Station Flow Rate	
on Run Staging Configuration screen	87
on Run Staging Monitor screen.....	95
Station No	
on Station Control Run Mapping screen.....	13
Station Settings	
on Run Staging Configuration screen	84
Station Status	
on Station Control Overview screen Station Controls sub tab.....	69
Stations	
defined	2
number supported	2
Status	
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen.....	102
on Remote Control Valve Monitor screen....	80
on Run Staging Configuration screen Tube settings tab.....	89
on Station Control Overview screen Meter Protection sub tab	71
on Station Control Run Mapping screen.....	15
Step Mode	
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	47
Stn No	
on Block Valve/ Dual LS sub-tab on Bi-Directional Flow Control Monitor screen .	108
on DP sub-tab on Bi-Directional Flow Control Monitor screen.....	101
on Frequency sub-tab on Bi-Directional Flow Control Monitor screen.....	110
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen.....	104
on Single DI sub-tab on Bi-Directional Flow Control Monitor screen.....	105
on Single Switch / DI sub-tab on Bi-Directional Flow Control Monitor screen .	107
on Software Switch sub-tab on Bi-Directional Flow Control Monitor screen.....	109
Stn Tagname	
on Block Valve/ Dual LS sub-tab on Bi-Directional Flow Control Monitor screen .	108
on DP sub-tab on Bi-Directional Flow Control Monitor screen.....	101
on Frequency sub-tab on Bi-Directional Flow Control Monitor screen.....	110
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen.....	104
on Single DI sub-tab on Bi-Directional Flow	

Control Monitor screen	105	Tube ID	
on Single Switch / DI sub-tab on Bi-Directional Flow Control Monitor screen.	107	on Run Staging Configuration screen Tube settings tab	87
on Software Switch sub-tab on Bi-Directional Flow Control Monitor screen	109	on Run Staging Configuration screen Valve settings tab	90
Switch Settings		on Run Staging Monitor screen.....	95
on Run Staging Configuration screen Tube settings tab	88	Tube Rank	
T		on Station Control Run Mapping screen	14
Tabs		Tube Settings	
selecting	10	on Run Staging Monitor screen.....	95
Tag		Tube Settings tab	
on PIDs tabs on Station Control Config screen31, 33		on Run Staging Configuration screen	87
on Remote Control Valve Config screen	75	Tube staging.....	2
on Remote Control Valve Monitor screen ...	79	Tube Status	
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab.....	48	on Run Staging Configuration screen Tube settings tab	87
on Station Control Config Control Valves tab	37	on Run Staging Monitor screen.....	95
Tagname		Tuning	
on Program Control sub-tab on Bi-Directional Flow Control Monitor screen	103	on PIDs tabs on Station Control Config screen32, 34	
on Single Switch / DI sub-tab on Bi-Directional Flow Control Monitor screen.	106	U	
Target Rank		Update Description in SC	
on Run Staging Configuration screen Tube settings tab	88	on Station Control Run Mapping screen	14
on Run Staging Monitor screen	96	Updating the application	7
Time Delay for Steps		Use Default PVs	
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab.....	47	button on PIDs tabs on Station Control Config screen.....	33
Transfer Point A		User PV	
on Station Control Config Control Bi-Directional Flow tab DP sub-tab	43	on Run Staging Configuration screen	86
Transfer Point B		V	
on Station Control Config Control Bi-Directional Flow tab DP sub-tab	43	Valid Flow Limit	
Travel Time		on Run Staging Configuration screen Tube settings tab	88
on Remote Control Valve Config screen	76	on Run Staging Monitor screen.....	96
Tube		Valve Action	
on Run Staging Configuration screen Tube settings tab	87	on Station Control Config Control Valves tab	38
on Run Staging Monitor screen	95	Valve Called To	
Tube Fail Mode		on Run Staging Configuration screen Valve settings tab	92
on Run Staging Configuration screen.....	84	Valve Close Sequence	
		on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	45, 48
		Valve Control Type	
		on Run Staging Configuration screen Valve settings tab	90

on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	48	Valve Travel Time on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	49
Valve Demand		Valve Type	
on Remote Control Valve Monitor screen ...	80	on Remote Control Valve Config screen	76
Valve Demand Output		on Station Control Config Control Valves tab	38
on Station Control Overview screen Control Valves sub tab.....	73	Valves	
Valve Open Sequence		remote control	2
on Station Control Config Control Bi-Directional Flow tab Programmed Control sub-tab	45, 48	Volume Today	
Valve Position		on Block Valve/ Dual LS sub-tab on Bi-Directional Flow Control Monitor screen .	108
on Remote Control Valve Monitor screen ...	80	on DP sub-tab on Bi-Directional Flow Control Monitor screen.....	101
on Station Control Overview screen Control Valves sub tab.....	73	on Frequency sub-tab on Bi-Directional Flow Control Monitor screen.....	110
Valve Settings		on Program Control sub-tab on Bi-Directional Flow Control Monitor screen.....	104
on Remote Control Valve Config screen.....	76	on Single DI sub-tab on Bi-Directional Flow Control Monitor screen.....	105
on Run Staging Configuration screen Valve settings tab	91	on Single Switch / DI sub-tab on Bi-Directional Flow Control Monitor screen .	107
Valve Settings tab		on Software Switch sub-tab on Bi-Directional Flow Control Monitor screen.....	109
on Run Staging Configuration screen	90		
Valve Status		Z	
on Remote Control Valve Monitor screen ...	80	Zap file	6
Valve Travel Time			
on Run Staging Configuration screen Valve settings tab	91		

FBxStation Control™ Application User Manual

D301919X012

March 2024

For customer service and technical support,
visit [Emerson.com/Guardian](https://emerson.com/Guardian).

North America and Latin America:

Emerson Automation Solutions
Energy and Transportation Solutions
6005 Rogerdale Road
Houston, TX 77072 U.S.A.
T +1 281 879 2699 | F +1 281 988 4445
[Emerson.com/SCADAforEnergy](https://emerson.com/SCADAforEnergy)

United Kingdom:

Emerson Automation Solutions
Meridian East
Meridian Business Park 7
Leicester LE19 1UX UK
T +44 0 870 240 1987
F +44 0 870 240 4389

Europe:

Emerson S.R.L
Regulatory Compliance Shared Services
Department
Company No. J12/88/2006
Emerson 4 Street
Parcul Industrial Tetarom 11
Romania
T +40 374 132 000

Middle East/Africa:

Emerson Automation Solutions
Energy and Transportation Solutions
Emerson FZE
P.O. Box 17033
Jebel Ali Free Zone – South 2
Dubai U.A.E.
T +971 4 8118100 | F +971 4 8865465

Asia-Pacific:

Emerson Automation Solutions
Energy and Transportation Solutions
1 Pandan Crescent
Singapore 128461
T +65 6777 8211 | F +65 6777 0947

© 2024 Bristol Inc. All rights reserved.

This publication is for informational purposes only. While every effort has been made to ensure accuracy, this publication shall not be read to include any warranty or guarantee, express or implied, including as regards the products or services described or their use or applicability. Bristol Inc. (hereinafter “Energy and Transportation Solutions” or ETS) reserves the right to modify or improve the designs or specifications of its products at any time without notice. All sales are governed by ETS terms and conditions which are available upon request. ETS accepts no responsibility for proper selection, use or maintenance of any product, which remains solely with the purchaser and/or end-user. Emerson Automation Solutions, Emerson, and the Emerson logo are trademarks and service marks of Emerson Electric Co. All other marks are the property of their respective owners.