

Fisher™ 3582 and 3582i Positioners and 582i Electro-Pneumatic Converter



Table of Contents

Section 1: Introduction

1.1 Scope of the Manual 1

1.2 Description 2

1.3 Specifications 7

1.4 Education Services 7

Section 2: Installation 8

2.1 Hazardous Area Classifications and Special Instructions for
"Safe Use" and Installation in Hazardous Locations for 582i
Electro-Pneumatic Converter 9

2.2 Mounting 10

2.3 Changing Cam Position 15

2.4 Pressure Connections 15

2.5 Vent 18

2.6 Electrical Connections for 3582i Valve Positioner 19

2.7 582i Converter Installation 21

Section 3: Operating Information

3.1 Valve Positioner Cam Information 23

3.2 Valve Positioner Bypass Operation 25

3.3 Input Signal Ranges 25

3.4 Valve Positioner Split-Range Operation 26

3.5 Changing Valve Positioner Action 27

Section 4: Calibration Of Valve Positioner

4.1 Beam Alignment 28

4.2 Calibration 30

Section 5: Principle of Operation

5.1 3582 Valve Positioners 32

5.2 3582i Valve Positioner 32

Section 6: Maintenance..... 34

6.1 Changing the Range Spring 35

6.2 Replacing Gaskets 36

6.3 Replacing the Nozzle O-Ring..... 36

6.4 Replacing the Relay 37

6.5 Adjusting the Flapper Pivot 37

6.6 Replacing the 582i Converter Primary O-ring and Filter 37

6.7 Replacing the 582i Converter Housing Cap O-ring 38

6.8 Removing the 582i Converter..... 38

6.9 Reassembling the 582i Converter..... 39

Section 7: Parts

7.1 Parts Ordering..... 40

7.2 Parts Kits..... 40

7.3 Parts List 41

Section 1: Introduction

1.1 Scope of the Manual


This instruction manual includes installation, operation, calibration, maintenance and parts ordering information for Fisher 3582 pneumatic valve positioners and the 3582i electro-pneumatic valve positioner. Refer to separate instruction manuals for information on the control valve, actuator and accessories.

WARNING



Do not install, operate or maintain a 3582 pneumatic valve positioner or a 3582i electro-pneumatic valve positioner without being fully trained and qualified in valve, actuator and accessory installation, operation and maintenance. To avoid personal injury or property damage it is important to carefully read, understand and follow all of the contents of this manual, including all safety cautions and warnings. If you have any questions about these instructions, contact your [Emerson sales office](#) before proceeding.

Figure 1. Typical Mounting for Fisher 3582 and 3582i Positioners



1.2 Description

3582 pneumatic valve positioners and the 3582i electro-pneumatic valve positioner shown in Figure 1 are used with diaphragm-actuated, sliding-stem control valve assemblies. The pneumatic valve positioners receive a pneumatic input signal from a control device and modulate the supply pressure to the control valve actuator. The positioner adjusts the actuator supply pressure to maintain a valve stem position proportional to the pneumatic input signal.

3582NS positioners are designed for nuclear power applications. The 3582NS construction includes materials that provide superior performance at elevated temperature and radiation levels. The O-rings are EPDM (ethylene propylene) and the diaphragms are EPDM/meta-aramid fabric. EPDM demonstrates superior temperature capability and shelf life over nitrile. The meta-aramid diaphragm fabric demonstrates improved strength retention at elevated temperature and radiation conditions.

NOTICE

Use a clean, dry, oil-free air supply with instruments containing EPDM components. EPDM is subject to degradation when exposed to petroleum-based lubricants.

Under the 10CFR50, Appendix B, quality assurance program, the 3582NS positioner is qualified commercial grade dedicated. These can be supplied as 10CFR, Part 21 items.

The 3582i is an electro-pneumatic valve positioner, consisting of a 582i electro-pneumatic converter installed on a 3582 pneumatic valve positioner. The 3582i valve positioner provides an accurate valve stem position that is proportional to a DC current input signal.

The 582i electro-pneumatic converter is a modular unit that can be installed at the factory or in the field. However, do not install a 582i converter on an existing positioner until you contact your [Emerson sales office](#) for application assistance.

The 582i converter receives the DC current input signal and, through a nozzle/flapper arrangement, provides a proportional pneumatic output signal. This pneumatic output signal provides the input signal to the pneumatic valve positioner, eliminating the need for a remote-mounted transducer.

Refer to the type number description for a detailed explanation of type numbers.

Table 1. Specifications for Fisher 3582 and 3582i Valve Positioners

Note: Specifications for 3582 positioners include 3582A, 3582C, 3582D, 3582G and 3582NS unless otherwise indicated.	
Available Configurations	Supply Pressure⁽¹⁾ (continued)
Refer to Type Number Descriptions on page 6.	Per ISO 8573-1 Maximum particle density size: Class 7 Oil content: Class 3 Pressure Dew Point: Class 3 Note: The 3582i is not approved for use with natural gas as the supply medium
Input Signal	
3582 ■ 0.2 to 1.0 bar / 3 to 15 psig, ■ 0.4 to 2.0 bar / 6 to 30 psig or ■ split range, see Table 5 3582i 4 to 20 mA DC constant current with 30 V DC maximum compliance voltage, can be split range, see Table 5	
Equivalent Circuit for 3582i	Input Bellows Pressure Rating⁽¹⁾
The 582i converter equivalent circuit is 120 ohms, shunted by three 5.6-V zener diodes (see Figure 10)	See Table 4 for minimum and maximum pressure ratings (allowable input signal) for each available range spring.
Output Signal	Maximum Steady-State Air Consumption⁽²⁾
Type: Pneumatic pressure as required by actuator up to 95% of maximum supply Action: Field-reversible between ■ direct and ■ reverse within the pneumatic valve positioner	3582 1.4 bar / 20 psig Supply: 0.38 normal m ³ /hr / 14.0 scfh 2.0 bar / 30 psig Supply: 0.48 normal m ³ /hr / 18.0 scfh 2.4 bar / 35 psig Supply: 0.54 normal m ³ /hr / 20.0 scfh 3582i 1.4 bar / 20 psig Supply: 0.46 normal m ³ /hr / 17.2 scfh 2.0 bar / 30 psig Supply: 0.57 normal m ³ /hr / 21.4 scfh 2.4 bar / 35 psig Supply: 0.64 normal m ³ /hr / 23.8 scfh
Supply Pressure⁽¹⁾	
Recommended: 0.3 bar / 5 psi above actuator requirement Maximum: 3.4 bar / 50 psig or pressure rating of actuator, whichever is lower Supply Medium: Air or Natural Gas Supply medium must be clean, dry and noncorrosive Per ISA Standard 7.0.01 A maximum 40 micrometer particle size in the air system is acceptable. Further filtration down to 5 micrometer particle size is recommended. Lubricant content is not to exceed 1 ppm weight (w/w) or volume (v/v) basis. Condensation in the air supply should be minimized. Pressure Dew Point: at least 10°C less than the lowest ambient temperature expected	

-continued-

Table 1. Specifications for Fisher 3582 and 3582i Valve Positioners (continued)

Maximum Supply Air Demand	Operative Temperature Limits ⁽¹⁾
1.4 bar / 20 psig Supply: 4.4 normal m ³ /hr / 164.5 scfh 2.0 bar / 30 psig Supply: 6.7 normal m ³ /hr / 248.5 scfh 2.4 bar / 35 psig Supply: 7.7 normal m ³ /hr / 285.5 scfh	Standard Construction 3582 and 3582i: -40 to +71 °C / -40 to +160 °F 3582NS: -40 to +82 °C / -40 to +180 °F with EPDM elastomers High-Temperature Construction 3582A and C only: -18 to +104 °C / 0 to +220 °F without gauges
Performance	Hazardous Area Approvals and Other Certifications for 582i
3582 Independent Linearity: ±1% of output signal span Hysteresis: 0.5% of span 3582i Independent Linearity: ±2% of output signal span Hysteresis: 0.6% of span Electromagnetic Compatibility for 582i electro-pneumatic converter Meets EN 61326-1:2013 Immunity—Industrial locations per Table 2 of the EN 61326-1 standard. Performance is shown in Table 2. Emissions—Class A ISM equipment rating: Group 1, Class A Note: The electromagnetic compatibility specifications also apply to the 3582i. 3582 and 3582i Typical Open Loop Gain (Output Signal): ■ 100 in the range of 0.2 to 1.0 bar / 3 to 15 psig ■ 55 in the range of 0.4 to 2.0 bar / 6 to 30 psig 3582 and 3582i Typical Open Loop Gain (Output Signal): ■ 100 in the range of 0.2 to 1.0 bar / 3 to 15 psig ■ 55 in the range of 0.4 to 2.0 bar / 6 to 30 psig	CSA: Intrinsically Safe, Explosion proof, Type n, Dust-Ignition proof, DIV 2 FM: Intrinsically Safe, Explosion proof, Type n, Non-incendive, Dust-Ignition proof ATEX: Intrinsically Safe, Flameproof, Type n IECEx: Intrinsically Safe, Increased safety, Flameproof (Gas Atmospheres Only) CUTR: Customs Union Technical Regulations INMETRO: National Institute of Metrology, Quality and Technology (Brazil) KTL: Korea Testing Laboratory (South Korea) CCC: China Compulsory Compliance NEPSI: National Supervision and Inspection Centre for Explosion Protection and Safety of Instrumentation (China) PESO CCOE - Petroleum and Explosives Safety Organization - Chief Controller of Explosives (India) UKEx—Intrinsically Safe, Flameproof, Type n (United Kingdom) Note: These classifications also apply to the 3582i positioner. Contact your Emerson sales office for classification/ certification specific information.
Operating Influences	
Supply Pressure - 3582: Valve travel changes less than 1.67% per bar / 0.25% per 2 psi change in supply pressure. Supply Pressure - 3582i: Valve travel changes less than 3.62% per bar / 1.5% per 2 psi change in supply pressure.	

-continued-

Table 1. Specifications for Fisher 3582 and 3582i Valve Positioners (continued)

Housing Classification for 582i	Maximum Valve Stem Travel
CSA: Type 3 Encl. FM: NEMA 3, IP54 ATEX: IP64 IECEX: IP54 Mount instrument with vent on the side or bottom if weatherproofing is a concern Note: These classifications also apply to the 3582i positioner	105 mm / 4.125 in.; adjustable to obtain lesser travels with standard input signals
Hazardous Area Classification for 3582	Characterized Cams
3582 valve positioners comply with the requirements of ATEX/UKEx Group II Category 2 Gas and Dust. CE  II 2 G D Ex h IIC Tx Gb Ex h IIIC Tx Db Maximum surface temperature (Tx) depends on operating conditions. Gas: T4, T5, T6 Dust: T85... T104 Note: This rating does not apply to the 3582i	See characterized cams section.
	Approximate Weight
	3582: 2.5 kg / 5.5 lbs 3582i: 3.6 kg / 8 lbs
Pressure Gauges	Declaration of SEP
40 mm / 1.5 in. diameter with plastic case and brass connection ■ triple scale (PSI, MPa and bar) or ■ dual scale (PSI and kg/cm²)	Fisher Controls International LLC declares this product to be in compliance with Article 4 paragraph 3 of the PED Directive 2014/68/EU and Part 1, Requirement 8 of the PESR Regulation. It was designed and manufactured in accordance with Sound Engineering Practice (SEP) and cannot bear the CE marking related to PED compliance or the UKCA mark related to the PESR Regulation.
Pressure Connections	However, the product may bear the CE or UKCA marking to indicate compliance with other applicable European Community Directives or UK Regulations (Statutory Instruments).
1/4-18 NPT	
Electrical Connection for 3582i	
1/2-14 NPT conduit connection	
NOTE: Specialized instrument terms are defined in ANSI/ISA Standard 51.1 - Process Instrument Terminology. 1. The pressure and temperature limits in this document and any applicable standard or code limitation should not be exceeded. 2. Normal m³/hr—normal cubic meters per hour (0 °C and 1.01325 bar, absolute); Scfh—Standard cubic feet per hour / 60 °F and 14.7 psia.	

Table 2. Fisher 582i Electro-Pneumatic Converter⁽¹⁾ EMC Summary Results—Immunity

Port	Phenomenon	Basic Standard	Test Level	Performance Criteria ⁽²⁾
Enclosure	Electrostatic Discharge (ESD)	IEC 61000-4-2	4 kV contact 8 kV air	A
	Radiated EM field	IEC 61000-4-3	80 to 1000 MHz at 10 V/m with 1 kHz AM at 80% 1400 to 2000 MHz at 3 V/m with 1 kHz AM at 80% 2000 to 2700 MHz at 1 V/m with 1 kHz AM at 80%	A
	Rated power frequency magnetic field	IEC 61000-4-8	60 A/m at 50 Hz	A
I/O signal/con- trol	Burst (fast transients)	IEC 61000-4-4	1 kV	A
	Surge	IEC 61000-4-5	1 kV (line to ground only, each)	B
	Conducted RF	IEC 61000-4-6	150 kHz to 80 MHz at 3 Vrms	A
Specification limit = $\pm 1\%$ of span 1. The information contained in the table also applies to the 3582i positioner. 2. A = No degradation during testing. B = Temporary degradation during testing, but is self-recovering.				

Type Number Descriptions

The Fisher 3582 series of positioners include the models listed below.

The following descriptions provide specific information on the different valve positioner constructions. If the type number is not known, refer to the nameplate on the positioner. For the location of the nameplate, refer to key 25 in Figure 20.

3582—Pneumatic valve positioner with bypass and instrument, supply and output pressure gauges.

3582A—Pneumatic valve positioner without bypass and without pressure gauges.

3582C—Pneumatic valve positioner without bypass and with automotive tire valves instead of pressure gauges.

3582D—Pneumatic valve positioner with bypass and with automotive tire valves instead of pressure gauges.

3582G—Pneumatic valve positioner without bypass and with instrument, supply and output pressure gauges.

3582NS—Pneumatic valve positioner for nuclear service applications with or without bypass and with automotive tire valves instead of pressure gauges.

3582i—Electro-pneumatic valve positioner without bypass; with 582i converter; and with: supply and output pressure gauges, automotive tire valves or pipe plugs.

582i—Electro-pneumatic converter with: supply and output pressure gauges, automotive tire valves or pipe plugs. Used for conversion of a 4 to 20 mA input signal to a 0.2 to 1.0 bar / 3 to 15 psig input signal for the pneumatic valve positioner.

1.3 Specifications

Specifications for the valve positioners are shown in Table 1.

Refer to the unit nameplate to determine the type of positioner, supply pressure, etc.

WARNING

This product is intended for a specific current range, temperature range and other application specifications. Applying different current, temperature and other service conditions could result in malfunction of the product, property damage or personal injury.

1.4 Education Services

Emerson Educational Services
Phone: +1-800-338-8158
e-mail: education@emerson.com
emerson.com/mytraining

Section 2: Installation

If using natural gas as the pneumatic supply medium, natural gas will be used in the pressure connections of the unit to any connected equipment. The unit will vent natural gas into the surrounding atmosphere, unless it is remote vented.

NOTE

All valve positioners are shipped with packing material inside the case. Remove the cover (key 33, Figure 20) and the packing material before attempting to operate the unit. Make sure all vent openings are clear before installation of the unit and that they remain clear during use.

WARNING

Always wear protective clothing, gloves and eyewear when performing any installation operations to avoid personal injury.

If installing into an existing application, also refer to the **WARNING** at the beginning of the Maintenance section in this instruction manual.

Check with your process or safety engineer for any additional measures that must be taken to protect against process media.

WARNING

Personal injury or property damage may result from fire or explosion if natural gas is used as the supply medium and appropriate preventive measures are not taken. Preventive measures may include, but are not limited to, one or more of the following: Remote venting of the unit, re-evaluating the hazardous area classification, ensuring adequate ventilation and the removal of any ignition sources.

3582i does not meet third party approvals for use with natural gas as the supply medium. Use of natural gas as the supply medium can result in personal injury or property damage from fire or explosion.

NOTICE

Do not use sealing tape on pneumatic connections. This instrument contains small passages that may become obstructed by detached sealing tape. Thread sealant paste should be used to seal and lubricate pneumatic threaded connections.

Typically, the positioner is ordered with the actuator. If so, the factory mounts the valve positioner and connects the valve positioner output to the actuator. If a Fisher 67CFR filter-regulator is specified, it may be integrally mounted to the valve positioner, except for the 3582NS positioner. For the 3582NS, the 67CFR is separately mounted, not integrally mounted to the positioner.

NOTE

In some cases, alignment and calibration of the valve positioner at the factory may not be possible and field alignment and calibration is required. Before putting the valve positioner into service, check the operation of the unit to be sure it is calibrated. If the valve positioner requires alignment or calibration, refer to the appropriate calibration instructions in this manual.

If the valve positioner is ordered separately, disconnected or removed from the actuator, refer to the appropriate sections of this manual for installation information.

2.1 Hazardous Area Classifications and Special Instructions for “Safe Use” and Installation in Hazardous Locations for 582i Electro-Pneumatic Converter

Refer to the following instruction manual supplements for approval information.

- CSA Hazardous Area Approvals - Fisher 582i Electro-Pneumatic Converter ([D104319X012](#))
- FM Hazardous Area Approvals - Fisher 582i Electro-Pneumatic Converter ([D104320X012](#))
- ATEX Hazardous Area Approvals - Fisher 582i Electro-Pneumatic Converter ([D104321X012](#))
- IECEx Hazardous Area Approvals - Fisher 582i Electro-Pneumatic Converter ([D104322X012](#))

All documents are available from your Emerson sales office or Fisher.com. Contact your [Emerson sales office](#) for all other approval/certification information.


2.2 Mounting

Key numbers used in this procedure are shown in Figure 2 except where indicated.

- Figure 2 shows the various mounting parts required for mounting on Fisher actuators. Mounting parts for actuators that require spacers have the spacers (key 50) included. 657 and 667 actuators, sizes 70 through 100, with or without a side-mounted handwheel, use spacers (keys 97 and 102) between the stem connector and the connector arm (key 48). On all other actuators that use spacers, place the spacers (key 50) between the mounting plate (key 63) and the actuator mounting boss.

When mounting the valve positioner on an actuator by another manufacturer, provide spacers, if necessary, by cutting sections from 1/2 or 3/8-in. pipe so that the "X" dimension matches the value given in Figure 3.

Figure 2. Mounting Assembly



2. As shown in Figures 2 and 4, attach the connector arm (key 48) to the stem connector so that the connector arm extends through the yoke legs on the side of the lower mounting boss.
3. Attach the valve positioner to the mounting plate (key 63) using the holes shown in Figure 5.
4. Mount the 67CFR regulator:
 - 3582 valve positioners (except 3582NS), mount the regulator on the integral boss on the bypass block.
 - 3582NS valve positioners, use the mounting plate with provision for separately mounting the 67CFR regulator. Separately mount the positioner and the regulator on the mounting plate.
 - 3582i valve positioners, mount the regulator on the integral boss that is part of the 582i converter housing.
5. As shown in Figure 5, the mounting bracket has four sets of holes for mounting the assembly to the actuator. Refer to Table 3 to determine which set of mounting holes to use, then attach the assembly to the lower mounting pad on the actuator.

NOTICE

To avoid equipment damage, be certain the connector arm clears the valve positioner case as the actuator moves through its complete stroke.

6. Position the actuator to its mid-travel position using a handwheel or manual loading regulator.
7. Slip the round end of the travel pin (key 60) into the rotary shaft arm (key 2) slot as shown in Figure 4.
8. Slide the square end of the travel pin into the pin holder and pin lock (keys 61 and 59). Place the pin lock and holder into the slot in the connector arm (key 48). Screw the cap nut (key 62) onto the pin lock (key 59), but do not tighten.
9. With the actuator at its mid-travel position, lift the rotary shaft arm so that the 0-degree index marks on the rotary shaft arm are aligned with the case index marks as shown in Figure 6.

NOTICE

Never set the travel pin at a setting that is less than the actual actuator stroke. Setting the travel pin at a setting that is less than the actual actuator stroke will cause the cam to rotate more than 60 degrees, causing damage to the cam or other parts.


10. Position the travel pin so that it is perpendicular to the connector arm and aligns with the correct actuator stem travel index on the rotary shaft arm. Tighten the cap nut to a torque of 10.6 N•m / 94 in•lbf (key 62 in Figure 4).

11. Check the travel pin setting using the following procedures:

- **For standard travel pin setting** (that is, with the travel pin setting equal to total actuator travel). Stroke the actuator to each end of its travel. At each end of travel, the 30-degree index marks on the rotary shaft arm should align with the case index marks. If the index marks are not in line, loosen the cap nut (key 62) and slide the travel pin (key 60) in the rotary shaft arm slot until the 30-degree index marks align with the case index marks. Be sure the travel pin remains perpendicular to the connector arm. After making this adjustment, tighten the cap nut and re-check the arm at the mid-travel position. If the 0-degree index marks do not align, repeat this procedure.
- **For special travel pin setting** (that is, with the travel pin setting greater than total actuator travel). Check the index marks using a procedure similar to the standard settings procedure. The arm will not rotate a full 60° as the actuator is stroked and the 30-degree index marks on the cam will be short of aligning with the case index marks. If necessary, adjust the travel pin position so that the 30-degree marks are the same distance from the respective case index mark at each end of actuator travel.

Figure 3. Spacing for Mounting on Other than Fisher Actuators

STEM TRAVEL	X		
	9.5 mm / 0.375 In. Stem	12.7 mm / 0.5 In. Stem	19.1 mm / 0.75 In. Stem
Millimeters			
29 or less	81	87	100
38	90	97	109
51	102	108	121
64	113	119	132
76	124	130	143
89	135	141	154
102	146	152	165
Inches			
1.125 or less	3.19	3.44	3.94
1.5	3.56	3.81	4.31
2	4.00	4.25	4.75
2.5	4.44	4.69	5.19
3	4.88	5.12	5.62
3.5	5.31	5.56	6.06
4	5.75	6.00	6.50



11B6520-F

Figure 4. Isometric View Showing Motion Feedback Arrangement and Typical Stem Connection




Figure 5. Mounting Plates Used with Fisher 3582 Valve Positioners





Figure 6. Rotary Shaft Arm and Case Index Marks



NOTES:

1. MAXIMUM ROTATION FROM MID-TRAVEL POSITION.
2. ALIGN INDEX MARKS AS SHOWN FOR MID-TRAVEL POSITION.

Table 3. Fisher 3582 Mounting Information

ACTUATOR		MAXIMUM TRAVEL		MOUNTING HOLES SET NO. ⁽¹⁾	TRAVEL PIN POSITION ²⁾	ACTUATOR		MAXIMUM TRAVEL		MOUNTING HOLES SET NO. ⁽¹⁾		TRAVEL PIN POSITION ²⁾	
Type	Size	mm	in.			Type	Size	mm	in.	657	667		
513 and 513R	20 32	19 19	0.75 0.75	2 2	Normal Normal	657 and 667 Without Side-Mounted Handwheel	30 34 40	19 19 38	0.75 1.125 1.5	3 3 2	4 2 3	Normal Normal Normal	
656	30 40 60	51 89 102	2 3.5 4	4 4 4	Inverted Inverted Inverted		45 45 50 60	19 51 51 51	0.75 2 2 2	1 1 1 1	4 1 2 2	Inverted ⁽³⁾ Normal Normal Normal	
	657-4 Without Side-Mounted Handwheel	70	102	4	3		Inverted	70	51 52 to 76 78 to 102	2 2.0625-3 3.0625-4	2 3 3	1 2 1	Normal Normal Inverted ⁽⁴⁾
	657-4 With Side-Mounted Handwheel	70 87	102 102	4 4	2 1		Inverted Inverted	80	76	3	2	2	Normal
657-8	30 34 40 40	54 54 79 89	2.125 2.125 3.125 3.5	3 3 3 3	Normal Normal Normal Normal		87	51 52 to 76 78 to 102	2 2.0625-3 3.0625-4	2 2 3	2 2 1	Normal Normal Inverted ⁽⁴⁾	
	46 46 47	79 105 79	3.125 4.125 3.125	2 2 2	Normal Normal Inverted								
	47 60 70	105 105 105	4.125 4.125 4.125	1 4 2	Inverted Inverted Inverted								
	667-4 Without Side-Mounted Handwheel	70 87	102 102	4 4	1 1		Normal Normal	657 and 667 With Side-Mounted Handwheel	34 40 45	19 38 51	0.75 1.5 2	2 1 1	2 2 4
						50 60 70 80			51 51 102 76	2 2 4 3	4 3 2 2	1 1 2 2	Inverted ⁽⁴⁾ Inverted ⁽⁴⁾ Inverted Normal
						87			76 78 to 102	3 3.0625-4	2 2	2 1	Normal Inverted

1. The indicated set number should be considered a reference point only, due to the variables related to making up the stem connection.

2. Normal position is shown in Figure 4.

3. Travel pin position for 657 is normal.

4. Travel pin position for 667 is normal.

1. The indicated set number should be considered a reference point only, due to the variables related to making up the stem connection.
2. Normal position is shown in Figure 4.
3. Travel pin position for 657 is normal.
4. Travel pin position for 667 is normal.

2.3 Changing Cam Position

Refer to Figure 20 for a typical cam illustration and key number locations.

NOTE

The small arrow on the cam must point in the direction of stem movement with increasing actuator diaphragm pressure.

If the arrow is pointing in the wrong direction, use the following procedure to remove, reverse and re-install the cam.

When mounting a valve positioner check to see if the correct cam (key 4) and cam position has been selected. To change the cam or cam position, unhook the extension spring (key 38) and remove the cam bolt and locking nut (keys 6 and 45). Remove the cam and spring retainer bracket (key 43).

To install the cam, screw the locking nut all the way onto the cam bolt. Attach the cam and spring retainer bracket to the shaft assembly with the cam bolt. Tighten the bolt to secure the cam. Then, tighten the locking nut against the spring retainer bracket. Hook the spring into the spring retainer bracket.

Details on cam characteristics can be found on page 21 in the cam information portion of the operating information section.

2.4 Pressure Connections

WARNING

Valve positioners are capable of providing full supply pressure to connected equipment. To avoid personal injury or equipment damage caused by parts bursting from system overpressure, make sure the supply pressure never exceeds the maximum safe working pressure of any connected equipment.

NOTICE

Do not use sealing tape on pneumatic connections. This instrument contains small passages that may become obstructed by detached sealing tape. Thread sealant paste should be used to seal and lubricate pneumatic threaded connections.

Pressure connections are shown in Figure 7. All pressure connections are 1/4 NPT internal. Use 3/8-in. tubing for all pressure connections. After making pressure connections, turn on the supply pressure and check all connections for leaks.


Supply Connection

⚠ WARNING

Personal injury or property damage may occur from an uncontrolled process if the supply medium is not clean, dry, oil-free air and noncorrosive gas. While use and regular maintenance of a filter that removes particles larger than 40 micrometers in diameter will suffice in most applications, check with an Emerson field office and industry instrument air quality standards for use with corrosive air or if you are unsure about the proper amount or method of air filtration or filter maintenance.

3582i does not meet third party approvals for use with natural gas as the supply medium. Use of natural gas as the supply medium can result in personal injury or property damage from fire or explosion.

Figure 7. Typical Dimensions and Connections



NOTICE

Use a clean, dry, oil-free air supply with instruments containing EPDM components. EPDM is subject to degradation when exposed to petroleum-based lubricants.

Supply pressure must be clean, dry, oil-free air or noncorrosive gas. Use a 67CFR filter regulator with standard 5 micrometer filter or equivalent, to filter and regulate supply air. Except for the 3582NS, the filter regulator can be mounted on the positioner. For the 3582NS the regulator can be mounted on the mounting plate with the positioner but not on the positioner. The supply pressure should be high enough to permit setting the regulator 0.3 bar / 5 psi above the upper limit of the appropriate pressure range, for example: 1.4 bar / 20 psig for a 0.2 to 1.0 bar / 3 to 15 psig range. However, do not exceed the maximum allowable supply pressure of 3.4 bar / 50 psig nor the pressure rating of any connected equipment.

Connect the nearest suitable supply source to the 1/4 NPT IN connection on the filter regulator (if furnished) or to the 1/4 NPT SUPPLY connection on the positioner block assembly.

Output Connection

A factory mounted valve positioner has the valve positioner output piped to the supply connection on the actuator. If mounting the valve positioner in the field, connect 3/8-in. tubing between the 1/4 NPT valve positioner connection marked OUTPUT and the actuator supply pressure connection.

Instrument Connection

For a 3582 pneumatic valve positioner connect 3/8-inch tubing from the control device to the 1/4 NPT INSTRUMENT connection. If the control device is mounted on the control valve assembly by the factory, this connection is made.


The 3582i electro-pneumatic valve positioner requires a 4 to 20 mA DC current input signal from the control device. A 1/2 NPT conduit connection is provided for properly wiring electrical installations. For more information, see the electrical connections section.

Diagnostic Connections

To support diagnostic testing of valve/actuator/positioner/accessory packages, special connectors and hardware are available. The hardware used includes 1/8 NPT connector bodies and body protectors. If the diagnostic connectors are ordered for a positioner with gauges, 1/8-in. stems are also included.

Install the connectors on the 3582 block assembly or 582i housing as shown in Figure 8. Before installing the connectors on the positioner, apply sealant to the threads. Sealant is provided with the diagnostic connections and hardware.

Figure 8. Diagnostic Connections



2.5 Vent

⚠ WARNING

Personal injury or property damage could result from fire or explosion of accumulated gas if a flammable gas is used as the supply pressure medium and the positioner actuator is in an enclosed area. The positioner/actuator assembly does not form a gas-tight seal and when the assembly is enclosed, a remote vent line, adequate ventilation and necessary safety measures should be used. For leakage rates, see the Maximum Steady-State Air Consumption specification. A remote vent pipe alone cannot be relied upon to remove all hazardous gas. Vent line piping should comply with local and regional codes and should be as short as possible with adequate inside diameter and few bends to reduce case pressure buildup.

⚠ WARNING

3582i does not meet third party approvals for use with natural gas as the supply medium. Use of natural gas as the supply medium can result in personal injury or property damage from fire or explosion.

NOTICE

When installing a remote vent pipe, take care not to overtighten the pipe in the vent connection. Excessive torque will damage the threads in the connection.

The vent opening at the back of the case marked VENT should be left open to prevent pressure buildup inside the case and to provide a drain hole for any moisture that might collect inside the case. The perforated section of the nameplate normally covers this opening to prevent blockage from debris or insects. Also, ensure the exhaust holes in the relay (key 32 in Figure 20) are kept open.

If a remote vent is required, the vent line must be as short as possible with a minimum number of bends and elbows. The vent connection is 3/8 NPT internal. Use 3/8-in. or larger tubing to provide a remote vent. The 582i has a 1/4 NPT internal vent connection. Use optional remote vent 83L relay for remote vent applications.

2.6 Electrical Connections for 3582i Valve Positioner

WARNING

For explosion-proof applications, disconnect power before removing the converter housing cap.

For Class I, Division 1 explosion-proof applications, install rigid metal conduit and a conduit seal no more than 457 mm / 18 in. from the converter. Personal injury or property damage might result from explosion if the seal is not installed.

For intrinsically safe installations, refer to the loop schematics included in the appropriate Hazardous Area Approval Supplement (CSA, [D104319X012](#) or FM, [D104320X012](#)), factory drawings or to instructions provided by the barrier manufacturer for proper wiring and installation.


Select wiring and/or cable glands that are rated for the environment of use (such as hazardous area, ingress protection and temperature). Failure to use properly rated wiring and/or cable glands can result in personal injury or property damage from fire or explosion.

Wiring connections must be in accordance with local, regional and national codes for any given hazardous area approval. Failure to follow the local, regional and national codes could result in personal injury or property damage from fire or explosion.

Use the 1/2-14 NPT conduit connection on the 582i converter housing for installation of field wiring. For Class I, Division I explosion-proof applications, install rigid metal conduit and a seal no more than 457 mm / 18 in. from the converter. Also, install conduit according to local and national electrical codes which apply to the application.

Refer to Figures 9, 10 and 11 when connecting field wiring from the control device to the converter. Connect the positive wire from the control device to the converter positive (+) terminal and the negative wire from the control device to the converter negative (-) terminal. Do not overtighten the terminal screws. Maximum torque is 0.45 N·m / 4 lbf·in. Connect the converter grounding terminal to an earth ground.

Figure 9. Typical Field Wiring Diagram



NOTE:

1. FOR TROUBLESHOOTING OR MONITORING OPERATION, AN INDICATING DEVICE CAN BE A VOLTMETER ACROSS A 250Ω RESISTOR OR A CURRENT METER.

Figure 10. Input Equivalent Circuit for Fisher 582i Converter





Figure 11. Wiring Connections for Fisher 582i Converter

A7140

2.7 582i Converter Installation

NOTE

Contact your [Emerson sales office](#) for application information before upgrading an existing 3582 valve positioner by field installation of a 582i electro-pneumatic converter.

⚠ WARNING

Avoid personal injury from sudden release of process pressure. Before mounting the 582i converter:

- Always wear protective clothing, gloves and eyewear when performing any maintenance operations.
- Do not remove the actuator from the valve while the valve is still pressurized.
- Disconnect any operating lines providing air pressure or a control signal to the actuator. Be sure the actuator cannot suddenly open or close the valve.
- Use bypass valves or completely shut off the process to isolate the valve from process pressure. Relieve process pressure on both sides of the valve.
- Vent actuator loading pressure.
- Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.
- Do not open when an explosive dust atmosphere is present.
- Check with your process or safety engineer for any additional measures that must be taken to protect against process media.

NOTE

Before planning to retrofit an installed 3582 positioner, refer to the positioner mounting plate illustrations shown in Figure 5. Mounting plates with a three-hole mounting pattern (positioner to mounting plate) cannot support a 582i converter. Do not attempt to mount a 582i converter on an existing 3582 positioner which has a three-hole mounting pattern.

Isolate the control valve from the line pressure and release pressure from both sides of the valve body. Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.

If a 3582 pneumatic valve positioner has previously been installed using a mounting plate with a five-hole mounting pattern (positioner to mounting plate), either at the factory or in the field, it can be upgraded to a 3582i electro-pneumatic valve positioner by installation of a 582i converter. To install a 582i converter, refer to the following instructions.

NOTE

Inspect the existing valve positioner to determine the input signal range. If the input signal range is not 0.2 to 1.0 bar / 3 to 15 psig, refer to the appropriate sections of this manual describing input signal ranges and how to change the range spring.

1. Inspect the positioner mounting plate. Be certain that five screws fasten the positioner to the mounting plate. Two additional screws fasten the plate to the actuator. When the positioner is correctly attached to the mounting plate, proceed with the installation by taking the control valve/actuator/positioner package out of service.
2. Properly vent the actuator loading pressure and the supply pressure. Disconnect the pressure tubing connections to the valve positioner.
3. Remove the two screws (key 105 in Figure 23 or 24) holding the bypass block (key 34A in Figure 23 or 24) to the valve positioner case and remove the bypass block. Save the screws to reattach the 582i converter.
4. Remove and discard the existing gasket (key 104 in Figure 23 or 24) between the bypass block and valve positioner case.
5. Unpack the 582i converter to be installed.
6. Position the new gasket on the 582i converter as shown in Figure 25. Insert the existing screws (key 105 in Figure 23 or 24) through the appropriate holes in the 582i converter housing and new gasket.
7. Mate the converter and new gasket to the side of the valve positioner case using the alignment pins on the converter housing.
8. Tighten the screws.
9. Reconnect the pressure connections according to the instructions given in the pressure connections section of this manual.
10. Make the electrical connections according to the instructions given in the electrical connections section of this manual.
11. Complete the standard calibration procedure described in the calibration section of this manual.
12. Return the control valve package to service.

Section 3: Operating Information

Instructions for setting the zero and span are found in the calibration section.

3.1 Valve Positioner Cam Information

NOTE


The small arrow on the valve positioner cam must point in the direction of stem movement with increasing actuator diaphragm pressure. If the arrow is pointing in the wrong direction, remove, reverse and re-install the cam. Refer to the Changing Cam Position section of this manual.

Refer to Figure 20 for key number locations. Unhook the spring (key 38) and remove the cam bolt and locking nut (keys 6 and 45). Remove the cam (key 4) and spring retainer bracket (key 43). To install the cam, screw the locking nut all the way onto the cam bolt. Attach the cam and spring retainer bracket with the cam bolt. Tighten the bolt to secure the cam. Then, tighten the locking nut against the spring retainer bracket. Hook the spring into the spring retainer bracket.

When shipped from the factory, 3582 valve positioners and the 3582i valve positioner have a linear cam, Cam A, installed in the operating position. Two characterized cams, Cams B and C, are available. These characterized cams may be used to modify the valve flow characteristics.


Figure 12 shows resultant stem travel due to an incremental instrument pressure change for each cam. In Figure 12, the curves are based on 60° cam rotation for 100% stem travel. At 50% of the input signal span, for example, the stem will travel 50% with cam A, 68% with cam B and 32% with cam C. Figure 13 shows how the flow characteristics change when using the cams with a valve that has equal percentage characteristics. Figure 14 shows how the flow characteristics change when using the cams with a valve that has linear characteristics.

Figure 12. Cam Characteristic Curves




CK4832-A

Figure 13. Flow Characteristics with Different Cams and Equal Percentage Valve Plug



CK4835-A

Figure 14. Flow Characteristics with Different Cams and Linear Valve Plug



CK4833-A

When cam A is the operating cam, there is a linear relationship between an incremental instrument pressure change and the resultant valve stem travel. The flow characteristic is that of the control valve. Installing either cam B or C as the operating cam changes the relationship between the incremental instrument pressure change and valve stem travel, thereby modifying the valve flow characteristic.

3.2 Valve Positioner Bypass Operation

3582 and 3582D valve positioners and 3582NS positioners with bypass, are supplied with a bypass assembly. A handle on the bypass assembly permits selecting positioner or bypass operation. Refer to Figure 23 for key number locations.

WARNING

To avoid personal injury and property damage, do not use bypass operation when the valve positioner is reverse-acting or is in split-range operation. In these cases, bypassing the valve positioner sends the input signal directly to the actuator which may cause the valve to move in an unexpected direction and upset process control. Use bypass only when the input signal range is the same as the valve positioner output range required for normal actuator operation.

Labels on the bypass block (key 34A) and a pointer on the bypass handle (key 34D) indicate if the input signal from the instrument goes to the positioner or directly to the control valve actuator. Push the bypass handle toward the back of the positioner to move the pointer over the word POSITIONER. With the bypass handle in this position, the input signal goes to the valve positioner bellows and the output pressure of the valve positioner goes to the actuator. Pull the bypass handle forward to move the pointer over the word BYPASS. In this position, the input signal goes directly to the actuator.

NOTE

A difference between the input signal pressure and the valve positioner output pressure could cause a transient bump in the controlled system when the bypass handle is moved to BYPASS.

With a reverse-acting or split-range valve positioner, the bypass handle may be locked in the POSITIONER position so that bypass cannot be used. To lock the bypass handle in the POSITIONER position, first shut off the instrument and supply pressure to the valve positioner. Then, remove the hex head shoulder screw from the center of the handle. Remove the handle and rotate it 180° and re-install it with the handle between the two lugs cast on the bypass block. Replace the shoulder screw.

3.3 Input Signal Ranges

Standard input signal ranges for valve positioners are shown in Table 4. Changing from one standard range to another requires changing the range spring. To change the range spring, refer to the instructions for changing the range spring in the maintenance section of this manual. Split-range operation of 3582 valve positioners or the 3582i valve positioner normally does not require changing the spring. Refer to Section 3.4 below for split-range information.

Table 4. Standard Instrument Input Signals and Range Springs

INSTRUMENT INPUT SIGNAL RANGE	STANDARD SPAN	ALLOWABLE INPUT SIGNAL ⁽¹⁾		RANGE SPRING COLOR
		Minimum	Maximum	
0.2 to 1.0 bar / 3 to 15 psig	0.8 bar / 12 psig	0.07 bar / 1 psig	1.4 bar / 21 psig	Silver
4 to 20 mA ⁽²⁾	16 mA	2 mA	22 mA	
0.4 to 2.0 bar / 6 to 30 psig	1.6 bar / 24 psig	0.07 bar / 1 psig	2.4 bar / 35 psig	Red

1. Minimum and maximum allowable input signals ensure functional operation.
2. For 3582i only.

3.4 Valve Positioner Split-Range Operation

3582 valve positioners and the 3582i valve positioner are suitable for split-range operations. In split-range operation, the input signal, either pneumatic or DC current, from a single control device is split between two or more control valves. No additional parts are required to use an existing valve positioner for split-range operation.

Table 5 shows some typical split-ranges for the valve positioners.

Table 5. Split-Range Capabilities

3582 POSITIONERS				
Split	0.2 to 1.0 Bar or 3 to 15 Psig Input Signal		0.4 to 2.0 Bar or 6 to 30 Psig Input Signal	
	Bar	Psig	Bar	Psig
Two-way	0.2 to 0.6 0.6 to 1.0	3 to 9 9 to 15	0.4 to 1.2 1.2 to 2.0	6 to 18 18 to 30
Three-way	0.2 to 0.5 0.5 to 0.7 0.7 to 1.0	3 to 7 7 to 11 11 to 15	0.4 to 0.9 0.9 to 1.5 1.5 to 2.0	6 to 14 14 to 22 22 to 30
3582i POSITIONER				
Split	4 To 20 Milliampere Input Signal			
Two-way	4 to 12 12 to 20			
Three-way	4 to 9.3 9.3 to 14.7 14.7 to 20			

To change to split-range operation, perform the beam alignment procedures then perform the calibration procedure using the desired split range inputs that result in full valve travel. For example, for a 3582 positioner with a 0.2 to 1.0 bar / 3 to 15 psig input signal range in a two-way split, a 0.6 bar / 9 psig input signal should completely stroke the valve for a 0.2 to 0.6 bar / 3 to 9 psig signal range.

NOTE

The flapper must approach the nozzle squarely at the midpoint value of the input signal range for proper operation.

On some applications where the input signal span is comparatively small (as found with split-range applications), the nozzle adjustment may not be enough to set the proper starting point. Also, some difficulty may be experienced in keeping a valve positioner from unloading when the input signal continues to increase above the split-range.

For example, for a 0.2 to 0.6 bar / 3 to 9 psig input signal range, the input signal could increase to 1.0 bar / 15 psig. Continued bellows travel due to the increased input signal over the split-range would drive the flapper into the nozzle. The impact could possibly cause misalignment between the flapper and nozzle. Such a misalignment, in turn, could affect split-range calibration.

In these cases, adjust the flapper assembly screw in addition to the nozzle adjustment to obtain satisfactory results.


NOTE

3582 valve positioners require a relatively small percentage of the instrument pressure span to obtain full valve travel. With the travel pin set to equal the valve travel, the input signal change required to fully stroke the valve can be reduced to 33 percent of normal input signal change. With the travel pin set to a value greater than the valve travel, the input signal change required to fully stroke the valve can be reduced to a minimum of 20 percent of normal input signal change.

3.5 Changing Valve Positioner Action

Converting a 3582 valve positioner or 3582i valve positioner from direct-acting (an increasing input signal, either pneumatic or electrical, increases output pressure) to reverse-acting (increasing input signal decreases output pressure) or vice versa requires no additional parts. The position of the flapper assembly on the beam determines the action. As shown in Figure 15, the beam is divided into quadrants. The direct-acting quadrant of the beam is labeled DIRECT and the reverse-acting quadrant is labeled REVERSE. To change the positioner action, simply move the flapper assembly to the opposite quadrant of the beam. Perform the calibration procedures in the valve positioner Calibration section.

Figure 15. Partial View for Beam Leveling and Calibration



Section 4: Calibration Of Valve Positioner

The following beam alignment and calibration procedures are applicable for 3582 and 3582i valve positioners.

WARNING

During calibration, the valve may move. To avoid personal injury or property damage caused by the release of pressure or process fluid, provide some temporary means of control for the process.

4.1 Beam Alignment

NOTE

The beam is leveled at the factory prior to shipment. Once the beam is leveled, no additional leveling should be required unless the beam pivot pin or the bellows assembly pivot pin are changed, the bellows assembly or range spring are replaced or the valve positioner is changed to split range operation.

The purpose of beam alignment is to ensure the correct mechanical position of parts so the valve positioner can be calibrated. Provide the appropriate supply pressure. Also, provide an input signal to the positioner which can be manually set at the midpoint of the desired input signal range.

Refer to Figure 15 for parts locations. Refer to Figure 20 for key number locations unless otherwise indicated. Position the flapper assembly by hand to different settings on the beam assembly or by using a screwdriver in the slot of the flapper setting adjustment.

To level the beam, proceed as follows:

NOTE

In the following steps, if the required rotary shaft arm position cannot be attained when adjusting a pivot point, adjust one of the other pivot points slightly. Then, repeat the original pivot adjustment. Continue this process until the required arm position can be attained.

1. Stroke the actuator to its mid-travel position with a handwheel or a manual loader. Refer to Figures 4 and 6. Lift the rotary shaft arm (key 2) so that the 0-degree index marks on the rotary shaft arm align with the case index marks as shown in Figure 6. Then, position the travel pin (key 60) so that it is perpendicular to the arm and aligns with the appropriate total actuator travel index mark on the rotary shaft arm. Tighten the cap nut (key 62).

NOTE

Valve stem travels less than 29 mm / 1.125 in. require that the travel pin be set at the 1-1/8 in. travel index mark on the rotary shaft arm.

2. Loosen the nozzle locknut and turn the nozzle clockwise to its lowest position. Then screw the nozzle out (counterclockwise) approximately four turns and tighten the locknut.


NOTE

For proper operation, the flapper must approach the nozzle squarely. Inspect the nozzle/flapper alignment. Be sure the flapper is not loose, bent or twisted.

3. Remove any loading pressure and/or disengage any handwheel used to position the actuator. Connect the necessary tubing from the valve positioner output to the actuator pressure connection.
4. Connect the input to the valve positioner and set the input signal value at midrange. For example, for a 3582 valve positioner with a 0.2 to 1.0 bar / 3 to 15 psig input signal range, set the input signal at 0.6 bar / 9 psig. Then apply supply pressure to the valve positioner.
5. Move the flapper assembly to zero on the beam scale. The 0-degree index marks on the rotary shaft arm should align with the case index marks as shown in Figure 16. If not, loosen the flapper assembly screw locknut and adjust the flapper assembly screw until the 0-degree index marks on the rotary shaft arm align with the case index marks. Tighten the locknut.
6. Move the flapper assembly to position 10 on the direct-acting side of the beam scale. The 0-degree index marks on the rotary shaft arm should align with the case index marks as shown in Figure 16. If not, loosen the bellows assembly locknut and adjust the bellows pivot pin until the 0-degree index marks on the rotary shaft arm align with the case index marks. Tighten the locknut.

7. Move the flapper assembly to the left to position 10 on the reverse-acting side of the beam. The 0-degree index marks on the rotary shaft arm should align with the case index marks as shown in Figure 16. If not, loosen the beam pivot pin locknut and adjust the beam pivot pin until the 0-degree index marks on the rotary shaft arm align with the case index marks. Tighten the locknut.
8. Repeat steps 5, 6 and 7 to optimize alignment. Recheck to make sure the flapper approaches the nozzle squarely. If it does not, adjust the nozzle and re-level the beam. After alignment, the valve positioner is ready for calibration.

Figure 16. Rotary Shaft Arm 0-Degree and Case Index Marks, Location and Alignment



A2452-3

NOTE:

1. ALIGN INDEX MARKS AS SHOWN FOR MID-TRAVEL POSITION.

4.2 Calibration

⚠ WARNING

During calibration, the valve may move. To avoid personal injury or property damage caused by the release of pressure or process fluid, provide some temporary means of control for the process.

1. Shut off the supply pressure to the valve positioner. Connect or reconnect the necessary tubing from the valve positioner output to the actuator supply connection. Connect the input to the valve positioner and set the input signal value at midrange.

2. Move the flapper assembly to approximately position 6 in the proper operating quadrant of the beam (direct or reverse-acting) and apply supply pressure to the valve positioner. The 0-degree index marks on the rotary shaft arm should align with the case index marks as shown in Figure 16 and the actuator should be at its midtravel position. If not, first check for loose linkage or improper cam installation. A minor nozzle height adjustment might be necessary to make the desired input signal value correspond to the starting point of travel.
3. Apply an input signal equal to the low value of the input signal range. For example, for a 3582 valve positioner with a 0.2 to 1.0 bar / 3 to 15 psig input signal range, set the input signal at 0.2 bar / 3 psig. Loosen the nozzle locknut and adjust the nozzle until the actuator moves to the proper end of its travel. Changing the nozzle position is intended only as a means of zero trim adjustment. Whenever nozzle position is changed, the zero reference point is changed.
4. Apply an input signal equal to the high value of the input signal range and observe the actuator stem travel. If the stem travel is short of its expected range, increase the travel by moving the flapper assembly to a higher number on the beam. If the desired stem travel occurs before the input signal reaches the high value of the input signal range, decrease the travel by moving the flapper assembly toward a lower number on the beam.
5. Repeat steps 3 and 4 until the correct travel is achieved. Each time the flapper assembly position is changed in step 4, repeat step 3 to provide proper zero.

Moving the flapper assembly toward zero on the beam scale decreases stem travel. Table 6 lists the minimum stem travel available for different travel pin settings. For example, with a travel pin setting of 2 the minimum stem travel possible, for the full input signal range, would be 11 mm / 0.4375 in.

NOTE

The positioner will fully vent or pressurize the actuator to supply pressure at the ends of actuator travel when the positioner is calibrated correctly. Failure to properly calibrate the positioner may result in reduced seat loading.

Table 6. Minimum Travel with Given Pin Position

TRAVEL PIN POSITION ALONG ROTARY SHAFT ARM	MINIMUM TRAVEL AVAILABLE	
	mm	in.
1-1/8 1-1/2 2	1-1/8 1-1/2 2	0.25 0.3125 0.4375
2-1/2 3 4	13 16 22	0.5 0.625 0.875

Section 5: Principle of Operation

5.1 3582 Valve Positioners

The 3582 (3582, 3582NS and 3582A, C, D and G pneumatic valve positioners) accepts a pneumatic input signal from a control device. Figure 17 is an operational schematic for a direct-acting pneumatic valve positioner.

As shown in Figure 17, in a diaphragm-actuated, sliding stem control valve package with a 3582 valve positioner, supply pressure is connected to the 83L relay. A fixed restriction in the relay limits flow to the nozzle so that when the flapper is not restricting the nozzle, air can bleed out faster than it is being supplied.

The input signal from the control device is connected to the bellows. When the input signal increases, the bellows expands and moves the beam. The beam pivots about the input axis moving the flapper closer to the nozzle. The nozzle pressure increases and, through relay action, increases the output pressure to the actuator. The increased output pressure to the actuator causes the actuator stem to move downward. Stem movement is fed back to the beam by means of a cam. As the cam rotates, the beam pivots about the feedback axis to move the flapper slightly away from the nozzle. The nozzle pressure decreases and reduces the output pressure to the actuator. Stem movement continues, backing the flapper away from the nozzle, until equilibrium is reached.

When the input signal decreases, the bellows contracts (aided by an internal range spring) and the beam pivots about the input axis to move the flapper away from the nozzle. Nozzle pressure decreases and the relay permits the release of diaphragm casing pressure to atmosphere. The actuator stem moves upward. Through the cam, stem movement is fed back to the beam to reposition the flapper closer to the nozzle. When equilibrium conditions are obtained, stem movement stops and the flapper is positioned to prevent any further decrease in diaphragm case pressure.

The principle of operation for reverse-acting units is similar except that as the input signal increases, the diaphragm casing pressure is decreased. Conversely, a decreasing input signal causes an increase in the pressure to the diaphragm casing.

5.2 3582i Valve Positioner

As shown in Figure 18, the 3582i electro-pneumatic valve positioner has a 582i electro-pneumatic converter attached to the valve positioner. The 582i contains an I/P module which provides a pneumatic output proportional to a DC current input signal. The DC current input operates coils in a force balanced beam system which in turn, control bleed air through an integral nozzle/flapper arrangement. The nozzle pressure provides the pneumatic input signal pressure used by the pneumatic valve positioner.

Figure 17. Schematic Illustration of Fisher 3582 Positioner





Figure 18. Schematic Illustration of Fisher 3582i Positioner



Section 6: Maintenance

Due to normal wear or damage from external sources (such as debris in the supply medium), periodic maintenance or repair of the valve positioner may be necessary. Maintenance of these units consists of troubleshooting, removal for inspection and replacement of component parts.

WARNING

Avoid personal injury from sudden release of process pressure. Before performing any maintenance operations:

- Always wear protective clothing, gloves and eyewear when performing any maintenance operations.
- Do not remove the actuator from the valve while the valve is still pressurized.
- Disconnect any operating lines providing air pressure or a control signal to the actuator. Be sure the actuator cannot suddenly open or close the valve.
- When disconnecting any of the pneumatic connections, natural gas, if used as the supply medium, will seep from the unit and any connected equipment into the surrounding atmosphere. Personal injury or property damage may result from fire or explosion if appropriate preventive measures are not taken. Preventive measures may include, but are not limited to, one or more of the following: ensuring adequate ventilation and the removal of any ignition sources.
- Use bypass valves or completely shut off the process to isolate the valve from process pressure. Relieve process pressure on both sides of the valve.
- Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.
- Check with your process or safety engineer for any additional measures that must be taken to protect against process media.

WARNING

3582i does not meet third party approvals for use with natural gas as the supply medium. Use of natural gas as the supply medium can result in personal injury or property damage from fire or explosion.

WARNING

For explosion proof applications, disconnect power before removing the converter housing cap in an explosive atmosphere.

WARNING

When replacing components, use only components specified by Emerson. Substitution with other components may result in the positioner no longer meeting safety certification requirements and personal injury or property damage.

Always use proper component replacement techniques. Improper techniques and poor quality repairs can impair the safety features of the device. In case of operational difficulties, the valve positioner should first be checked to see that adjustments have been properly made. All pressure lines and connections should be checked for leaks.

The pneumatic relay and gaskets should also be inspected and replaced if necessary.

Instructions are given below for:

- changing the range spring;
- replacing gaskets, nozzle O-rings and relay;
- adjusting the flapper pivot;
- replacing the 582i converter primary O-ring and filter;
- replacing the 582i converter cover O-ring;
- removing the 582i converter; and
- reassembling the 582i converter.

6.1 Changing the Range Spring

Unless otherwise noted, key number locations are shown in Figure 20.

The range spring is inside the bellows assembly. Standard range spring data is given in Table 4. When an input signal range is split to operate two or more control valves, normally changing the range spring is not necessary. The input signal range for the range spring is stamped on the nameplate.

Perform the following procedure to change the range spring in a valve positioner.

1. Unhook the extension springs (keys 27, 77) from the beam (key 29).
2. Loosen and remove the two screws (key 13) and lock washers (key 12) that hold the bellows assembly (key 7) in place.
3. Lift out the beam and bellows assembly. Be careful not to lose the small O-ring (key 11).
4. Loosen the machine screw (key 10) and remove the range spring (key 8).
5. Install a new range spring, making sure the small end of the spring is against the spring seat (key 9). Replace the spring seat and tighten the screw.
6. If the O-ring (key 11) is worn or damaged, replace it with a new one after applying lubricant (key 94). Make sure the O-ring is in place, then install the bellows assembly, securing it with two mounting screws and lock washers.
7. Install the beam over the pivots and hook the springs to the beam.
8. Make any minor adjustments that may be necessary to re-level the beam as outlined in the beam alignment procedures of the valve positioners calibration section. After leveling the beam, calibrate the unit according to the appropriate calibration instructions.

6.2 Replacing Gaskets

Unless otherwise noted, key numbers used in this procedure are shown in Figures 23 and 24.

A gasket (key 34C) is located behind the bypass handle (key 34D).

1. Remove the screw (key 34G) and lift out the bypass handle or manifold.
2. Remove the gasket.
3. Apply lubricant (key 94) to both sides of the replacement gasket when used with the bypass assembly. Do not apply lubricant to the gasket when the bypass assembly is not used.
4. Set the new gasket in place on the four locating pins and replace the bypass handle or manifold.

The case gasket (key 104) is located between the case (key 1 in Figure 20) and the bypass block (key 34A) in a 3582 valve positioner or the housing of the 582i converter (key 1 in Figure 25).

5. Remove the two mounting screws (key 105 in Figures 23 and 24; key 11 in Figure 25) that hold the bypass block or converter housing to the case and remove the unit to expose the case gasket.
6. Install a new gasket and replace the bypass block or converter housing.

6.3 Replacing the Nozzle O-Ring

Unless otherwise noted, key numbers are shown in Figures 19 and 21.

1. Remove the two screws (key 19C) that hold the flapper and flapper assembly (keys 19B and 19G) to the adjustment arm (key 19A).

NOTICE

For proper operation, be careful not to bend or twist the flapper or nick the nozzle orifice during reassembly.

2. Carefully remove the flapper and flapper assembly for access to the nozzle (key 18 in Figure 20).
3. Loosen the locking nut (key 71) and unscrew the nozzle (key 18).
4. Remove the locking sleeve (key 72) from the nozzle adaptor (key 3). The nozzle adaptor is bonded to the positioner case with adhesive (key 96) and should not be removed.
5. Inspect the O-ring (key 73) on the nozzle adapter and replace the O-ring, if necessary. If replacing the O-ring, apply lubricant (key 94) to the O-ring before installing it on the nozzle adapter.
6. Reinstall the nozzle onto the nozzle adapter, leaving the locking nut loose.
7. Replace the flapper and flapper assembly. Make sure the letter "T" on the flapper is visible from the front of the positioner.
8. Perform the beam alignment and calibration procedures in the Calibration of Valve Positioner section.

6.4 Replacing the Relay

NOTE

The relay is not field repairable. If the relay is defective, replace the relay.

Use the following procedure to replace the relay assembly. Refer to Figure 20 for key number locations, unless otherwise noted.

1. For valve positioners using a bypass, direct action and a full-range input signal, place the positioner in bypass operation by moving the bypass handle to BYPASS. Then, shut off the supply pressure. For all other valve positioners isolate the control valve from the system and shut off all pressure lines.

NOTE

A difference between input and valve positioner output pressure could cause a transient bump in the controlled system when the bypass handle is moved to BYPASS.

2. Remove the 83L relay (key 32) from the back of the case by loosening the two mounting screws (key 10, Figure 22).
3. Reinstall the new relay assembly on the case, making sure the O-rings (keys 13 and 15, Figure 22) are in place. Secure with the two mounting screws (key 10, Figure 22).
4. Resume operation by moving the bypass handle to the POSITIONER position or by connecting the valve positioner and control valve to the system.

6.5 Adjusting the Flapper Pivot

Key numbers used in this procedure are shown in Figure 19.

1. Loosen the two screws (key 19C).
2. Tighten the pivot pin (key 19L) by compressing the upturned ears of the arm support (key 19K). Tighten the screws (key 19C) and make sure the flapper (key 19B) does not rub on the supports.
3. The flapper should be snug, but not constricting to pivot action.

6.6 Replacing the 582i Converter Primary O-ring and Filter

Key numbers used in this procedure are shown in Figure 25.

1. Locate and remove the nozzle restriction adaptor assembly (key 4).
2. Inspect and replace, if necessary, the O-rings (keys 5 and 6). Apply lubricant (key 15) to the O-ring before replacing.
3. Inspect and replace the filter cartridge (key 23).

6.7 Replacing the 582i Converter Housing Cap O-ring

Key numbers used in this procedure are shown in Figure 25.

1. Unscrew and remove the converter housing cap (key 2). Inspect and replace the O-ring (key 8), if necessary. Apply lubricant (key 15) to the O-ring before replacing.

6.8 Removing the 582i Converter

During the following converter removal procedures, refer to Figure 25 for key number locations.

NOTICE

The I/P module should never be disassembled because the magnetism in the coils will decrease permanently. If troubleshooting or alignment attempts indicate a faulty I/P module, replace the module or return the converter to your Emerson sales office for repair.

NOTE

To check the operation of the I/P module, remove the pipe plug (key 12) and connect a pressure gauge. Provide a 1.4 bar / 20 psig supply pressure to the converter. With a 4 mA signal the pressure output should read 0.16 to 0.24 bar / 2.3 to 3.5 psig. With a 20 mA input signal the pressure output should read 0.96 to 1.07 bar / 14.0 to 15.5 psig.

1. Turn off the input signal to the converter. Release all supply pressure from the valve positioner.
2. Remove the housing cap (key 2).
3. Note the location of the wires, disconnect the field wiring from the terminal block. Disconnect the grounding wire from the external ground screw (key 10).
4. To remove the I/P module, remove the two screws (key 9) and pull the module out of the housing. Inspect the O-ring (key 6) and replace it, if necessary. Apply lubricant (key 15) to the O-ring before replacing.
 - a. To remove the entire 582i converter from the 3582i valve positioner, continue with steps 5 through 7.
 - b. To replace the I/P module only, obtain a replacement I/P module listed in the parts list and refer to the procedures for reassembling the 582i converter.
5. Disconnect the supply tubing, output tubing and electrical conduit from the converter.

6. If necessary, remove the 67CFR regulator by removing the two screws (key 13). Then, remove the regulator from the converter assembly. Inspect the O-ring (key 3) and replace it if necessary. Apply lubricant (key 15) to the O-ring before replacing.
7. Remove the two screws (key 11) holding the 582i converter to the valve positioner case. Remove the converter from the valve positioner case (key 1 in Figure 20). Inspect the gasket (key 20) and replace it if necessary.

6.9 Reassembling the 582i Converter

During the following converter reassembly procedures, refer to Figure 25 for key number locations.

1. If the 582i converter was removed from the valve positioner, install a new gasket (key 20) between the converter housing and the valve positioner case. Attach the converter housing to the valve positioner case with the screws (key 11) and tighten the screws.
2. If the I/P module was removed from the 582i converter, inspect the O-ring (key 6) and replace if necessary, then reinstall the I/P module in the converter housing. Secure the I/P module with the two screws (key 9).
3. If other valve positioner components are removed, refer to the appropriate reassembly procedures and assemble the valve positioner completely.
4. Reconnect the supply tubing, output tubing and conduit to the valve positioner.
5. Reconnect the wiring to the terminal block. Do not overtighten the terminal screws. Maximum torque is 0.45 N·m / 4 lbf·in. Reconnect the grounding wire to the housing ground screw (key 10) and replace the cap (key 2).

NOTE

To check the operation of the I/P module, remove the pipe plug (key 12) and connect a pressure gauge. Provide a 1.4 bar / 20 psig supply pressure to the converter. With a 4 mA input signal the pressure output should read 0.16 to 0.24 bar / 2.3 to 3.5 psig. With a 20 mA input signal the pressure output should read 0.96 to 1.07 bar / 14.0 to 15.5 psig. Reinstall the pipe plug (key 12). There is no converter module calibration.

NOTICE

Do not apply a signal greater than 35 mA to the I/P module. Higher signal values may damage the converter module.

6. Apply supply pressure and 20 mA DC current input signal to the converter.
7. Check for leaks using a soap solution. Check any components which were disassembled or disconnected.

Section 7: Parts

7.1 Parts Ordering

A serial number is assigned to each valve positioner and is stamped on the nameplate. Always refer to this number when corresponding with your [Emerson sales office](#) regarding spare parts or technical information.

WARNING

Use only genuine Fisher replacement parts. Components that are not supplied by Emerson should not, under any circumstances, be used in any Fisher instrument. Use of components not supplied by Emerson may void your warranty, might adversely affect the performance of the instrument and could cause personal injury or property damage.

7.2 Parts Kits

Table 7. Parts Kits

Description	Part Number
Repair kit w/nozzle and flapper for the 3582 Positioner Kit contains keys 11, 18, 19B, 19E, 33B, 34C, 73 and 104. For standard temperature applications, except 3582NS For high temperature applications except 3582NS For 3582NS, contains EPDM parts	R3582X00012 R3582X00022 R3582X00032
Repair kit for 582i electro-pneumatic converter Kit contains keys 3, 5, 6, 8, 20 and 23	R582X000012
Replacement kit for 83L Relay Kit contains relay, gaskets and mounting screws, (key 32 in Figure 20, keys 10, 13 and 15 in Figure 22) For 3582 except 3582NS, std. const. For 3582 except 3582NS, Remote Vent, std. temp. For 3582 except 3582NS, hi-temp. const. For 3582 except 3582NS, Remote Vent, hi-temp. For 3582NS	R3580XRS012 R3580XRR012 R3580XRH012 R3580XRR022 R3580XNS012

7.3 Parts List

NOTE

Contact your [Emerson sales office](#) for Part Ordering information.


Table 8. Positioner Common Parts (Figure 20)

Key	Description	Key	Description
1	Case Assembly	19A	Adjustment Arm (Figure 19)
2*	Shaft Assembly For all except 3582NS and high vibration For travel up to 54 mm / 2.125 in. For travel up to 102 mm / 4 in. For 3582NS and high vibration For travel up to 54 mm / 2.125 in. For travel up to 102 mm / 4 in.	19B	Flapper (Figure 19)
		19C	Machine Screw (2 req'd) (Figure 19)
		19D	Flapper Arm (Figure 19)
		19E	Machine Screw (2 req'd) (Figure 19)
3	Nozzle Adaptor	19F	Flapper Spring (Figure 19)
4	Cam, Standard Cam A (For all types except 3582NS) Cam B (For all except 3582NS) Cam C (For all except 3582NS)	19G	Flapper Assembly Screw (Figure 19)
		19H	Hex Nut (Figure 19)
	Cam, for 3582NS and high vibration Cam A Cam B Cam C	19J	Lockwasher (Figure 19)
		19K	Arm Support (Figure 19)
6	Cam Bolt	19L	Pivot Pin (Figure 19)
7*	Bellows Assembly	20	Setting Adjustment Gear
8	Range Spring (see Table 4) 0.2 to 1.0 bar / 3 to 15 psi 0.4 to 2.0 bar / 6 to 30 psi	21	Flapper Assembly Retainer
		23	Self Tapping Screw (2 req'd)
9	Spring Seat	25	Nameplate
10	Machine Screw	26	Self Tapping Screw (2 req'd)
11*	O-ring	27	Extension Spring
12	Lockwasher (2 req'd)	28	Machine Screw (3 req'd)
13	Machine Screw (2 req'd)	29	Beam Sub-Assembly For all except 3582NS and high vibration For 3582NS and high vibration
18	Nozzle	30	Bellows Pivot Pin
19	Flapper Sub-Assembly	32*	83L Relay (Figure 22) See Parts Kits, Replacement Kit for 83L Relay
*Recommended spare parts			


Table 8. Positioner Common Parts (Figure 20) (continued)

Key	Description	Part Number
33	Cover Assembly	22B4905X012
34	Bypass block assembly (key 34) and parts are listed later in this parts list. Non-bypass block assembly (also key 34) and parts are listed following the bypass block assembly and parts.	---
35	Pipe Plug (Figures 23 and 24) Req'd when gauges or test connections are not used: 3 req'd for 3582 positioners	---
36*	Output Gauge, Dual Scale (Figures 23 and 24) 3582, 3582G 0 to 30 psig / 0 to 2 kg/cm ² 0 to 60 psig / 0 to 4 kg/cm ²	11B4040X042 11B4040X052
	Output Gauge, Triple Scale (Figures 23 and 24) 3582, 3582G 0 to 30 psig/0 to 0.2 MPa/0 to 2 bar 0 to 60 psig/0 to 0.4 MPa/0 to 4 bar	11B4040X012 11B4040X022
37*	Supply Gauge, Dual Scale 3582, 3582G 0 to 30 psig/0 to 2 kg/cm ² 0 to 60 psig/0 to 4 kg/cm ²	11B4040X042 11B4040X052
	Supply Gauge, Triple Scale 3582, 3582G 0 to 30 psig/0 to 0.2 MPa/0 to 2 bar 0 to 60 psig/0 to 0.4 MPa/0 to 4 bar	11B4040X012 11B4040X022
Recommended spare parts		

Figure 19. Flapper Sub-Assembly (Key 19)



13A1451-E


Figure 20. Fisher 3582 Positioner Assembly Drawing

41B8558-E

NOTE:


1. APPLY A GOOD-QUALITY THREAD LOCKING COMPOUND TO THE THREAD OF THE NOZZLE ADAPTOR (KEY 3).

Figure 21. Nozzle Sub-Assembly



12A7441-C

Figure 22. 83L Relay



32B0255-B

Table 8. Positioner Common Parts (Figure 20) (continued)

Key	Description	Part Number
38	Extension Spring,	---
39	Shipping Stop (not shown)	---
42	Hex Nut (2 req'd)	---
43	Spring Retainer Bracket	---
44	Gear Mounting Plate	---
45	Locking Nut	---
46*	Instrument Gauge, Dual Scale (Figures 23 and 24) 0 to 30 psig/0 to 2 kg/cm ² (3 to 15 psig/0.2 to 1.0 kg/cm ² ranges) 0 to 60 psig/0 to 4 kg/cm ² (6 to 30 psig/0.4 to 2.0 kg/cm ² ranges)	11B4040X042 11B4040X052
	Instrument Gauge, Triple Scale (Figures 23 and 24) 0 to 30 psig/0 to 0.2 MPa/0 to 2 bar (3 to 15 psig/20 to 100 kPa/0.2 to 1 bar ranges) 0 to 60 psig/0 to 0.4 MPa/0 to 4 bar (6 to 30 psig/40 to 200 kPa/0.4-2 bar ranges)	11B4040X012 11B4040X022
*Recommended spare parts		

Table 8. Positioner Common Parts (Figure 20) (continued)

Key	Description	Key	Description
47	Test Connection (Figures 23 and 24) 3582C, 3582D (3 req'd) 3582NS (3 req'd)	94	Lubricant, silicone sealant (not furnished with positioner)
71	Locking Nut	95	Lubricant, All except 3582NS, Lithium grease (not furnished with positioner) 3582NS Molykote™ (not furnished with positioner)
72	Locking Sleeve		
73*	O-ring (2 req'd) Std. const. All except 3582NS Hi-temp. const. 3582A, 3582C 3582NS	96	Adhesive, Loctite 680 Retaining Compound (not furnished with positioner)
		103*	O-Ring, (not shown) used with integrally mounted 67CFR filter regulator
75	Machine Screw	104*	Case Gasket (Figures 23 and 24) Std. const. Hi-temp. const. 3582NS
76	Beam Pivot Pin		
77	Extension Spring		
78	Speed Nut	105	Machine Screw (2 req'd) (Figures 23 and 24)
93	Anti-Seize sealant (not furnished with positioner)	108	Shipping tag (not shown)
*Recommended spare parts			

Table 9. For Units With Bypass (Figure 23)

Key	Description	Key	Description
34	Block Assembly 3582, 3582D 3582NS Note: Non-bypass block assembly (also key 34) and parts are listed in Table 10	34D	Bypass Handle
		34E	Spring
		34F	Washer
34A	Bypass Block	34G	Screw
34B*	Groove-Pin (not shown) (4 req'd)	34K	Spring Seat
34C*	Bypass Gasket 3582, 3582D 3582NS	34L	Spring Retainer
*Recommended spare parts			

Figure 23. Fisher 3582 Block Assembly with Bypass




Table 10. For Units Without Bypass (Figure 24)

Key	Description	Key	Description
34	Non-Bypass Block Assembly Std. const. 3582A, 3582C, 3582G 3582C Hi-temp. const. 3582A, 3582C 3582NS	34C*	Gasket Std. Const. Hi-temp. const. 3582NS
		34D	Manifold 3582, std. and hi-temp. const.
34A	Bypass Block	34G	Cap Screw

*Recommended spare parts



Figure 24. Fisher 3582 Block Assemblies without Bypass

Table 11. 582i Parts (Figure 25)

Key	Description	Part Number
---	I/P Module	33B7073X032
1	Housing 1/2-14 NPT conduit connection	---
2	Cap	---
---	Screw, (not shown), Used to lock cap	---
3*	O-ring, used with integrally-mounted 67CFR filter regulator	---
4	Nozzle Restriction Assembly	---
5	O-ring	---
6*	O-ring (2 req'd)	---
7	Tire Valve (not shown) (2 req'd with tire valve option)	---
8*	O-ring	---
9	Machine Screw (2 req'd)	---
10	Wire Retaining Screw (2 req'd)	---
11	Machine Screw (2 req'd)	---
12	Pipe Plug (2 req'd with pipe plug option)	---
13	Screw, used with integrally-mounted 67CFR filter/regulator (2 req'd)	---
14*	Supply Gauge, Dual Scale 0 to 30 psig/0 to 2 kg/cm ² 0 to 60 psig/0 to 4 kg/cm ²	11B4040X042 11B4040X052
	Supply Gauge, Triple Scale 0 to 30 psig/0 to 0.2 MPa/0 to 2 bar 0 to 60 psig/0 to 0.4 MPa/0 to 4 bar	11B4040X012 11B4040X022
15	Lubricant, Lithium grease (not furnished with positioner)	---
16	Anti-seize sealant (not furnished with positioner)	---
18	Self-Tapping Screw (2 req'd)	---
19	Nameplate, without 3rd party approvals	---
20*	Case Gasket	---
22*	Output Gauge, Dual Scale 0 to 30 psig/0 to 2 kg/cm ² 0 to 60 psig/0 to 4 kg/cm ²	11B4040X042 11B4040X052
	Output Gauge, Triple Scale 0 to 30 psig/0 to 0.2 MPa/0 to 2 bar 0 to 60 psig/0 to 0.4 MPa/0 to 4 bar	11B4040X012 11B4040X022
23*	Filter	---
24	Vent Assembly	---
25	Pipe Plug (required when a 582i is used without an integrally-mounted 67CFR filter/regulator)	---
*Recommended spare parts		

Figure 25. Fisher 582i Converter**NOTE:**

APPLY LUB/SEALANT

1. GAUGES MAY BE REPLACED PIPE PLUGS (KEY 12) OR TIRE VALVES (KEY 7).

Mounting Parts

NOTEContact your [Emerson sales office](#) for mounting parts information.

Diagnostic Connections (Figure 8)

FlowScanner valve diagnostics system hook-up. Includes connector body and body protector. If ordered for units with gauges, a stem is also included.

Description
For 3582 pneumatic valve positioners For units with gauges For units without gauges

-  Fisher.com
-  Facebook.com/FisherValves
-  LinkedIn.com/groups/3941826
-  X.com/FisherValves

D200138X012 © 1989, 2026, Emerson. All rights reserved. The Emerson logo is a trademark and service mark of Emerson Electric Co. Fisher and FlowScanner are each a mark of an entity in the Emerson family of businesses. All other marks are the property of their respective owners.

Neither Emerson, nor any of its affiliated entities assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use, and maintenance of any product remains solely with the purchaser and end user.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.

Emerson
Marshalltown, Iowa 50158 USA
Sorocaba, 18087 Brazil
Cernay 68700 France
Dubai, United Arab Emirates
Singapore 128461 Singapore
www.Fisher.com

FISHER™

