

Rosemount™ 848T Wireless Temperature Transmitter



Safety messages

⚠ WARNING

Failure to follow these installation guidelines could result in death or serious injury.

Make sure only qualified personnel perform the installation.

Explosions could result in death or serious injury.

Installation of this transmitter in an explosive environment must be in accordance with the appropriate local, national, and international standards, codes, and practices. Review the approvals section of the *Quick Start Guide* for any restrictions associated with a safe installation.

Before connecting a Field Communicator in an explosive atmosphere, ensure the instruments are installed in accordance with intrinsically safe or non-incendive field wiring practices.

Process leaks could result in death or serious injury.

Before applying pressure, install and tighten thermowells and sensors.

Electrical shock could cause death or serious injury.

Avoid contact with the leads and terminals. High voltage that may be present on leads can cause electrical shock.

Use extreme caution when making contact with the leads and terminals.

The power module with the wireless unit contains two “C” size cells. Each of the primary lithium/thionyl chloride battery contains approximately 2.5 grams of lithium, for a total of 5 grams in each power module. Under normal conditions, the battery materials are self-contained and are not reactive as long as the batteries and the module integrity are maintained. Care should be taken to prevent thermal, electrical or mechanical damage. Contacts should be protected to prevent premature discharge.

This device complies with Part 15 of the Federal Communication Commission (FCC) Rules. Operation is subject to the following conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.

This device must be installed to ensure a minimum antenna separation distance of 8-in. (20 cm) from all persons.

The power module may be replaced in a hazardous area. The power module has surface resistivity greater than one gigaohm and must be properly installed in the wireless device enclosure. Care must be taken during transportation to and from the point of installation to prevent electrostatic charge build-up.

Physical access

Unauthorized personnel may potentially cause significant damage to and/or misconfiguration of end users' equipment. This could be intentional or unintentional and needs to be protected against.

Physical security is an important part of any security program and fundamental to protecting your system. Restrict physical access by unauthorized personnel end users assets. This is true for all systems used within the facility.

Battery hazards remain when cells are discharged.

Power modules should be stored in a clean and dry area. For maximum life, storage temperature should not exceed 30 °C.

⚠ CAUTION

The products described in this document are NOT designed for nuclear-qualified applications. Using non-nuclear qualified products in applications that require nuclear-qualified hardware or products may cause inaccurate readings.

For information on Rosemount nuclear-qualified products, contact a Emerson Sales Representative.

NOTICE

Read this manual before working with the product. For personal and system safety and for optimum product performance, ensure that you thoroughly understand the contents before installing, using, or maintaining this product.

NOTICE

Shipping considerations for wireless products (lithium batteries):

The unit was shipped without the power module installed. Prior to re-shipment, ensure that the power module has been removed.

Each power module contains two “C” size primary lithium batteries. Primary lithium batteries are regulated in transportation by the U.S. Department of Transportation, and are also covered by International Air Transport Association (IATA), International Civil Aviation Organization (ICAO), and European Ground Transportation of Dangerous Goods (ARD). It is the responsibility of the shipper to ensure compliance with these or any other local requirements. Consult current regulations and requirements before shipping.

If the sensor is installed in a high-voltage environment and a fault condition or installation error occurs, the sensor leads and transmitter terminals could carry lethal voltages. Use extreme caution when making contact with the leads and terminals.

NOTICE

All wireless devices must be installed only after the Wireless Gateway has been installed and is functioning properly. Wireless devices must also be powered up in order of proximity from the Wireless Gateway, beginning with the closest. This will result in a simpler and faster network installation. For more information, see [Emerson Wireless 1410 Gateway](#).

Contents

Chapter 1	Introduction.....	7
	1.1 Considerations.....	7
	1.2 Product recycling/disposal.....	8
Chapter 2	Configuration.....	9
	2.1 Overview.....	9
	2.2 Bench top configuration.....	9
	2.3 Default settings.....	10
	2.4 Device network configuration.....	10
	2.5 Sensor configuration.....	12
	2.6 Advanced configuration (optional).....	13
Chapter 3	Installation.....	19
	3.1 Wireless considerations.....	19
	3.2 Sensor connections.....	20
	3.3 Physical installation.....	24
Chapter 4	Commissioning.....	29
	4.1 Insert power module.....	29
	4.2 Network status.....	29
	4.3 Verify operation.....	29
Chapter 5	Operation and Maintenance.....	33
	5.1 Calibration.....	33
	5.2 Power module replacement.....	34
	5.3 Spare parts.....	35
Chapter 6	Troubleshooting.....	37
	6.1 Device troubleshooting.....	37
	6.2 Wireless network troubleshooting.....	40
Chapter 7	Appendix.....	41
	7.1 Product certifications.....	41
	7.2 View ordering, information, specifications, and dimensional drawings.....	41

1 Introduction

1.1 Considerations

1.1.1 General

Electrical temperature sensors such as RTDs and thermocouples produce low-level signals proportional to their sensed temperature. The 848T Transmitter converts this signal into a robust *WirelessHART*® digital signal.

1.1.2 Commissioning

The transmitter can be commissioned before or after installation. It may be useful to commission it on the bench, before installation, to ensure proper operation and to become familiar with its functionality. When applicable, make sure the instruments are installed in accordance with intrinsically safe or non-incendive field wiring practices. The device will be powered whenever the power module is installed. To avoid depleting the power module, make sure it is removed when the device is not in use.

1.1.3 Mechanical

Location

When choosing an installation location and position, take into account the need for access to the transmitter. For best performance, the antenna should be vertical with the conduit entries facing downward. The antenna should have space between objects in a parallel metal plane, such as pipes or metal framework, as they may adversely affect the performance of the antenna. Place the antenna 18 to 36 in. (0.46 to 0.91 m) from any solid metal surface, building, or structure.

Note

The antenna can only rotate backwards.

1.1.4 Electrical

Power module

The 848T Transmitter is self-powered. The power module with the wireless unit contains two **C** size primary lithium/thionyl chloride batteries. Each battery contains approximately two-and-a-half grams of lithium, for a total of five grams in each power module. Under normal conditions, the battery materials are self-contained and are not reactive as long as the batteries and the power module are maintained.

NOTICE

Care must be taken to prevent thermal, electrical or mechanical damage. Contacts must be protected to prevent premature discharge.
Use caution when handling the power module. It may be damaged if dropped from heights in excess of 20 ft. (6 m).

Sensors

Make sensor connections through the conduit entries on the bottom of the enclosure. Be sure to provide adequate clearance for cover removal.

1.1.5 Environmental

Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.

Temperature effects

The transmitter will operate within specifications for ambient temperatures between -40 and 185 °F (-40 and 85 °C).

Note

If the ambient temperature is outside of the specification limit, consider moving the transmitter to a location within the specified limits.

1.2 Product recycling/disposal

Consider recycling equipment and packaging.

Dispose of the product and packaging in accordance with local and national legislation.

2 Configuration

2.1 Overview

This section contains information on configuration and verification that must be performed prior to installation.

Field Communicator and AMS Wireless Configurator instructions are included for performing configuration functions. Additionally, Field Communicator Fast Key sequences are identified for each software function.

Example of Fast Key sequence listing

Fast Keys 1, 2, 3, etc.

2.2 Bench top configuration

Bench top configuration requires a Field Communicator or AMS Wireless Configurator. Connect the Field Communicator leads to the terminals labeled **COMM** on the terminal block, as shown in [Figure 2-1](#).

Bench top configuration is testing of the transmitter and verifying the transmitter configuration data. Configuring the transmitter on the bench prior to installation ensures all network settings are working correctly.

When using a Field Communicator, any configuration changes made must be sent to the transmitter using the **Send** key (**F2**). AMS Wireless Configurator changes are implemented by selecting the **Apply** button.

AMS Wireless Configurator

AMS Wireless Configurator is capable of connecting to devices directly, using a HART® modem, or wirelessly using the Emerson Smart Wireless Gateway. When configuring the device, double click the device icon or right click and select **Configure**.

2.2.1 Connection diagrams


Bench hook-up

Connect the bench equipment as shown in [Figure 2-1](#) and turn the Field Communicator on by selecting the **ON/OFF** key or log into AMS Wireless Configurator. The Field Communicator or AMS Wireless Configurator will search for a HART® compatible device and indicate when it is connected. If the Field Communicator or AMS Wireless Configurator fail to connect, it indicates that no device was found. Refer to [Troubleshooting](#).

Field hook-up

The wiring for a field hook-up for a Field Communicator or AMS Wireless Configurator, illustrated in [Figure 2-1](#), by connecting at **COMM** on the transmitter terminal block.

Figure 2-1: Field Communicator Connection



A. Battery

2.3 Default settings

The Rosemount 848T Wireless Transmitter default configuration:

Sensor 1	Type J Thermocouple
Sensor 2	Type J Thermocouple
Sensor 3	Type J Thermocouple
Sensor 4	Type J Thermocouple
Engineering Units	°C
Number of Lead Wires	2
Sensor Alerts	Disabled
Network ID	Factory Generated Network Parameters
Join Key	Factory Generated Network Parameters
Update Rate	1 Minute

Note

Use the **C1** option code to have the factory configure each sensor individually. This option also enables factory configuration of process alerts, update rate, and channel tag. This option code is not required to configure the self-organizing network parameters, or to set all of the sensors identically.

2.4 Device network configuration

2.4.1 Join device to network

Fast Keys 1, 12

The transmitter must be configured in order to communicate with the Gateway, and ultimately with the host system. This step is the wireless equivalent of connecting wires from the transmitter to the host system.

Procedure

1. From the **Home** screen, select **2: Configure**.
2. Select **1: Guided Setup**.
3. Select **1: Join Device to Network**, and follow the on-screen instructions to complete the configuration.

Using a Field Communicator or AMS Wireless Configurator, enter the network ID and join key so they match the network ID and join key of the Gateway, and other devices in the network.

Note

If the network ID and join key do not match the Gateway, the transmitter will not communicate with the network. The network ID and join key can be obtained from the Gateway on the **Setup** → **Network** → **Settings** page on the web server.

Figure 2-2: Wireless Gateway

2.4.2 Configure update rate

Fast Keys 2, 1, 2

The update rate is the frequency a new measurement is taken and transmitted over the wireless network. The default setting for update rate is one minute. This may be changed at commissioning, or at any time using AMS Wireless Configurator. The update rate is user selectable, and can be configured between 4 seconds and 60 minutes.

Procedure

1. From the **Home** screen, select **2: Configure**.
2. Select **1: Guided Setup**.
3. Select **2: Configure Update Rate**, then follow the on-screen instructions to complete the configuration.
 - If using a Gateway, select **Yes** to enable optimizations.

- If using a third party *WirelessHART*® Gateway, select **No** to disable optimizations and consult the manufacturer's Gateway manual.

2.5 Sensor configuration

2.5.1 Configure sensor type

Fast Keys 2, 1, 3

Every temperature sensor has unique characteristics, to achieve the most accurate measurement, configure the input channels of the 848T Transmitter to match the specific sensor type.

Procedure

1. From the **Home** screen, select **2: Configure**.
2. Select **1: Guided Setup**.
3. Select **3: Configure Sensors**, then follow the on-screen instructions to complete the configuration.

Each input can be independently configured on the 848T Transmitter. Select the desired sensor type and number of lead wires for each sensor input. If an input is not being used, **Not Used** must be selected for the sensor type.

Related information

[Sensor Wiring Connections](#)

2.5.2 Configure engineering units

Fast Keys 2, 1, 3, 3

Each input can be configured on the 848T Transmitter for different engineering units. The supported units are °C, °F, °R, °K, millivolts, ohms, and milliamps.

Procedure

1. From the **Home** screen, select **2: Configure**.
2. Select **1: Guided Setup**.
3. Select **3: Configure Sensors**.
4. Select **3: Configure Device Engineering Units**, then follow the on-screen instructions to complete the configuration.

2.5.3 Removing the power module

After the sensor and network parameters have been configured, remove the power module and close the housing cover.

Note

Only insert the power module when the device is ready for commissioning.

NOTICE

Use caution when handling the power module. It may be damaged if dropped.

2.6 Advanced configuration (optional)

2.6.1 Configure process alerts

Fast Keys 2, 1, 5

Alerts allow the user to set the transmitter to provide a notification when the measurement readings exceed the specified temperature range. A high and low alert may be established for each sensor input. A process alert is transmitted if the trigger points are exceeded and alert mode is **ON**. An alert is displayed on a Field Communicator or on the AMS Wireless Configurator status screen, and will reset when the value is once again within the user-configured range.

Note

The high alert value must be set higher than the low alert value, and both values must be within the temperature sensor limits.


Procedure

1. From the **Home** screen, select **2: Configure**.
2. Select **1: Guided Setup**.
3. Select **5: Process Alerts**, then follow the on-screen instructions to complete the configuration process.
The user configures the trigger point and dead band for each high and low alert and when the measurement value exceeds the trigger point it activates the alert. The alert deactivates when the measurement value falls outside the dead band range.

Example

For the following illustration, the alert is active when the value rises above 212 °F (100 °C) or falls below 32 °F (0 °C). The alert turns **OFF** when the value falls below 203 °F (95 °C) or rises above 41 °F (5 °C). Dead band is a buffer so the alerts do not toggle **ON** and **OFF** when the temperature measurement is close to the trigger point.

	High alert configuration	Low alert configuration
Trigger point	212 °F (100 °C)	32 °F (0 °C)
Dead band	41 °F (5 °C)	41 °F (5 °C)



- A. **Trigger point** 212 °F (100 °C)
- B. **High alert ON**
- C. **Low alert ON**
- D. **Dead band** 203 °F (95 °C)
- E. **Dead band** 41 °F (5 °C)
- F. **Trigger point** 32 °F (0 °C)

2.6.2 Device temperature engineering units

Fast Keys 2, 2, 8, 3

The device temperature reported can be configured for different engineering units.
To select the sensor temperature unit:

Procedure

1. From the **Home** screen, select **2: Configure**.
2. Select **2: Manual Setup**.
3. Select **8: Device Temperature**.
4. Select **3: Unit**.

2.6.3 Write protect

Fast Keys 2, 2, 7, 1

The 848T Transmitter has a software write protect security feature.
To view write protect security settings:

Procedure

1. From the **Home** screen, select **2: Configure**.
2. Select **2: Manual Setup**.
3. Select **7: Security**.
4. Select **1: Write Protect**.

2.6.4 AC power filter

Fast Keys 2, 2, 10, 2

The **AC power filter** can be set to reject line power noise at either 50 or 60 Hz.

Procedure

1. From the **Home** screen, select **2: Configure**.
2. Select **2: Manual Setup**.
3. Select **10: Power**.
4. Select **2: AC Power Filter**.

2.6.5 Device tag

Fast Keys 2, 2, 9, 1

The 848T Transmitter device tag (eight characters) can be configured to identify the device.

Procedure


1. From the **Home** screen, select **2: Configure**.
2. Select **2: Manual Setup**.
3. Select **7: Device Information**.
4. Select **1: Tag**⁽¹⁾.

2.6.6 HART® menu tree

Options listed in bold type indicate a selection provides other options. For ease of operation, changing calibration and setup, such as sensor type, number of wires, and range values, can be completed in several locations.

⁽¹⁾ A long tag (consisting of 32 characters) can be configured using the Fast Key sequence by selecting **2: Long Tag**.

Figure 2-3: Field Communicator Menu Tree



2.6.7

Fast Key sequences

Table 2-1 lists the Fast Key sequences for common transmitter functions.

Note

The Fast Key sequences assume that Device v3, DD v1 is being used.

Table 2-1: 848T Transmitter Fast Key Sequence

Function	Fast Key sequence	Menu items
Device Information	1, 13	Tag, Long Tag, Descriptor, Message, Date, SI Unit Restriction, Country, Sensors
Guided Setup	2, 1	Join Device to Network, Configure Update Rate, Configure Sensors, Calibrate Sensors, Process Alerts
Manual Setup	2, 2	Wireless, Sensor 1, Sensor 2, Sensor 3, Sensor 4, Hart, Security, Device Temperature, Device Information, Power
Wireless	2, 2, 1	Network ID, Join Device to Network, Broadcast Information, including Update Rate and Messages
Sensor Calibration	3, 4, 2-5	Sensor Status, Current Upper Trim, Current Lower Trim, Lower Sensor Trim, Upper Sensor Trim, Recall Factory Trim, RTD 2 Wire Offset

3 Installation

3.1 Wireless considerations

Power up sequence

The Power Module should not be installed on any wireless device until the Wireless Gateway is installed and functioning properly. Enable **Active Advertising** on the Gateway to ensure that new devices join the network faster. For more information, see the [Emerson Wireless 1410 Gateway](#).


Note

Emerson recommends to have wireless devices be powered up in order of proximity from the Gateway, beginning with the closest. This will result in a simpler and faster network installation.

Antenna position

Emerson recommends that the antenna be positioned vertically and approximately 3 ft. (1 m) from any large structure, building, or conductive surface. This will allow for clearer communication to other devices.


Figure 3-1: Antenna Position



Conduit plug

The temporary orange plugs must be replaced with the included conduit plugs using approved thread sealant.


Figure 3-2: Conduit Plug



Field Communicator connections

The Power Module needs to be connected for the Field Communicator to interface with the 848T Transmitter.

Figure 3-3: Field Communicator Connection Diagram



A. Battery

3.2 Sensor connections

The 848T Transmitter is compatible with a number of RTD and thermocouple sensor types. [Figure 3-4](#) shows the correct input connections to the sensor terminals on the transmitter. To ensure a proper sensor connection, anchor the sensor lead wires into the appropriate compression terminals and tighten the screws.


Thermocouple or millivolt inputs

Use appropriate thermocouple extension wire to remote mount the transmitter from the sensor. Make millivolt input connections with copper wire. Use shielding for long runs of wire.

RTD or ohm inputs

There are various RTD configurations, including the 2-, 3-, and 4-wire, used in industrial applications. A 3- or 4-wire RTD operates within specification, without recalibration, for lead wire resistances up to 60 ohms per lead. This is the equivalent of 6,000 ft of 20 AWG wire. For a 2-wire RTD, both RTD leads are in series with the sensor element, so an error can occur in lead lengths that exceed one foot of 20 AWG wire. This error can be eliminated by using a 3- or 4-wire RTD.

Figure 3-4: Sensor Wiring Connections



- A. 2-wire RTD, ohm
- B. 4-wire RTD, ohm
- C. 3-wire RTD, ohm
- D. Thermocouple, millivolt

Refer to [Grounding practices](#) for more information on sensor grounding practices.

3.2.1 Sensor lead wire resistance effect—RTD input

When using a 4-wire RTD, the effect of lead resistance is eliminated and has no impact on accuracy. A 3-wire sensor will not fully cancel lead resistance error because it cannot compensate for imbalances in resistance. Using the same type and length of wire on all three lead wires will make a 3-wire RTD installation as accurate as possible. A 2-wire sensor will produce the largest error because it directly adds the lead wire resistance to the sensor resistance. For 2- and 3-wire RTDs, an additional lead wire resistance error is induced with ambient temperature variations. The table and the examples shown below help quantify these errors.

Examples of Approximate Basic Error:

Sensor Input	4-wire RTD
Approximate Basic Error	Negligible (independent of lead wire resistance up to 60 Ω per lead)
Sensor Input	3-wire RTD
Approximate Basic Error	$\pm 1.0 \Omega$ in reading per ohm of unbalanced lead wire resistance (Unbalanced lead wire resistance = maximum imbalance between any two leads.)
Sensor Input	2-wire RTD

Approximate Basic Error 1.0 Ω in reading per ohm of lead wire resistance

Examples of approximate lead wire resistance effect calculations

Total cable length	150 m
Imbalance of the lead wires at 68 °F (20 °C)	0.5 Ω
Resistance/length (18 AWG Cu)	0.025 Ω /m
Temperature coefficient of Cu (α_{Cu})	0.039 Ω / Ω °C
Temperature coefficient of Pt (α_{Pt})	0.00385 Ω / Ω °C
Change in Ambient Temperature (ΔT_{amb})	25 °C
RTD Resistance at 0 °C (R_0)	100 Ω (for Pt 100 RTD)

3.2.2 Pt100 4-wire RTD

No lead wire resistance effect.

3.2.3 Pt100 3-wire RTD

Lead wire imbalance seen by the transmitter = 0.5 Ω

$$\text{Basic Error} = \frac{0.5 \Omega}{\left(0.00385 \frac{\Omega}{\Omega^{\circ}\text{C}}\right) \times (100 \Omega)} = 1.3^{\circ}\text{C}$$

Error due to amb. temp. var. of $\pm 25^{\circ}\text{C}$ =

$$\frac{(\alpha_{Cu}) \times (\Delta T_{amb}) \times (\text{Imbalance of Lead Wires})}{(\alpha_{Pt} \times R_0)}$$

$$\frac{\left(0.0039 \frac{\Omega}{\Omega^{\circ}\text{C}}\right) \times (25^{\circ}\text{C}) \times (0.5 \Omega)}{\left(0.00385 \frac{\Omega}{\Omega^{\circ}\text{C}}\right) \times (100 \Omega)} = \pm 0.1266^{\circ}\text{C}$$

3.2.4 Pt100 2-wire RTD

Lead wire resistance seen by the transmitter = 150 m $\times$ 2 wires $\times$ 0.025 Ω /m = 7.5 Ω

$$\text{Basic Error} = \frac{7.5 \, \Omega}{\left(0.00385 \frac{\Omega}{\Omega^{\circ}\text{C}}\right) \times (100 \, \Omega)} = 19.5 \, ^{\circ}\text{C}$$

$$\text{Error due to amb. temp. var. of } \pm 25 \, ^{\circ}\text{C} = \frac{(\alpha_{\text{Cu}}) \times (\Delta T_{\text{amb}}) \times (\text{Lead Wires Resistance})}{(\alpha_{\text{Pt}} \times R_0)}$$


$$\frac{\left(0.0039 \frac{\Omega}{\Omega^{\circ}\text{C}}\right) \times (25 \, ^{\circ}\text{C}) \times (7.5 \, \Omega)}{\left(0.00385 \frac{\Omega}{\Omega^{\circ}\text{C}}\right) \times (100 \, \Omega)} = \pm 1.9 \, ^{\circ}\text{C}$$

3.2.5 4–20 milliamp inputs

This section details the wiring and configuration of the 848T Transmitter to monitor a 4–20 mA signal using the S002 option code. This technique is used to capture data from a 4–20 mA device that does not have a connection to traditional loop control or monitoring system. The 848T Transmitter measures millivolt signals, to monitor a 4–20 mA signal there must be a conversion to millivolt using a 5 ohm resistor to create a 20–100 mV signal. It is optimal to use a 5 ohm resistor with stable operation over the ambient temperature range where the 848T Transmitter is located.

See [Figure 3-5](#) for information on wiring.

Figure 3-5: 848T Wireless Terminal Diagram



Note

For a device to be Intrinsically Safe, it must operate on only one power source. By converting a 4–20 mA signal to a measurable millivolt signal, it is considered as a second power source in the terminal block of the 848T Transmitter, and voids the Intrinsically Safe approval. This does not affect the Division 2, non-incendive approvals so this configuration can still be installed and operated in Division 2 areas.

Note

This technique must not be applied to a 4–20 mA device currently connected to a **loop control**.

NOTICE

The mA signal must not be directly applied to the transmitter's millivolt terminals. Doing this without the resistor may damage the electronics. The voltage applied across the terminals should not exceed 1000 mV. Excessive voltage could damage the transmitter.

Using the Field Communicator or AMS, reconfigure the 848T Transmitter sensor type to either 4–20 mA (Rosemount), 4–20 mA (NAMUR), 100 mV, or 1000mV. Note that when measuring voltages less than 100mV, the 100mV sensor type should be selected for best accuracy. The engineering units are user-selectable and can be either mA or mV.

[Table 3-1](#) shows the saturation and alarm thresholds for 4–20 mA (Rosemount) sensor type and [Table 3-2](#) shows the saturation and alarm thresholds for 4–20 mA (NAMUR) sensor type.

Table 3-1: 4–20 mA (Rosemount) Saturation and Alarm

Transmitter status	Analog input (mA)	Measured voltage (mV)	Analog region
Sensor Saturation	> 21.71	> 108.55	Upper Alarm
Sensor Out of Limits	20.8–21.71	104–108.55	Upper Saturation
Good	3.9–20.8	19.5–104	Normal Region
Sensor Out of Limits	3.79–3.9	18.95–19.5	Lower Saturation
Sensor Saturation	< 3.79	< 18.95	Lower Alarm

Table 3-2: 4–20 mA (NAMUR) Saturation and Alarm

Transmitter status	Analog input (mA)	Measured voltage (mV)	Analog region
Sensor Saturation	> 20.96	> 104.8	Upper Alarm
Sensor Out of Limits	20.5–20.96	102.5–104.8	Upper Saturation
Good	3.8–20.5	19–102.5	Normal Region
Sensor Out of Limits	3.64–3.8	18.2–19	Lower Saturation
Sensor Saturation	< 3.64	< 18.2	Lower Alarm

Because of resistor variances, the input must be calibrated with the resistor installed to meet the accuracy specifications. For more information on lower and upper trim procedures, see [Calibration](#).

3.3 Physical installation

3.3.1 Remote mount

The 848T Transmitter is only intended to be installed in the Remote Mount configuration where the sensor is mounted separate from the 848T Transmitter housing, then connected to the transmitter using conduit or cable glands.


Procedure

1. Install the sensor according to standard installation practices.

Note

Be sure to use approved thread sealant on all connections.


2. To reduce sensor wiring length, mount the 848T Transmitter central to all of the measurements. When installing the 848T Transmitter, the conduit entries need to be facing downward. If using the mounting bracket (Option Code B6), mount to a 2-in. pipe.



3. Run wiring (and conduit, if necessary) from the sensor to the 848T Transmitter. For an easier installation, use the outside conduit entries, as shown below.

Note

Any unused conduit entries must be sealed with an approved sealant using the included threaded conduit plug.




- A. Conduit entries
B. Conduit plug
-

4. Pull the wiring through the threaded conduit entry of the 848T Transmitter.
5. Attach the sensor wiring to the terminals as indicated in [Figure 3-4](#).

Note

Terminal Screw 5 is for attaching the shield wire of the sensor to the device. See [Grounding practices](#) for more information.

6. To connect the power module, remove the plastic plug from the receptacle and discard.
-



A. Plastic plug

7. After initial installation, close the housing cover securely.
-

Note

Always ensure a proper seal by installing the electronics housing cover so that metal touches metal, but do not over tighten.

8. Position the antenna vertically.
-

Note

The antenna must be approximately 3-ft. (1 m) from any large structures or buildings to allow clear communication to other devices.

3.3.2 Grounding practices

The transmitter operates with the housing floating or grounded. However, the extra noise in floating systems may impact many types of readout devices. If the signal appears noisy or erratic, grounding the transmitter at a single point may solve the problem.


The electronics enclosure should be grounded according to local and national installation codes. This can be accomplished via the process connection, internal case grounding terminal, or the external grounding terminal.

Each process installation has different requirements for grounding, use the options recommended by the facility for the specific sensor type, or begin with the recommendations below.

Ungrounded thermocouple, mV, and RTD/ohm inputs option

Procedure


1. Connect sensor wiring shield to Terminal Screw 5 at the terminal block. Terminal Screw 5 is internally connected to the housing.
2. Ensure the sensor wiring is electrically isolated from the transmitter housing.



Grounded thermocouple option

Procedure


1. Ground the sensor wiring shield at the sensor.
2. Ensure the sensor wiring and shield is electrically isolated from the transmitter housing and Terminal Screw 5.



4-20 mA input option

Procedure

1. Ground the 4-20 mA signal at the power supply, making sure not to attach the signal shield to Terminal Screw 5.
2. The 4-20 mA signal shield should be electrically isolated from the 848T Transmitter housing and the 4-20 mA device to ensure a single point ground.



4 Commissioning

4.1 Insert power module

At commissioning, the power module needs to be inserted. If present, remove the plastic plug from the receptacle and insert the power module. Then close the housing cover, making sure to tighten the cover so that metal touches metal but do not overtighten.

4.2 Network status

If the 848T Transmitter was configured with the **Network ID** and **Join Key** and sufficient time has taken place for network polling, the transmitter should be connected to the network. To verify connectivity, open the Wireless Gateway's integral web interface and navigate to the explorer page.

Figure 4-1: Wireless Gateway Explorer Page

The screenshot displays the 'Network Settings' page of a Wireless Gateway web interface. On the left is a navigation tree with options like Diagnostics, Monitor, Explorer, Setup, Network, Security, Time, System Backup, Page Options, Restart Apps, Firmware Upgrade, Firmware Options, HART, Changes, Modbus, OPC, and Trends. The 'Network' section is expanded. The main content area shows the following settings:

- Network name:** myNet
- Network ID:** 36863
- Security mode:** ☒ Common join key, ☐ Access control list
- Join key:** A field containing eight asterisks (*****).
- Show join key:** ☐ Yes, ☒ No
- Generate random join key:** A button labeled 'Generate'.
- Rotate network key?:** ☐ Yes, ☒ No
- Key rotation period (days):** 90
- Change network key now?:** ☐ Yes, ☒ No
- Submit:** A button at the bottom of the settings section.

The footer of the page includes '© Emerson, 2010', 'Feedback', and 'Terms Of Use'.

Note

It may take several minutes for the device to join the network.

This page displays the transmitter's HART® tag, **PV**, **SV**, **TV**, **QV**, and **Update Rate**. If the device and sensors are working properly, a green status indicator is present for HART status. A red indicator means there is a problem with either the device, a sensor, or the communication path. If **Not Used** has been selected for a sensor, a yellow indicator is shown. For more information on a specific device, click on the **tag** name.

4.3 Verify operation

Operation can be verified using one of three methods: Field Communicator, the Wireless Gateway's integrated web interface, or using AMS Wireless Configurator.

Field Communicator

For HART® communication, an 848T Wireless DD is required. For connecting with a Field Communicator, refer to [Figure 3-3](#).

Function Communications

Key Sequence 3, 3

Menu Items Join Status, Communications Status, Join Mode, Number of Advertisements Heard, Number of Available Neighbors, Number of Join Attempt

Emerson Wireless Gateway

In the **Gateway's** integrated web interface, navigate to the **Explorer** page. This page shows whether the device has joined the network, and if it is communicating properly.

Figure 4-2: Wireless Gateway Explorer Page

The screenshot displays the 'Network Settings' web interface. On the left is a navigation tree with options like Diagnostics, Monitor, Explorer, Setup, Network, Speed, Bandwidth, Ethernet protocol, Security, Time, System Backup, Page Options, Restart Apps, Firmware Upgrade, Firmware Options, HART, Changes, Modbus, OPC, and Trends. The 'Network' section is expanded, and 'Settings' is selected. The main content area shows the following configuration options:

- Network name:** myNet
- Network ID:** 36863
- Security mode:** ☒ Common join key ☐ Access control list
- Join key:** A field with masked characters (dots).
- Show join key:** ☐ Yes ☒ No
- Generate random join key:** A button labeled 'Generate'.
- Rotate network key?:** ☐ Yes ☒ No
- Key rotation period (days):** 90
- Change network key now?:** ☐ Yes ☒ No
- Submit:** A button at the bottom of the form.


At the bottom of the page, there are links for 'Feedback' and 'Terms Of Use', and a copyright notice '© Emerson, 2010'.

Note

If the device joins the network and immediately has an alarm present, it is likely due to sensor configuration. Check the sensor wiring in [Figure 4-2](#) and the sensor configuration in [Fast Key sequences](#).

4.3.1 AMS Wireless Configurator

When the device has joined the network, it will appear in the AMS Wireless Configurator as illustrated below:



5 Operation and Maintenance

5.1 Calibration

Calibrating the transmitter increases the measurement precision. It does this by allowing corrections to be made to the factory-stored characterization curve and by digitally altering the transmitter's interpretation of the sensor input.

To understand calibration, it is necessary to understand that smart transmitters operate differently from analog transmitters. An important difference is that smart transmitters are factory characterized, meaning that they are shipped with a standard sensor curve stored in the transmitter firmware. In operation, the transmitter uses this information to produce a process variable output, in engineering units, dependent on the sensor input.

Perform a sensor trim if the transmitter's digital value for the sensor measurement variables does not match the plant's standard calibration equipment. The sensor trim function calibrates the sensor to the transmitter in temperature units or raw units. Unless the site-standard input source is NIST-traceable, the trim functions will not maintain the NIST-traceability of the system.

5.1.1 Sensor trim

Fast Keys 3, 4, 2-5

To calibrate the transmitter using the **sensor trim** function:

Procedure

1. Assemble and power the calibration system including the 848T Transmitter, Field Communicator/AMS, power supply, and temperature input source.
2. From the **Home** screen, select **3: Service Tools**.
3. Select **4: Maintenance**.
4. Select **2-5: Calibrate Sensor 1, 2, 3, or 4**.
5. Select **5: Lower Sensor Trim**.
6. Follow the on-screen instructions to complete the adjustment of the lower value.
7. Repeat the procedure for the upper value. Select **6: Upper Sensor Trim** and follow the on-screen instructions to complete the adjustment of the upper value.
8. Verify calibration.

5.1.2 Recall factory trim

Fast Keys 3, 4, 2-5, 7

Recalling factory trim recalls the factory-characterization of the standard sensor curve stored in the transmitter firmware.

Procedure

1. From the **Home** screen, choose **3: Service Tools**.
2. Choose **4: Maintenance**.
3. Choose **2-5: Calibrate Sensor 1, 2, 3, or 4**, depending on what selection is made.
4. Choose **7: Recall Factory Trim**.

5.2 Power module replacement

Expected power module life is six years at reference conditions.⁽²⁾

When power module replacement is required, open the cover and then remove the power module. Replace the power module (part number 701PBKKF) and close the cover making sure to tighten so that metal touches metal but do not over tighten.

Handling considerations

The power module with the wireless unit contains two **C** size primary lithium/thionyl chloride batteries. Each battery contains approximately 2.5 grams of lithium, for a total of 5 grams in each pack. Under normal conditions, the battery materials are self-contained and are not reactive as long as the batteries and the power module integrity are maintained.

⚠ WARNING

Battery hazards remain even after cells are fully discharged.

NOTICE

Care must be taken to prevent thermal, electrical, or mechanical damage. Contacts must be protected to prevent premature discharge.

NOTICE

Use caution when handling the power module. The power module may be damaged if dropped from heights in excess of 20 feet.

Environmental considerations

As with any battery, local environmental rules and regulations should be consulted for proper management of spent power module. If no specific requirements exist, recycling through a qualified recycler is encouraged.

Note

Consult the materials safety data sheet for battery specific information.

Shipping considerations

The unit was shipped without the power module installed. Remove the power module from the unit prior to shipping.

Primary lithium batteries are regulated in transportation by the U.S. Department of Transportation, and are also covered by International Air Transport Association (IATA), International Civil Aviation Organization (ICAO), and European Ground Transportation of Dangerous Goods (ARD). It is the responsibility of the shipper to ensure compliance with these or any other local requirements.

Note

Consult current regulations and requirements before shipping.

⁽²⁾ Reference conditions are 70 °F (21 °C), transmit rate of once per minute, and routing data for three additional network devices.

5.3 Spare parts

Table 5-1: Spare Parts List

Part description	Part number
Long-life power module, Intrinsically Safe	701PBKKF
O-ring for Aluminum housing cover	00849-1603-0001
Captive screws for Aluminum housing cover	00849-1602-0001
Aluminum housing cover and captive screws ⁽¹⁾	00849-1601-0001
Electronics module	00849-1600-0001
Kit, Spare cable gland, ½-NPT, 7.5 mm - 11.9 mm (Qty 1)	00648-9010-0001
Kit, Spare cable gland, ½-NPT, thin wire, 3 mm - 8mm (Qty 1)	00648-9010-0003
Mounting bracket for 2-in. pipe mount - SST bracket and bolts	00848-4350-2001
M20 cable gland adapter (Qty 4)	00849-1605-0001

⁽¹⁾ O-ring is included.

6 Troubleshooting

6.1 Device troubleshooting

6.1.1 Cold Junction Temperature Out of Limits

Cause

The cold junction compensation temperature is outside of the allowed operating limits.

Recommended actions

1. Verify that the electronics temperature is within the device operating range.
2. Contact a service center if the condition persists.

6.1.2 Electronics failure

Description

An electronics error has occurred that could impact the device measurement reading.

Recommended actions

1. Reset the device.
2. Reconfirm all of the configuration items in the device.
3. Contact a service center if the condition persists.

6.1.3 Electronics Temperature Failure

Cause

The electronics temperature is beyond the failure limits of the transmitter.

Recommended actions

1. Make sure the device is installed in an environment within the device operating temperature range.
2. Contact a service center if the condition persists.

6.1.4 Electronics Temperature Out of Limits

Cause

The electronics temperature is outside of the operating range of the transmitter.

Recommended actions

1. Make sure the device is installed in an environment within the device operating temperature range.
2. Contact a service center if the condition persists.

6.1.5 High Power Active

Cause

The device is operating in a **high power** mode ideal for configuration situations.

Note

If the device is self-powered, using the **high power** mode for long periods of time will significantly reduce the life of the power module.

Recommended actions

1. When configuring the device, activate **high power** mode.
2. Upon completion of configuration, disable **high power** mode.

6.1.6 Process sensor excessive EMF

Cause

There is excess voltage on the process temperature sensors.

Recommended actions

1. Check the sensor wiring and connections.
2. Replace the process sensor.
3. Contact a service center if the condition persists.

6.1.7 Process sensor out of limits

Description

The process temperature sensor is out of the allowed operating range.

Recommended actions

1. Verify that the appropriate sensor is selected for the application.
2. Replace the temperature sensor with an appropriate sensor type for the process temperature range.
3. Contact a service center if the condition persists.

6.1.8 Process sensor saturated

Description

The process temperature value has saturated and can no longer track the actual process temperature measurement.

Recommended actions

1. Verify that the process temperature is within the valid operating limits of the temperature sensor and device.
2. Replace the temperature sensor.
3. Contact a service center if the condition persists.

6.1.9 Sensor failure

Description

The process temperature sensor cannot be read.

Recommended actions

1. Check the sensor wiring connections and configuration.
2. Replace the temperature sensor.
3. Contact a service center if the condition persists.

6.1.10 Sensor high alert

Cause

The temperature measurement has gone above the **high alert** configured by the user. The alert is **Active**.

Recommended actions

1. Check the process sensors and process conditions.
2. Check the user-configured alerts.

6.1.11 Sensor low alert

Cause

The temperature measurement has dropped below the **low alert** configured by the user. The alert is **Active**.

Recommended actions

1. Check the process sensors and process conditions.
2. Check the user-configured alerts.

6.1.12 Simulation Active

Cause

The device is in **simulation** mode and may not report actual information.

Recommended actions

1. Disable any simulation values.
2. Contact a service center if the condition persists.

6.1.13 Supply Voltage Failure

Cause

The supply voltage is too low for the device to function properly.

Recommended actions

Replace the power module.

6.1.14 Supply Voltage Out of Range

Cause

Low supply voltage may affect the operation of the device.

Recommended actions

Replace the power module.

6.2 Wireless network troubleshooting

6.2.1 Device not joining the network

Recommended actions

1. Verify the **Network ID** and **Join Key**.

Note

This may take up to 30 minutes to complete.

2. Enable **High Speed Operation** on Smart Wireless Gateway.
3. Check the power module and verify the device is within range of at least one other device.
4. Verify network is in active network.
5. **Power Cycle** device to try again
6. Verify device is configured to join.
7. Send the **Force Join** command to the device.
8. If the device still does not join the network, then see the **Troubleshooting** section of the [Wireless 1410 Gateway Manual](#) for more information.

6.2.2 Limited Bandwidth Error

Recommended actions

1. Reduce the **Update Rate** on the transmitter.
2. Increase communication paths by adding more wireless points.

6.2.3 Short Battery Life

Recommended actions

1. Check that **Power Always On** mode is **Off**.
2. Verify the device is not installed in extreme temperatures.
3. Verify that the device is not a network pinch point.
4. Check for excessive network rejoins from poor connectivity.

7 Appendix

7.1 Product certifications

To view current product certifications:

Procedure

1. Go to [Emerson.com/Rosemount/848T Wireless Temperature Transmitter](https://emerson.com/Rosemount/848T-Wireless-Temperature-Transmitter).
2. Scroll as needed to the green menu bar and click **Documents & Drawings**.
3. Click **Manuals & Guides**.
4. Select the appropriate **Quick Start Guide**.

7.2 View ordering, information, specifications, and dimensional drawings

To view current Rosemount 848T Wireless ordering information, specifications, and dimensional drawings:

Procedure

1. Go to [Emerson.com/Rosemount/848T Wireless Temperature Transmitter](https://emerson.com/Rosemount/848T-Wireless-Temperature-Transmitter).
2. Scroll as needed to the green menu bar and click **Documents & Drawings**.
3. Click **Data Sheets & Bulletins**.
4. Select the appropriate **Product Data Sheet**.

For more information: [Emerson.com/global](https://emerson.com/global)

©2024 Emerson. All rights reserved.

Emerson Terms and Conditions of Sale are available upon request. The Emerson logo is a trademark and service mark of Emerson Electric Co. Rosemount is a mark of one of the Emerson family of companies. All other marks are the property of their respective owners.

ROSEMOUNT™

