Fisher™ Parts Manuals and Kitting Documents

ENVIRO-SEAL™ Packing Instructions

Gasket Assembly

Installation Instructions

Instruction Manuals

Safety Instructions

Mounting Instructions

FIELDVUE™ Instruments Mounting Instructions



ENVIRO-SEAL™ Packing Instructions

Design A, E, EH, HP, YD, and YS – 3/4-1/2 Inch

Design A, E, EH, HP, YD, and YS – 3/8-1/2 Inch

Design A, E, EH, HP, YD, and YS – Duplex

Design E, EH, HP, YD, & YS - Graphite ULF Packing

Design BF & BFC

Design CP - Graphite - Single

H2 Duplex High-Pressure Packing

Graphite Rotary Valve Packing Types CV500, V100, V150, V200, V260, V300, V500, 8510, 8550, and 8560

PTFE Rotary Valve Packing Types CV500, V100, V150, V200, V260, V300, V500, 8510, 8550, and 8560

PTFE Rotary Valve PackingTypes 8522, 8532, A31, A31A, A31D, B21A

PTFE Rotary Valve Packing
Outboard End Packing Arrangement for 8510

RCPXPACK012 - 022 - 222

RCPXPACK112 and RCPXPACK122

Gasket Assembly

RGASKETX162 - 312 - 422

RGASKETX172 - 322 - 432

RGASKETX182 - 332 - 442

RGASKETX192 - 342 - 452

RGASKETX202 - R52 - 462

RGASKETX212 - 362 - 472

RGASKETX222 - 372 - 482

RGASKETX232

RGASKETX262

RGASKETX242

RGASKETX272

RGASKETX252

RGASKETX282

Gasket continues next page

Gasket Assembly

RGASKETX382 and RGASTKET392

RGASKETX402 and RGASKET412

RGASKETXB62	RGASKETXC22
RGASKETXB72	RGASKETXC32
RGASKETXB82	RGASKETXC42
RGASKETXB92	RGASKETXC52
RGASKETXC12	RGASKETXC62

Installation Instructions

Design CP Single Graphite Packing

DVC6200 Digital Valve
Controller Spare Housing Assemblies

GX Replacement Parts

RCPXPKRT012 - 022 - 032 - 042 - 052 - 062 - 192 - 242

RCPXPACK132 - 142 - 152 - 162

RGLX0000012 - 022 - 032 - 042 - 052

Instruction Manuals

657 Diaphragm Actuator

667 Diaphragm Actuator

L2e Electric Level Controller

Replacing the Controller Assembly (RL2E0X00C22) on the
Fisher™ L2e Electric Level Controller

Seal and O-ring Installation InstructionsSupplement to
Fisher™ 685 Series Instruction Manuals

Safety Instructions

Safety Instructions 5740 10/01

FIELDVUE™ Instruments Mounting Instructions

1051 and 1052 Size 33 Actuators - End Mount

1051 and 1052 Size 40-70 Actuators - End Mount

1052 Size 20 Actuator - End Mount

1061 Size 80-100 Actuator - Window Mount

1066 Size 20/27 Actuator - End Mount

1066 Size 75 Actuator - End Mount

2052 Size 1, 2 & 3 Actuator - End Mount

585C and 471 Size 60-130 with 0.56 to 4 Inch Travel
Except 585C Size 68

585C and 471-16, Size 60-130 with 4 to 8 Inch Travel

585C Size 68 with 0.56 to 2.00 Inch Travel

585C and 585CR Size 25 Actuators with or without Handjack

585C and 585CR Size 50 Actuators with or without Handjack

657 and 667 Size 30-60 Actuators

657 and 667 Size 34-60 Actuators with Handwheel

657 and 667, Size 70, 76 & 87 Actuators - 4 Inch Travel

657 and 667, Size 70, 76 & 87 Actuators - 2 Inch Travel

Baumann Sliding-Stem Actuators

GX Control Valve and Actuator System

IEC60534-6-1 (Old NAMUR) Sliding Stem Actuator

Packing Instructions

RPACKX00012 - 022 - 032 - 342 - 352

RPACKX00042 - 052 - 062 - 362 - 372

RPACKX00072 - 082 - 092

RPACKX00102 and RPACKX00132

RPACKX00112 and RPACKX142

RPACKX00122 and RPACKX152

RPACKX00162

RPACKX00172

RPACKX00182

RPACKX00512

RPACKX00522 - RPACKX00532 - RPACKX00542

RPACKX00552