


Type 1290



- █ INLET PRESSURE
- █ ATMOSPHERIC PRESSURE
- █ LOADING PRESSURE
- █ INTERMEDIATE PRESSURE
- █ TANK PRESSURE

