


Type 92B



- █ INLET PRESSURE
- █ OUTLET PRESSURE
- █ ATMOSPHERIC PRESSURE
- █ LOADING PRESSURE

