

Actuator assembly codes

Single acting (Spring Return) assembly codes

Standard assembly code: (= Clock Wise Rotation / Spring to Close)	CW
Visual indicator mounted: (= for In line position indication)	I

Optional assembly code: (= Counter Clock Wise Rotation/ Spring to Open)	CC
Visual indicator mounted: (= for In line position indication)	I

Optional assembly code: (= Clock Wise Rotation / Spring to Close)	CW
Visual indicator mounted: (= for Cross line position indication)	C

Optional assembly code: (= Counter Clock Wise Rotation/ Spring to Open)	CC
Visual indicator mounted: (= for Cross line position indication)	C

A = Pilot valve operated in Control Module
B = Pilot valve not operated in Control Module

- Central air chamber (1) pressurized
- Spring stroke (2)

All views are from above. Pistons are shown in inner position