

Infrared Remote Control for 5081 Analyzer

Please note the following notifications and instructions for use of PN 24479-00:

- Do not use harsh chemicals or abrasive brushes when cleaning the remote controller.
- If the Green LED does not light upon pressing any key, a weak battery is the probable cause. To restore operation, remove four screws to access and replace the two batteries. Observe warning messages posted at the rear of the remote control.
- Requires two 1.5V AAA batteries. If used in hazardous areas, replacement batteries must be Energizer E92/EN92 or Duracell MN2400/PC2400.
- All functions for remote control PN 24479-00 are the same as previous remote control PN 23572-00.



Remote Control information on back

<p>FM APPROVED</p> <p>IS/II/1/ABCD T4 CLASS I ZONE 0 AEx ia IIC T4 -20°C ≤ Ta ≤ +50°C</p> <p>Ex IECEx BAS 13.0108 Baseefa02ATEX0198 II 1G Ex ia IIC T4 Ga -20°C ≤ Ta ≤ +50°C</p> <p>CE 1180</p>	<p>IRC – INFRARED REMOTE CONTROL PN 24479-00</p> <p>SP LR34186 c US Ex ia IIC T4 CLASS I ZONE 0 AEx ia IIC T4 INTRINSICALLY SAFE SÉCURITÉ INTRINSÈQUE CLASS I DIVISION 1 GROUPS A,B,C,D T4 -20°C ≤ Ta ≤ +50°C</p>	<p>WARNING: SUBSTITUTION OF COMPONENTS MAY IMPAIR INTRINSIC SAFETY. TO PREVENT IGNITION, ONLY CHANGE BATTERIES IN NONHAZARDOUS AREA.</p> <p>AVERTISSEMENT: LA SUBSTITUTION DE COMPOSANTS PEUT COMPROMETTRE LA SÉCURITÉ INTRINSÈQUE. POUR PRÉVENIR L'INFLAMMATION D'ATMOSPHERE, NE CHANGER LES BATTERIES QUE DANS DES EMPLACEMENTS DESIGNES NON DANGEREUX.</p> <p>USE ONLY ENERGIZER E92/EN92 OR DURACELL MN2400/PC2400 (2) 1.5V AAA BATTERIES.</p>
---	---	--