


# Type FL with Type PRX/131 Booster



- INLET PRESSURE
- OUTLET PRESSURE
- ATMOSPHERIC PRESSURE
- LOADING PRESSURE
- PILOT SUPPLY PRESSURE