

# X-STREAM Enhanced Suppressed Range 98–100 % CO<sub>2</sub>–Gas Purity

## Overview

The X-STREAM *Enhanced* analyzer provides CO<sub>2</sub> gas purity measurement with a full range of 0–100 % CO<sub>2</sub> and a suppressed range of 98–100 % CO<sub>2</sub>.

## Features

- Nitrogen purged thermostated photometer containment
- Barometric pressure compensation
- Internal pressure regulator, filter and capillary
- Sample flow measurement as option
- Table-top or rack-mountable analyzer
- 4 ranges per channel
- Autocalibration via internal or external valve block, controlled by digital I/O, serial interface, network, time-programmed
- Alternatively manual zero and span adjustment
- Analog, digital and serial I/Os
- Other suppressed ranges e. g. for O<sub>2</sub>, H<sub>2</sub> and N<sub>2</sub>O available.

## Technical Information

Housed in a total 19-inch enclosure with thermostat control, the X-STREAM *Enhanced* Gas Analyzer for CO<sub>2</sub> gas purity can measure two ranges of CO<sub>2</sub> on a single bench: An absolute range of 0–100 % CO<sub>2</sub> and a suppressed range of 98–100 %.

The main advantage is that calibration can be done in the absolute range using pure nitrogen as zero gas and pure carbon dioxide as span gas thus avoiding zeroing with inaccurate and more expensive calibration gas (98 % +/- x %) as zero gas for the suppressed range. Since suppressed ranges are depending much more on the influence of pressure, temperature and flow, special measures are necessary to keep those constant and run special compensation methods additionally (internal pressure regulator, capillary & pressure sensor; temperature & pressure compensation).

Therefore, the standard calibration interval has to be changed for the non-standard suppressed range. A daily calibration has to be carried out with 100 % N<sub>2</sub> and 100 % CO<sub>2</sub>. Due to the big change from 98–100 % CO<sub>2</sub> to 100 % N<sub>2</sub> (0 % CO<sub>2</sub>) a purge time of more than 240 seconds is required before running a zero adjustment. The same purge time is necessary to switch over to span gas or sample gas. To achieve the best results sample, zero and span gases need to be kept at constant temperature within the range of permissible ambient temperature.



X-STREAM Enhanced XEGP

## Calibration Procedure

Calibration is carried out within the absolute range:

- 0–100 % CO<sub>2</sub>

Run span gas calibration only after having carried out a zero calibration:

- zero gas: 100 % N<sub>2</sub>
- span gas: 100 % CO<sub>2</sub>

Zero and span calibration requires a certain purge time, after which the calibration routine with stability and averaging procedures takes place (calibration time). Purge time is also required after return from zero or span to sample gas.

Analyzer factory settings:

- purge time: >240 s (from sample to zero; from zero to span)
- calibration time: approximately 40 s
- purge time: >240 s (from zero to span or sample; span to zero)

Notes:

- The factory settings for calibration purge time covers the gas path from the X-STREAM gas inlet only, and does not include such times for an external sample handling system.
- All calibration gases have to be kept at the same temperature as sample gas. Sample gas has to be conditioned to the ambient temperature of the analyzer.

## General

Installation of the analytical equipment (gas analyzer, sample handling system and calibration gases) should be in an air conditioned room or at least in a well ventilated housing.

# Gas Production & Distribution

0–100 % CO <sub>2</sub> Enhanced Performance Specifications		98–100 % CO <sub>2</sub> Performance Specifications		
Detection limit (4 σ) <sup>(1)(4)</sup>	≤ 0.5 %	Detection limit (4 σ) <sup>(1)(4)</sup>	≤ 2 %	
Linearity <sup>(1)(4)</sup>	≤ 1 %	Linearity <sup>(1)(4)</sup>	≤ 1 %	
Zero-point drift <sup>(1)(4)</sup>	≤ 1 % per week	Zero-point drift <sup>(1)(4)(5)</sup>	≤ 2 % per day	
Span (sensitivity) drift <sup>(1)(4)</sup>	≤ 1 % per month	Span (sensitivity) drift <sup>(1)(4)(5)</sup>	≤ 2 % per day	
Repeatability <sup>(1)(4)</sup>	≤ 0.5 %	Repeatability <sup>(1)(4)</sup>	≤ 2 %	
Response time (t <sub>90</sub> ) <sup>(3)</sup>	4 s ≤ t <sub>90</sub> ≤ 7 s	Response time (t <sub>90</sub> ) <sup>(6)</sup>	≤ 30 s	
Permissible gas flow	0.2–1.5 l/min	Permissible gas flow	defined by constant pressure at inlet	
Influence of gas flow <sup>(1)(4)</sup>	≤ 0.5 %	Permissible gas pressure	1300 hPa (4.4 psig)–1700 hPa (10.1 psig)	
Maximum gas pressure <sup>(8)</sup>	≤ 1500 hPa abs. (≤ 7 psig)	Permissible gas pressure variation	± 70 hPa (1 psig)	
Influence of ambient pressure <sup>(2)</sup>		Influence of ambient pressure change from 800 to 1100 hPa at constant temperature with pressure compensation <sup>(1)(7)</sup>		
– At constant temperature	≤ 0.10 % per hPa			
– With pressure compensation <sup>(7)</sup>	≤ 0.01 % per hPa		≤ 2 %	
Permissible ambient temperature	0 to +50 °C (32 to 122 °F)	Permissible ambient temperature	15 to 35 °C (59 to 95 °F)	
Influence of temperature <sup>(1)(10)</sup> (at constant pressure)		Influence of temperature <sup>(1)(10)</sup> (at constant pressure)		
– On zero point	≤ 0.5 % per 10 K		– On zero point	≤ 0.5 % per 10 K
– On span (sensitivity) <sup>(11)</sup>	≤ 5 %		– On span (sensitivity) <sup>(11)</sup>	≤ 2 %
Thermostat control <sup>(9)</sup>	none / 60 °C (140 °F)	Thermostat control	60 °C (140 °F)	
Warm up time	15 to 50 minutes	Warm up time	approx. 50 minutes	
		Purge gas (N <sub>2</sub> ) flow	approx. 0.1- 0.2 l/min	

\*NOTE: 1psi = 68.95 hPa

(1) Related to f. s. (absolute range) or suppressed range (98–100 %)

(2) Related to measuring value

(3) From gas analyzer inlet at gas flow of 1.0 l/min (electronic damping = 0 s)

(4) Constant pressure and temperature

(5) Daily zero and span calibration requested

(6) Switching from absolute to suppressed range requires purge time of > 240 s

(7) Sample gas pressure sensor mandatory

(8) Limited to atmospheric if internal sample pump

(9) Optional thermostatically controlled box with temperature 60 °C (140 °F)

(10) Temperature variation: ≤ 10 K per hour

(11) Related to permissible ambient temp. range

[www.RosemountAnalytical.com](http://www.RosemountAnalytical.com)

## EUROPE

**Emerson Process Management GmbH & Co. OHG**

Rosemount Analytical  
Process Gas Analyzer Center of Excellence

Industriestrasse 1  
63594 Hasselroth, Germany

T +49 6055 884 0

F +49 6055 884 209

[www.RosemountAnalytical.com](http://www.RosemountAnalytical.com)



## ASIA-PACIFIC

**Emerson Process Management**

Asia Pacific Private Limited

1 Pandan Crescent

Singapore 128461

Republic of Singapore

T +65 6 777 8211

F +65 6 777 0947

[analytical@ap.emersonprocess.com](mailto:analytical@ap.emersonprocess.com)

[www.RosemountAnalytical.com](http://www.RosemountAnalytical.com)

## MIDDLE EAST AND AFRICA

**Emerson Process Management**

Emerson FZE

P.O Box 17033

Jebel Ali Free Zone

Dubai, United Arab Emirates

T +971 4 811 8100

F +971 4 886 5465

[analytical@ap.emersonprocess.com](mailto:analytical@ap.emersonprocess.com)

[www.RosemountAnalytical.com](http://www.RosemountAnalytical.com)

©2012 Emerson Process Management. All rights reserved.

## AMERICAS

**Emerson Process Management**

Rosemount Analytical

Gas Chromatograph Center of Excellence

10241 West Little York, Suite 200

Houston, TX 77040 USA

Toll Free 866 422 3683

T +1 713 396 8880 (North America)

T +1 713 396 8759 (Latin America)

F +1 713 466 8175

[gc.csc@emerson.com](mailto:gc.csc@emerson.com)

The Emerson logo is a trademark and service mark of Emerson Electric Co. Rosemount Analytical is a mark of one of the Emerson Process Management family of companies. All other marks are the property of their respective owners.

The contents of this publication are presented for information purposes only, and while effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the designs or specifications of our products at any time without notice.

**ROSEMOUNT**  
Analytical

42-PGA-AN-GPD-XSTREAM-XE-SR

  
**EMERSON**  
Process Management