Product Data Sheet 00813-0100-2240, Rev AC June 2020

# Rosemount<sup>™</sup> 2240S Multi-input Temperature Transmitter

for tank gauging systems



# Provides multiple spot temperature measurement in liquid storage tanks, used for average temperature calculation and stratification correction

- Obtain outstanding temperature conversion accuracy of ±0.05 °C (±0.09 °F)
- Get ultra-stable temperature measurement for precise inventory calculations and custody transfer for API chapter 7.3 compliance
- Connect up to sixteen 3- or 4-wire temperature elements
- Include integrated water level sensor
- Benefit from convenient and safe installation with 2-wire IS bus power supply



ROSEMOUNT

# Exact net volume calculations with highest precision average temperature measurement

The Rosemount 2240S Multi-input Temperature Transmitter provides multiple spot temperature measurement in liquid storage tanks. It is used for calculation of the average temperature of the liquid and corrects for stratification.

The Rosemount 2240S is approved for demanding custody transfer applications, which require very accurate level and temperature measurements for net standard volume calculations. It has an ultra high temperature conversion accuracy of  $\pm 0.05$  °C ( $\pm 0.09$  °F). The IP 66/67 and NEMA<sup>®</sup> 4X certified robust design makes it suitable for installation in harsh environments.

The temperature transmitter supplies measured data, such as temperature and water level, via the intrinsically safe 2-wire Tankbus, to a Rosemount 2410 Tank Hub. Measurement data and status information can be viewed on a PC with the Rosemount TankMaster software, as well as on the integral display of the tank hub and the Rosemount 2230 Graphical Field Display.





- A. TankMaster PC
- B. Modbus<sup>®</sup> RTU/TCP
- C. Rosemount 2460 System Hub
- D. Tankbus
- E. Rosemount 2410 Tank Hub
- F. Rosemount 2240S Multi-input Temperature Transmitter with Rosemount 765 Multiple Spot Temperature and Water Level Sensor
- G. Rosemount 5900S Radar Level Gauge
- H. Rosemount 2230 Graphical Field Display
- I. Rosemount 3051S Pressure Transmitter
- J. Rosemount 644 Temperature Transmitter with Rosemount 65, 114C, or 214C Single Point Temperature Sensor

#### Contents

xact net volume calculations with highest precision average temperature measurement	2
Drdering information	4
pecifications	9
' Product certifications	15
Dimensional drawings	.23

# Highly accurate multiple spot temperature and water level sensors

Rosemount 2240S can connect up to sixteen 3- or 4-wire temperature spot elements and an integrated water level sensor. The value from each individual spot temperature element, in combination with the level value from the radar gauge is used for average liquid temperature calculation.

The water level sensor is factory calibrated. If any adjustment is necessary during installation, it can easily be done with the Rosemount 2240S built-in on-line calibration feature.

Available temperature sensor versions are:

- Rosemount 565 Multiple Spot Temperature Sensor
- Rosemount 566 Multiple Spot Temperature Sensor for cryogenic applications such as LNG
- Rosemount 765 Multiple Spot Temperature Sensor with Integrated Water Level Sensor
- Rosemount 614 Cryogenic Spot Temperature Sensor

### Precise and reliable measurements in cryogenic storage tanks

The Rosemount 2240S Multi-input Temperature Transmitter provides complete temperature measurements for cryogenic and refrigerated full containment storage.

Figure 2 illustrates an LNG Tank Gauging system with temperature transmitters for average liquid temperature measurement and online redundant temperature stratification monitoring. The system also includes temperature transmitters for skin/cool-down temperature measurement (white dotted line) and leak detection (red dotted line).



#### Figure 2: Liquefied Natural Gas (LNG) Tank Gauging System

- A. Separate device for temperature and density profiling (LTD)
- B. Rosemount 2240S Multi-input Temperature Transmitter with Rosemount 566 Multiple Spot Temperature Sensor
- C. Rosemount 2240S Multi-input Temperature Transmitter with Rosemount 614 Cryogenic Spot Temperature Sensor

# Ordering information

# **Specifications and options**

See the Specifications and options section for more details on each configuration. Specification and selection of product materials, options, or components must be made by the purchaser of the equipment. See the Material selection section for more information.

# **Model codes**

Model codes contain the details related to each product. Exact model codes will vary; an example of a typical model code is shown in Figure 3.

#### Figure 3: Model Code Example

2240S P 16 4 A F I1 0 A 1 M 1 2 WR3 ST

- 1. Required model components (choices available on most)
- 2. Additional options (variety of features and functions that may be added to products)

# Rosemount 2240S Multi-Input Temperature Transmitter



The ultra-stable Rosemount 2240S is approved for demanding custody transfer applications, which require very accurate temperature measurements for net standard volume calculations. It can be used with a Rosemount 565, 566, or 765 temperature sensor. The Rosemount 2240S connects up to sixteen 3- or 4-wire temperature spot elements and an integrated water level

Rosemount 2240S provides average liquid temperature for net volume calculation based on each individual spot temperature element in combination with the corresponding level value. It has an impressive temperature conversion accuracy of  $\pm 0.05$  °C ( $\pm 0.09$  °F).

VIEW PRODUCT >

sensor.

#### **Required model components**

#### Model

Code	Description
22405	Multi-input Temperature Transmitter

#### Performance class

Code	Description
Р	Premium

#### Number of temperature sensor inputs

Code	Description
16 <sup>(1)</sup>	Up to 16xRTD spot elements
08 <sup>(1)</sup>	Up to 8xRTD spot elements
04 <sup>(1)</sup>	Up to 4xRTD spot elements
00 <sup>(2)</sup>	None

(1) Temperature sensors of Pt-100 or Cu-90 type, for use in -200 to 250 °C (-328 to 482 °F), can be connected to the Rosemount 2240S.

(2) Water level sensor only requires Number of temperature sensor inputs code 00, Temperature elements wiring code 0, and Auxiliary inputs code A.

#### **Temperature elements wiring**

Code	Description
4	4-wire or 3-wire (individual or common return)
0 <sup>(1)</sup>	None (for water level only, no temperature sensors)

(1) Water level sensor only requires Number of temperature sensor inputs code 00, Temperature elements wiring code 0, and Auxiliary inputs code A.

#### Rosemount 2240S

#### **Auxiliary inputs**

Code	Description
A <sup>(1)</sup>	Rosemount 765 temperature and water level sensor input
0	None

(1) Water level sensor only requires Number of temperature sensor inputs code 00, Temperature elements wiring code 0, and Auxiliary inputs code A.

#### Tankbus: Power and communication

Code	Description
F	Bus powered 2-wire Foundation <sup>™</sup> Fieldbus (IEC 61158)

#### Hazardous location certification

Code	Description
11	ATEX Intrinsic Safety
12	Brazil Inmetro Intrinsic Safety
14	Japan Intrinsic Safety
15	FM-US Intrinsic Safety
16	FM-Canada Intrinsic Safety
17	IECEx Intrinsic Safety
IM	Technical Regulations Customs Union (EAC) Intrinsic Safety
IP	KC Intrinsic Safety (South Korea)
NA	No Hazardous Location Certification

#### Custody transfer type approval

Code	Description
$C^{(1)(2)(3)}$	PTB (German W&M approval)
G <sup>(2)(3)</sup>	GUM (Poland)
K <sup>(2)(3)</sup>	GOST (Kazakhstan)
S <sup>(2)(3)</sup>	GOST (Russia)
0	None

(1) Approval plate, sealing kit and Eich adapter included. One spot position used for external reference.

Available spot elements in Number of temperature sensor inputs = 15, 7, or 3.

(2) Requires Rosemount 2410 Tank Hub with corresponding Custody transfer type approval.

(3) Requires one out of following displays: Rosemount 2410 with integral display, Rosemount 2230 with corresponding Custody transfer type approval, or TankMaster.

#### Housing

Code	Description
A	Standard enclosure (polyurethane-covered aluminum IP 66/67)

#### Cable/Conduit connections

Code	Description
1	1/2-14 NPT, female thread (includes 2 plugs)
2	M20 x 1.5 adapters, female thread (includes 2 plugs, and 3 adapters)
G <sup>(1)</sup>	Metal cable glands (½-14 NPT)
E	Eurofast <sup>®</sup> male connector and ½-14 NPT (includes 2 plugs)
М	Minifast <sup>®</sup> male connector and ½-14 NPT (includes 2 plugs)

(1) Minimum temperature -20 °C (-4 °F). ATEX / IECEx. Exe approved. Includes 2 plugs, and 3 glands (includes an M32 gland if combined with Mechanical installation code W or P).

#### **Mechanical installation**

Code	Description
M <sup>(1)</sup>	Prepared for integrated installation with Rosemount 565, 566, or 765 (standard) temperature sensor
W <sup>(2)</sup>	Installation kit for wall mounting
P <sup>(2)</sup>	Installation kit for wall and pipe mounting (1-2 in. vertical and horizontal pipes)

(1) M33x1.5 female threaded connection. As standard, the transmitter is not pre-assembled with any temperature sensor.

(2) For separate installation of temperature sensor and transmitter.

#### **Additional options**

#### Tag plate

Code	Description
ST	Engraved SST tag plate

#### **Conformance certificate**

Code	Description
Q1	Certificate of conformance

#### **Calibration certificate**

Code	Description
Q4	Calibration certificate

#### Hazardous location certificate

Code	Description
Q7	Printed copy of hazardous location certificate

#### Extended product warranty

Rosemount extended warranties have a limited warranty of three or five years from date of shipment.

Code	Description
WR3	3-year Limited Warranty
WR5	5-year Limited Warranty

# **Specifications**

# **Performance specifications**

#### Temperature conversion accuracy

±0.05 °C (±0.09 °F) Over measuring range and ambient temperature 20 °C (68 °F)

#### Ambient temperature effect

±0.05 °C (±0.09 °F) within the total range; -40 to 70 °C (-40 to 158 °F)

#### Temperature measuring range

Supports -200 to 250 °C (-328 to 482 °F) for Pt-100

#### Resolution

 $\pm$  0.1 °C (± 0.1 °F) according to API chapter 7 and 12

#### **Update time**

4 seconds

# **General specifications**

#### **Material selection**

Emerson provides a variety of Rosemount products with various product options and configurations including materials of construction that can be expected to perform well in a wide range of applications. The Rosemount product information presented is intended as a guide for the purchaser to make an appropriate selection for the application. It is the purchaser's sole responsibility to make a careful analysis of all process parameters (such as all chemical components, temperature, pressure, flow rate, abrasives, contaminants, etc.), when specifying product, materials, options, and components for the particular application. Emerson is not in a position to evaluate or guarantee the compatibility of the process fluid or other process parameters with the product, options, configuration or materials of construction selected.

#### Number of spot elements and wiring

Up to 16 RTD spot elements or averaging sensors can be connected to a Rosemount 2240S.

#### Rosemount temperature / water level sensors (models 565, 566, and 765)

Three wiring types can be used:

- 3-wire RTD with common return (1-16 spot elements)
- 3-wire RTD individual:
  - 1-16 spot elements with Rosemount 565 and 566
  - 1-14 spot elements with Rosemount 765

- 4-wire RTD individual:
  - 1-16 spot elements with Rosemount 565 and 566
  - 1-10 spot elements with Rosemount 765

#### Rosemount 614 Cryogenic Spot Temperature Sensor

The following wiring types can be used:

- 3-wire RTD individual (1-16 spot elements)
- 4-wire RTD individual (1-16 spot elements)

#### Standard temperature sensor types

Supports Pt-100 (according to IEC/EN60751, ASTM E1137) and Cu-90

#### Metrology sealing possibility

Yes

#### Write protect switch

Yes

# **Configuration specifications**

#### **Configuration tool**

TankMaster WinSetup is the recommended tool for easy configuration of Rosemount 2240S. The Tankbus autoconfiguration feature, handled by the Rosemount 2410 Tank Hub, supports Rosemount 2240S.

#### **Configuration parameters (examples)**

#### Temperature

- Number of temperature sensor elements
- Temperature element type (spot or average)
- Temperature element position in tank

#### Water level sensor

- Level offset (difference between tank zero level and water zero level)
- Probe length (autoconfigured by Rosemount 765)

#### **Output variables and units**

Spot and average temperature: °C (Celsius), and °F (Fahrenheit) Free water level (FWL): meter, centimeter, millimeter, feet, or inch

# FOUNDATION<sup>™</sup> Fieldbus characteristics

#### **Polarity sensitive**

No

### Quiescent current draw

30 mA

#### Lift-off minimum voltage

9.0 VDC

#### **Device capacitance inductance**

See Product certifications

#### FOUNDATION Fieldbus class (basic or Link Master)

Link Master (LAS)

#### Number of available VCRs

Maximum 20, including one fixed

#### Links

Maximum 40

#### Minimum slot time / maximum response delay / minimum intermessage delay

8/5/8

#### **Blocks and execution time**

Block	Execution time
1 Resource	N/A
3 Transducer (Temperature, Register, AVG_Temp)	N/A
2 Multiple Analog Input (MAI)	15 ms
6 Analog Input (AI)	10 ms
1 Analog Output (AO)	10 ms
1 Signal Characterizer (SGCR)	10 ms
1 Proportional/Integral/Derivate (PID)	15 ms
1 Integrator (INT)	10 ms
1 Arithmetic (ARTH)	10 ms
2 Input Selector (ISEL)	10 ms
1 Control Selector (CS)	10 ms
1 Output Splitter (OS)	10 ms

For more information, see the FOUNDATION<sup>™</sup> Fieldbus Blocks Manual.

#### Instantiation

Yes

**Conforming FOUNDATION<sup>™</sup> Fieldbus** 

ITK 6

#### **Field Diagnostics support**

Yes

#### Action support wizards

Restart/stop measurement, write protect device, factory reset - measurement configuration, reset statistics, start/stop device simulation

#### **Advanced diagnostics**

Failures/Maintenance/Advisory alerts: Software, memory/database, electronics, internal communication, simulation, auxiliary device, auxiliary device measurement, ambient temperature, average temperature measurement, temperature measurement, configuration

# **Electrical specifications**

#### **Power supply**

FISCO: 9.0 - 17.5 VDC polarity insensitive (for example from Rosemount 2410 Tank Hub) Entity: 9.0 - 30.0 VDC polarity insensitive

#### Internal power consumption

0.5 W

**Bus current draw** 

30 mA

**Tankbus cabling** 0.5-1.5 mm<sup>2</sup> (AWG 22-16), twisted shielded pairs

#### Built-in Tankbus terminator

Yes (to be connected if required)

#### Tankbus to sensor isolation

Minimum 700 VAC

#### **Auxiliary sensor input**

Digital bus connection for water level sensor

# **Mechanical specifications**

#### **Housing material**

Polyurethane-coated die-cast aluminum

#### Cable entry (connection/glands)

Three  $\frac{1}{2}$  - 14 NPT entries for cable glands or conduits. Two metal plugs to seal any unused ports are enclosed in the delivery. Optional:

- M20 x 1.5 conduit / cable adapter
- Cable glands in metal (½ 14 NPT)
- 4-pin male eurofast connector or A size Mini 4-pin male minifast connector

#### Rosemount 565/566/765 connection

M33 x 1.5 female threaded connection Optional:

An M32 adapter or M32 gland can be used if the Rosemount 2240S is installed away from the sensor

#### **Rosemount 614 connection**

Optional cone with M33 x 1.5 female threaded connection

#### Installation

The Rosemount 2240S can be installed directly on top of the temperature / water level sensor or remotely installed on a 33.4-60.3 mm (1 to 2-in) pipe or on a wall

#### Weight

2.8 kg (6.2 lbs)

# **Environmental specifications**

#### **Ambient temperature**

-40 to 70 °C (-40 to 158 °F) Minimum start-up temperature -50 °C (-58 °F)

#### Storage temperature

-50 to 85 °C (-58 to 185 °F)

#### Humidity

0-100% relative humidity

#### **Ingress protection**

IP 66 and 67 (NEMA<sup>®</sup> 4X)

#### Transient / built-in lightning protection

According to IEC 61000-4-5, level 1 kV line to ground. Complies with IEEE 587 Category B transient protection and IEEE 472 surge protection.

# Product certifications

Rev 2.9

# **European directive information**

The most recent revision of the EU Declaration of Conformity can be found at Emerson.com/Rosemount.

# **Ordinary location certification**

As standard, the transmitter has been examined and tested to determine that the design meets the basic electrical, mechanical, and fire protection requirements by a nationally recognized test laboratory (NRTL) as accredited by the Federal Occupational Safety and Health Administration (OSHA).

# **Installing equipment in North America**

The US National Electrical Code<sup>®</sup> (NEC) and the Canadian Electrical Code (CEC) permit the use of Division marked equipment in Zones and Zone marked equipment in Divisions. The markings must be suitable for the area classification, gas, and temperature class. This information is clearly defined in the respective codes.

# North America

#### 15 USA Intrinsic Safety (IS)

Certificate	FM 3035518
Standards	FM Class 3600 – 2011;
	FM Class 3610 – 2010;
	FM Class 3810 – 2005;
	ANSI/ISA 60079-0 – 2013;
	ANSI/ISA 60079-11 – 2013;
	ANSI/ISA 60079-26 – 2011;
	ANSI/IEC 60529 – 2004;
	ANSI/NEMA 250 – 2008
Markings	IS / I,II,III / 1 / ABCDEFG / T4 Ta = -50°C to 70°C; 9240040-910 Entity/FISCO; Type 4X/IP66/IP67
	I / 0 / AEx ia IIC / T4 Ta = -50°C to 70°C; 9240040-910 Entity/FISCO; Type 4X/IP66/IP67
	I / 1 / AEx ib [ia] IIC T4 Ta = -50°C to 70°C; 9240040-910 FISCO; Type 4X/IP66/IP67

#### Special Conditions for Safe Use (X):

- 1. The enclosure contains aluminum and is considered to present a potential risk of ignition by impact or friction.
- 2. Rating I / 1 / AEx ib [ia] IIC T4 Ta = -50°C to 70°C; 9240040-910 FISCO; Type 4X/IP66/IP67 is only applicable when supplied from an FM certified AEx [ib] FISCO Power Supply with triplicate output voltage limitation meeting the requirements for two faults ("ia" voltage limitation).
- 3. The Rosemount 2240S Multi-Input Temperature Transmitter will not pass the 500Vrms dielectric strength test and this must be taken into account during installation.

	Ui	li	Pi	Ci	Li
Entity parameters	30 V	300 mA	1.3 W	2.2 nF	2 μH
FISCO parameters	17.5 V	380 mA	5.32 W	2.2 nF	2 μH

#### 16 Canada CSA Intrinsically Safe

Certificate	3035518C
Standards	CSA-C22.2 No. 157-92 1992 (2012),
	CSA-C22.2 No. 1010-1 2004 (2009),
	CSA-C22.2 No. 25-1966 1992 (2009),
	CSA-C22.2 No. 60529-05 2005 (2010),
	CSA-C22.2 No. E60079-0 2011,
	CSA-C22.2 No. E60079-11 2011,
	CSA-C22.2 No. 94 2011
Markings	IS / I,II,III / 1 / ABCDEFG / T4 Ta = -50°C to 70°C; 9240040-910 Entity/FISCO; Type 4X/IP66/IP67
	l / 0 / Ex ia IIC / T4 Ta = -50°C to 70°C; 9240040-910 Entity/FISCO; Type 4X/IP66/IP67
	l / 1 / Ex ib [ia] IIC T4 Ta = -50°C to 70°C 9240040-910 FISCO; Type 4X/IP66/IP67

#### Special Conditions for Safe Use (X):

- 1. The enclosure contains aluminum and is considered to present a potential risk of ignition by impact or friction.
- 2. Rating I / 1 / Ex ib [ia] IIC T4 Ta = -50°C to 70°C 9240040-910 FISCO; Type 4X/IP66/IP67 is only applicable when supplied from an FM certified Ex [ib] FISCO Power Supply with triplicate output voltage limitation meeting the requirements for two faults ("ia" voltage limitation).
- 3. The Rosemount 2240S Multi-Input Temperature Transmitter will not pass the 500Vrms dielectric strength test and this must be taken into account during installation.

	Ui	li	Pi	Ci	Li
Entity parameters	30 V	300 mA	1.3 W	2.2 nF	2 μH
FISCO parameters	17.5 V	380 mA	5.32 W	2.2 nF	2 μH

# Europe

#### **I1 ATEX Intrinsic Safety**

Certificate	FM09ATEX0047X
Standards	EN 60079-0:2012, EN 60079-11:2012, EN 60079-26:2007, EN 60529:2013
Markings:	©FISCO Field Device
	II 1 G Ex ia IIC T4 Ta = -50°C to 70°C Entity/FISCO; IP66, IP67
	II 2(1) G Ex ib [ia] IIC T4 Ta = -50°C to 70°C FISCO; IP66, IP67

#### Special Conditions for Safe Use (X):

1. The enclosure contain aluminum and is considered to present a potential risk of ignition by impact or friction. Care must be taken during installation and use to prevent impact or friction.

- Rating II 2(1) G Ex ib [ia] IIC T4 Ta = -50°C to 70°C FISCO 9240040-976; IP66, IP67 is only applicable when supplied from a certified Ex [ib] FISCO Power Supply with triplicate output voltage limitation meeting the requirements for two faults ("ia" voltage limitation).
- 3. The Rosemount 2240S Multi-input Temperature Transmitter will not pass the 500Vrms dielectric strength test and this must be taken into account during installation.

	Ui	li	Pi	Ci	Li
Entity parameters	30 V	300 mA	1.3 W	2.2 nF	2 μΗ
FISCO parameters	17.5 V	380 mA	5.32 W	2.2 nF	2 μΗ

### International

#### **I7 IECEx Intrinsic Safety**

Certificate	IECEx FMG 10.0010X
Standards	IEC 60079-0:2011,
	IEC 60079-11:2011,
	IEC 60079-26:2006
Markings	Ex ia IIC Ga; Entity/FISCO; IP66/IP67
	Ex ib IIC [ia Ga] Gb; FISCO; IP66/IP67

#### Special Conditions for Safe Use (X):

- 1. The enclosure contains aluminum and is considered to present a potential risk of ignition by impact or friction. Care must be taken during installation and use to prevent impact or friction.
- 2. Rating Ex ib IIC [ia Ga] Gb; FISCO 9240040-976; IP66/IP67 is only applicable when supplied from a certified Ex [ib] FISCO Power Supply with triplicate output voltage limitation meeting the requirements for two faults ("ia" voltage limitation).
- 3. The Rosemount 2240S Multi-input Temperature Transmitter will not pass the 500Vrms dielectric strength test and this must be taken into account during installation.

	Ui	li	Pi	Ci	Li
Entity parameters	30 V	300 mA	1.3 W	2.2 nF	2 μH
FISCO parameters	17.5 V	380 mA	5.32 W	2.2 nF	2 μH

# Brazil

#### **I2 INMETRO Intrinsic Safety**

Certificate	UL-BR 17.0927X
Standards	ABNT NBR IEC 60079-0:2013,
	ABNT NBR IEC 60079-11:2013,
	ABNT NBR IEC 60079-26:2016
Markings	Ex ia IIC T4 Ga (Entity)
	Ex ib IIC [ia Ga] T4 Gb (FISCO)
	Tamb = -50 °C to +70 °C, IP 66/67

#### Special Conditions for Safe Use (X):

1. See certificate for special conditions.

	Ui	li	Pi	Ci	Li
Entity parameters	30 V	300 mA	1.3 W	2.2 nF	2 μH
FISCO parameters	17.5 V	380 mA	5.32 W	2.2 nF	2 μH

# **Technical Regulations Customs Union (EAC)**

#### **IM EAC Intrinsic Safety**

Certificate RU C-SE.AA87.B.00350

Markings FISCO field mounted device 0Ex ia IIC T4 Ga X 1Ex ib [ia Ga] IIC T4 Gb X Tamb = -50 °C to +70 °C, IP 66/67

#### Special Conditions for Safe Use (X):

1. See certificate for special conditions.

	Ui	li	Pi	Ci	Li
Entity parameters	30 V	300 mA	1.3 W	2.2 nF	2 μH
FISCO parameters	17.5 V	380 mA	5.32 W	2.2 nF	2 μH

# Japan

#### 14 Japan Intrinsic safe

Certificate CML 17JPN2123X

MarkingsEx ib [ia Ga] IIC T4 Gb, FISCO,  $-50^{\circ}C \le Ta \le +70^{\circ}C$ 

#### Special Conditions for Safe Use (X):

1. See certificate for special conditions.

	Ui	li	Pi	Ci	Li
FISCO parameters	17.5 V	380 mA	5.32 W	2.2 nF	2 μΗ

# **Republic of Korea**

#### IP Korea Intrinsic safe

Certificate 11-KB4BO-0065X

Markings FISCO Field Device (Fieldbus Terminal) Ex ia IIC T4

#### Special Conditions for Safe Use (X):

1. See certificate for special conditions.

	Ui	li	Pi	Ci	Li
Entity parameters	30 V	300 mA	1.3 W	2.2 nF	2 μΗ
FISCO parameters	17.5 V	380 mA	5.32 W	2.2 nF	2 μH

# India

#### IW India Intrinsic safe

Certificate	P382295/1
Markings	Ex ia IIC Ga
	Ex ib IIC (ia Ga) Gb

#### Special Conditions for Safe Use (X):

1. See certificate for special conditions.

# **Conduit plugs and adapters**

#### IECEx Flameproof and Increased Safety

Certificate	IECEx FMG 13.0032X
Standards	IEC60079-0:2011, IEC60079-1:2007-04, IEC60079-7:2006-07
Markings	Ex de IIC Gb

#### **ATEX Flameproof and Increased Safety**

- Certificate FM13ATEX0076X
- Standards EN60079-0:2012, EN60079-1:2007, IEC60079-7:2007

Markings 💿 II 2 G Ex de IIC Gb

#### Table 1: Conduit Plug Thread Sizes

Thread	Identification mark
M20 x 1.5	M20
½ - 14 NPT	1/2 NPT

#### **Table 2: Thread Adapter Thread Sizes**

Male thread	Identification mark
M20 x 1.5 – 6g	M20
½ - 14 NPT	1⁄2 - 14 NPT
3⁄4 - 14 NPT	¾ - 14 NPT
Female thread	Identification mark
M20 x 1.5 – 6H	M20
½ - 14 NPT	1⁄2 - 14 NPT
G1/2	G1/2

#### Special Conditions for Safe Use (X):

- 1. When the thread adapter or blanking plug is used with an enclosure in type of protection increased safety "e" the entry thread shall be suitably sealed in order to maintain the ingress protection rating (IP) of the enclosure. See certificate for special conditions.
- 2. The blanking plug shall not be used with an adapter.
- 3. Blanking Plug and Threaded Adapter shall be either NPT or Metric thread forms. G<sup>1</sup>/<sub>2</sub> thread forms are only acceptable for existing (legacy) equipment installations.

### **Custody Transfer**

#### Australia Custody Transfer

	-
Certificate	No 5/1/7
Standards	Regulation 60: National Measurement Regulations 1999
Belgium Custoc	ly Transfer
<b>BMS</b> Certificate	NR. P6.0.014.02-B-16

#### Croatia Custody Transfer

**Certificate** 558-02-01\_01-15-2

#### Czech Republic Custody Transfer

**Certificate** 0111-CS-C022-10

#### **Estonia Custody Transfer**

**Certificate** TJA 6.13-3\_15.09.11

#### France Custody Transfer

Certificate No. LNE-24609

#### **Germany Custody Transfer**

Certificate PTB-1.5-4058175 (Rosemount Tank Gauging system)

India Custody T	ransfer
Certificate	IND/13/12/191
Indonesia Custo	ody Transfer
Certificate	DITJEN MIGAS CT approval 26.10.2010
Italy Custody Tr	ransfer
Certificate	183349 (Rosemount Tank Gauging system)
Malaysia Custo	dy Transfer
Certificate	ATS 09-11
Netherlands Custody Transfer	
NMI Certificate	TC7982
Norway Custod	y Transfer
Certificate	No. N-11-7146
Poland Custody	Transfer
Certificate	ZT-7 2013
Portugal Custody Transfer	
Certificate	P12_101.12_31
Serbia Custody	Transfer
Certificate	393-7_0-01-2088
South Africa Cu	stody Transfer
Certificate	SAEx S11-065
Switzerland Cu	stody Transfer
Certificate	Zulassungszertifikat CH-L-11127-01
Russia Custody	Transfer
GOST Pattern App	roval:
Certificate	SE.C.32.639.A No. 68126 (2240), OC.C.29.010.A No. 70348 (Rosemount Tank Gauging system) OC.C.29.010.A No. 70349 (Rosemount Tank Gauging system)
Kazakhstan Cus	tody Transfer
GOST Pattern App	roval:
Certificate	KZ.02.02.06184-2018 (2240)

#### **OIML Custody Transfer**

**Certificate** R85-2008-SE-11.01

# **Dimensional drawings**

#### Figure 4: Rosemount 2240S





- A. Optional tag plate
- B. M33
- C. Optional mounting kit

Dimensions are in millimeters (inches).

#### Installation options

- Installed with a multiple spot temperature sensor
- Installed separately on a 33.4-60.3 mm (1 to 2-in.) pipe, or on a wall

#### Global Headquarters and Europe Regional Office Tank Gauging

Emerson Automation Solutions Box 150 (Visiting address: Layoutvägen 1) SE-435 23 Mölnlycke Sweden +46 31 337 00 00 +46 31 25 30 22

Sales.RTG@Emerson.com

#### Latin America Regional Office

Emerson Automation Solutions 1300 Concord Terrace, Suite 400 Sunrise, FL 33323, USA + 1 954 846 5030 + 1 954 846 5121 RMTLAContactUS@Emerson.com

#### Middle East and Africa Regional Office

Emerson Automation Solutions Emerson FZE P.O. Box 17033 Jebel Ali Free Zone - South 2 Dubai, United Arab Emirates III +971 4 8118100 C +971 4 8865465 C RTGMEA.Sales@Emerson.com

#### North America Regional Office Tank Gauging

#### Asia Pacific Regional Office

Emerson Automation Solutions 1 Pandan Crescent Singapore 128461 1 +65 6777 8211 2 +65 6777 0947 Specialist-OneLevel.RMT-AP@Emerson.com

in Linkedin.com/company/Emerson-Automation-Solutions

Twitter.com/Rosemount\_News

Facebook.com/Rosemount

🔛 Youtube.com/user/RosemountMeasurement

©2020 Emerson. All rights reserved.

Emerson Terms and Conditions of Sale are available upon request. The Emerson logo is a trademark and service mark of Emerson Electric Co. Rosemount is a mark of one of the Emerson family of companies. All other marks are the property of their respective owners.



# ROSEMOUNT