


## DIRECTIONS TO EMERSON AUTOMATION SOLUTIONS


1. Upon exiting the Greater Pittsburgh International Airport, follow signs for I-376 EAST / I-79 EAST / Pittsburgh / Pennsylvania Turnpike EAST.
2. Merge onto I-376 EAST.
3. Follow I-376 EAST for approx. 18 miles and through the Fort Pitt Tunnel.
4. Upon exiting the tunnel, proceed to the far left lane and follow signs for the Ft. Duquesne Bridge (I-279 NORTH).
5. Continue on I-279 NORTH for 1 mile.
6. Take Exit 1D for East Ohio Street toward Etna NORTH.
7. Merge onto PA-28 NORTH. Watch lane restrictions at Route 8 and the Highland Park Bridge Exits.
8. Take Exit 10 toward RIDC Drive.
9. Turn right at the stop sign. The Comfort Inn will be on your left. Bear right at the next stop sign. Emerson will be on your left.



## Emerson Automation Solutions Power & Water Solutions

200 Beta Drive  
Pittsburgh PA 15238

## TO RETURN TO AIRPORT



1. Take Route 28 SOUTH towards Pittsburgh.
2. Merge onto I-279 SOUTH towards I-376 WEST.
3. I-279 SOUTH becomes I-376 WEST as you cross the Ft. Pitt Bridge.
4. Stay on I-376 WEST (22/30 WEST) and follow signs to the airport.

0 1/2 1 2  
Scale in Miles