

INSTRUCTION ON HOW TO INSTALL LON WITH A MLT2 ANALYZER

MLT 2 analyzers provide internal screw terminals instead of a RJ45 connector to install LON cables. The reason is that the RJ45 does not fit through the IP66 cable glands.

To connect your LON cable:

- Feed the LON cable (without RJ45 connector) through the cable gland.
- Strip the cable insulation, locate the red and green wires inside the cable and, inside the analyzer, connect them to the terminals marked with „LON“. There is no polarity to observe for these lines.
- Finally fix the gland.

Keep this instruction for future use!

WORLD HEADQUARTERS

ROSEMOUNT ANALYTICAL EUROPE

Emerson Process Management

GmbH & Co. OHG

Industriestrasse 1

63594 Hasselroth

Germany

T 49 6055 884 0

F 49 6055 884209

Emerson Process Management

Rosemount Analytical Inc.

6565 P Davis Industrial Parkway

Solon, OH 44139 USA

T 440.914.1261

Toll Free in US and Canada 800.433.6076

F 440.914.1271

e-mail: gas.csc@EmersonProcess.com

www.raihome.com

GAS CHROMATOGRAPHY CENTER AND LATIN AMERICA

Emerson Process Management

Rosemount Analytical Inc.

11100 Brittmoore Park Drive

Houston, TX 77041

T 713 467 6000

F 713 827 3329

EUROPE, MIDDLE EAST AND AFRICA

Emerson Process Management

Shared Services Limited

Heath Place

Bognor Regis

West Sussex PO22 9SH

England

T 44 1243 863121

F 44 1243 845354

ASIA-PACIFIC

Emerson Process Management

Asia Pacific Private Limited

1 Pandan Crescent

Singapore 128461

Republic of Singapore

T 65 6 777 8211

F 65 6 777 0947

e-mail: analytical@ap.emersonprocess.com